



Broadcast Network Processor

BNP3xr User Guide, Release 3

RGB Networks, Inc.
390 West Java Drive
Sunnyvale, CA 94089
Support Tel: 877-RGB-NETW
Fax: (408) 701-2710
www.rgbnetworks.com

BNP3xr User Guide

Document part number: 250-0098-01 Rev A, BNP3xr User Guide.

Printed 05-16-2011

Copyright 2005-2011 RGB Networks, Inc. All rights reserved worldwide.

This material is protected by the copyright laws of the United States and other countries. No part of this document may be reproduced, distributed, or altered in any form, by any means, by any entity nor may it be used to make any derivative work (such as translation, transformation, or adaptation) except in accordance with applicable agreements, contracts, or licensing, without the express written consent of RGB Networks.

Notice

RGB Networks provides this document without warranty of any kind, either implied or expressed, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. RGB Networks has made every attempt to ensure the accuracy and completeness of information in this document at the time of publication. As we continuously improve and add features to our products, RGB Networks reserves the right to revise this document without prior notification of such revision or change. Variations in network design or environment are outside the control of RGB Networks. You may verify product specifications and obtain assistance selecting the appropriate solution for your situation by contacting RGB Networks.

Trademarks

RGB Networks, VIA, and RDS are trademarks of RGB Networks, Inc. All other company, brand, and product names are trademarks or registered trademarks of their respective holders. The products described are covered by one or more U.S. and foreign patents pending

Patents

US Patents. 6,996,129; 7,046,677. Other US and foreign patents pending.

BNP3xr User Guide document history

Part Number	Software Version	Release Date	Document Changes
250-0052-01 rev A	3.0	02/18/2010	Production Release
250-0052-01 rev B	3.0.1	05/07/2010	<ul style="list-style-type: none">Added Operator, Advanced Messaging, and Logo Overlay scheduling feature.PSIP enhanced grooming configuration.
250-0052-01 rev C	3.1.1	10/18/2010	<ul style="list-style-type: none">Added transparency support for Non-Ascii text.Added EBIF support.Added AAA User Authentication.DC power supply support.Enhanced NTP synchronization feature.Output TS modification enhancements.DVB-CA enhancements.Added ES-level grooming.
250-0052-01 rev D	3.1.1	02/23/2011	<ul style="list-style-type: none">Added appendix of Caution and Warning statements in French and German and TÜV GS certification
250-0052-01 rev E	3.2.0	03/02/2011	<ul style="list-style-type: none">DPI cue and postblack handling
250-0098-01 rev A	3.2.1	05/16/2011	<ul style="list-style-type: none">Changed part numberNetwork cue forwarding during DPIPSI & PSIP pass-throughH.264 enhancements for HD

Table of Contents

Chapter 1: Introduction	1
Document Organization	2
Document Audience	2
Document Conventions	3
Graphics Used	3
Chapter 2: Overview	5
In This Chapter:	5
Product Overview	5
Product Features	5
BNP3xr Applications	6
Grooming, Transrating and Multiplexing	7
DPI-Based Ad Splicing	7
Messaging System	7
DVB Conditional Access (DVB-CA) Encryption	8
BNP Deployment Architecture	9
Redundancy	12
Program Redundancy	12
Gigabit Ethernet Port Output Mirroring	12
1:1 Chassis-level Redundancy	13
Chapter 3: Installation	15
In This Chapter:	15
Before You Begin	15
Required Equipment	15
Electrostatic Precautions	16
Broadcast Network Processor Components	16
Front Panel	16
LED Indicators	17
Port Mapping	19
Rear Panel	19
BNP3xr Component Layout	20
Rack Mounting the BNP3xr	22
Grounding the BNP3xr	24
To connect the chassis ground:	24
Installing SFP Modules	25
Connecting AC Power to the BNP3xr	26
Disconnecting AC Power from the BNP	27
Connecting DC Power to the BNP3xr	27
Before Connecting Power	27
Connecting Power	27
Disconnecting DC Power from the BNP3xr	29
Connecting External Ports	29
Installing the Compact Flash Card	30

Chapter 4: System Configuration	31
In This Chapter:	31
Obtaining Java Runtime Environment	32
Obtaining JRE from the RGB Customer Portal	32
Launching the BNP Element Manager	32
Using the Element Manager	34
Logging In	34
BNP Element Manager Overview	34
Element Manager Title Bar	34
Element Manager Main Menu and Tabs	35
Status Information	35
Chassis View	36
Setting the Time Offset Table (TOT)	38
Global Chassis Configuration	41
NTP Server Force Sync	45
Force Sync on Redundant BNP Systems	46
Configuring Chassis-level 1:1 Redundancy	47
Forcing Redundancy	50
1:1 Redundancy Best Practices and Considerations	50
Ethernet Control Port Configuration	50
Determining the BNP IP Address for DHCP	53
GigE Port Configuration	53
Gigabit Ethernet Port Mirroring	54
Removing Port Mirroring	55
Configuring ASI Ports	55
Modifying a Port Name	56
User Authentication	57
Global Configuration	59
Local Configuration	61
Server Configuration	62
Messaging System Configuration	69
Messaging Zones	69
Logo Overlay Zones	90
Messaging System Zone Priority	99
Show Program List	99
Creating Messaging Zone Transport Streams and Output Programs	103
SNMP Configuration	103
Configuring an SNMP Trap Agent	103
Changing a Community String	104
Upgrading Software	107
To Upgrade Software in a Single Chassis Environment	107
To Upgrade Software in a Redundant Chassis Environment	109
Clearing the Web Start Cache	110
The License Manager	111
Overview	111
Functionality	111
Purchasing Licenses	112
Activating a License Key	112
Hardware Capacity Status	113
Flash Portability	114

Regrooming	114
Stopping All Services	115
Rebooting the System	116
Checking for the BNP Element Manager Version	117
Chapter 5: Grooming and PSIP	119
In This Chapter:	119
Before You Begin	119
Overview	119
Using the Mapping Tab	120
Viewing Program-Level Input Source	122
Viewing ES-Level Input Source	123
Interpreting the Program Status Icons	124
Interpreting Elementary Stream Status Icons	125
Expanding and Collapsing Mapping	126
Creating Input Transport Streams	127
Basic Input Transport Stream Creation	127
Multiple IP and UDP Creation	128
Managing Input Transport Streams	129
GigE Port Transport Stream Options	129
ASI Port Transport Stream Options	130
Creating MPEG-2 Output Transport Streams	131
ASI Port MPEG-2 Transport Streams	132
GigE Port MPEG-2 Transport Streams	133
Advanced Transport Stream Settings	135
SPTS Advanced Options	135
MPTS Advanced Options	136
Creating ATSC Output Transport Streams	137
Creating SCTE Output Transport Streams	141
Creating DVB Output Transport Streams	142
Setting Up Network Information Tables (NIT) for DVB	145
Creating a FAT ASI Port Output Transport Stream	148
Advanced FAT ASI Transport Stream Settings	150
Creating Programs	151
Creating Output Programs Manually	151
Program Messaging System Setting	154
Modifying and Deleting Streams or Programs	156
Modifying Streams or Programs	156
Deleting Streams and Programs	163
Drag and Drop Grooming	163
Drag and Drop Grooming Options	164
Viewing Grooming Details	173
Scheduling Grooming - One time event	174
Program Redundancy	175
Modes of Program Redundancy Operation	175
To Configure Program Redundancy	176
Manual Recovery Procedures	177

Elementary Streams	179
Creating an Elementary Stream	179
Reordering an Elementary Stream	185
Elementary Stream Remapping	186
Reserved PIDs	186
Dummy PIDs	187
Adding an Unreferenced PID as an Elementary Stream	190
Elementary Stream Ghost PID Management	193
Unreferenced PID Pass Through	194
Unreferenced PID Mapping	196
Referenced PID Mapping	199
Managing PMT and ES Descriptors	203
To Add a Program Descriptor Rule	204
To Edit a Program Descriptor Rule	207
To Delete a Program Descriptor Rule	207
Monitoring Bitrates	208
Chapter 6: Digital Program Insertion (DPI)	213
In This Chapter:	213
Digital Program Insertion	213
Connecting an Ad Server to the BNP	214
Setting SCTE 30 and SCTE 35 Message Handling	215
Setting Postblack Options for DPI	217
Chapter 7: ETV Binary Interchange Format (EBIF)	219
In This Chapter:	219
Overview	219
Prerequisite Reading	219
Functionality	219
Use Case Configuration Examples	220
Pre-Bound Ad Splice	221
Pre-Bound EBIF Passthrough (no DPI)	224
Pre-Bound EBIF Drop	227
Pre-Bound EBIF Passthrough and Keep During Ad Splice	228
Pre-Bound Network EBIF; Late-Bind EBIF During Ad	231
Chapter 8: DVB Conditional Access	237
In This Chapter:	237
Overview	237
DVB-CA Required Components	238
DVB-CA Configuration	238
Verify DVB-CA License	239
Set Up an NTP Server	240
Configure Ethernet Control Port for DVB-CA	240
Configure GigE or ASI Port(s) for DVB-CA System	241
Create Input TS(s) for DVB-CA System	243
Create Output DVB TS(s) for DVB-CA System	244
Groom Input Program(s) to Output DVB TS	245
Create Input PSI/SI Table Grooming	247
Groom the Ghost Program to Output DVB TS	249
Configure DVB-CA Global Parameters	250

Configure DVB-CA Tab: External and Internal EIS Mode	254
Complete DVB-CA Tab Configuration for Internal EIS Mode	265
DVB-CA Best Practices and Considerations	274
Chapter 9: Monitoring the BNP	275
In This Chapter:	275
Selecting the Elements to View	275
Viewing Alarms and Events	275
Alarms and Events	276
The Status Bar	277
Chapter 10: Troubleshooting	279
In This Chapter:	279
LED Indicators	279
Event Log Analysis	280
Software Upgrade	280
Contacting RGB Customer Support	280
Searching the RGB Customer Portal	281
Chapter 11: Field-replaceable Units	283
In This Chapter:	283
Overview	283
Replacing a Power Supply	284
Removing a Power Supply	284
Inserting a Power Supply	286
Replacing a Fan Tray	287
Replacing a Gigabit Ethernet Processor (GBP3) Module	289
Removing a GBP3 Module	289
Replacing a GBP3 Module	290
Replacing a Processor Module (PROC3) or an ASI Module	290
Removing a PROC3 or ASI Module	291
Replacing a PROC3 or ASI Module	291
Chapter 12: Specifications	293
In This Chapter:	293
Input Interfaces/Output Interfaces	293
MPEG Processing	293
Video Formats	294
Audio Formats	294
Elementary Stream Types & Conversions	295
Digital Broadcast	295
Regulatory Compliance	296
Electrical/Mechanical	296
Environmental	296
Appendix A: Editing the DVB NIT Table	297
In This Appendix:	297
NIT Values Supported	297

Naming, Viewing, Deleting and Editing NIT Configuration Files	300
Naming a Configuration File	300
Viewing a Configuration File	302
Deleting a Configuration File	303
Editing a Configuration File	304
Suggestions for Editing the NIT Table	311
Appendix B: Localized Cautions and Warnings	313
Information to Users	319
United States	319
For Class A Equipment	319
Canada	319
European Declaration of Conformity	320
Glossary	321
Index	329

List of Tables

CHAPTER 1: Introduction

Table 1: Document Conventions	3
-------------------------------------	---

CHAPTER 2: Overview

CHAPTER 3: Installation

Table 2: LED indicators	18
Table 3: Environmental Requirements	22
Table 4: Supported SFPs	25

CHAPTER 4: System Configuration

Table 5: User levels	34
Table 6: Element Manager Menus	35
Table 7: Element Manager Primary Tabs	35
Table 8: Chassis information window	38
Table 9: Tot Time Offset Window Parameters	40
Table 10: Global Chassis Configuration Fields	42
Table 11: Ethernet Control Port Configuration Fields	51
Table 12: GigE Port Configuration Fields	54
Table 13: User Authentication - Global Fields	60
Table 14: Local User Accounts:	62
Table 15: User Authentication - Servers - Add/Edit Server Fields	65
Table 16: User Authentication - Servers - Edit AAA Server Order Fields.	67
Table 17: AAA Server List Example	68
Table 18: Messaging Zones subtab	70
Table 19: Add / Modify EAS Messaging Zone menu	72
Table 20: Crawl Positioning	75
Table 21: Operator Messaging tab	78
Table 22: Advanced Messaging tab	84
Table 23: Logo Overlay Zones subtab	92
Table 24: Logo Overlay tab	94
Table 25: Upgrade Software Configuration Fields	108

CHAPTER 5: Grooming and PSIP

Table 26: Program Status Icons	124
Table 27: Elementary Stream Icons	125
Table 28: Input Transport Stream Creation	127
Table 29: Selecting Multiple IP and UDP	128
Table 30: Input Transport Stream pop-up menu options	130
Table 31: MPEG-2 Output Transport Stream Creation (ASI Port)	132
Table 32: MPEG-2 Output Transport Stream Creation (MPEG-2, GigE Port)	133
Table 33: Advanced Transport Stream Settings	137
Table 34: ATSC TS Creation: PSIP Table Information Configuration Parameters	139
Table 35: DVB Output Transport Stream Configuration Parameters	145
Table 36: Creating a FAT ASI Transport Stream	149
Table 37: Create Output Program Configuration Parameters	153
Table 38: Messaging System Setting window	155

Table 39: Drag and drop grooming.....	163
Table 40: Configure Program Mapping	166
Table 41: Service Level Configuration Details.....	169
Table 42: Configure Elementary Stream Mapping	171
Table 43: Program Redundancy Modes of Operation	176
Table 44: Manage Elementary Streams menu	184
Table 45: Manage Descriptor Rules fields.....	205
CHAPTER 6: Digital Program Insertion (DPI)	
Table 46: Postblack Enable Options	218
CHAPTER 7: ETV Binary Interchange Format (EBIF)	
CHAPTER 8: DVB Conditional Access	
Table 47: Output DVB TS parameters for DVB-CA configuration	244
Table 48: DVB-CA Global Configuration fields	252
Table 49: Create ECMG dialog fields	257
Table 50: Create EMM dialog descriptions.....	260
Table 51: Create SCG dialog - Internal EIS mode	268
Table 52: Create ECM dialog	271
CHAPTER 9: Monitoring the BNP	
CHAPTER 10: Troubleshooting	
Table 53: LED Indications	279
Table 54: Contacting Customer Support	280
CHAPTER 11: Field-replaceable Units	
CHAPTER 12: Specifications	
Table 55: Input/Output Interfaces	293
Table 56: MPEG Processing	293
Table 57: Video Formats	294
Table 58: Audio Formats	294
Table 59: Elementary Stream Types & Conversions.....	295
Table 60: Digital Broadcast	295
Table 61: Regulatory Compliance	296
Table 62: Electrical and Mechanical	296
Table 63: Environmental Ranges	296
APPENDIX A: Editing the DVB NIT Table	
Table 64: Values Supported	297
APPENDIX B: Localized Cautions and Warnings	

List of Figures

CHAPTER 1: Introduction

Figure 1, RGB's Broadcast Network Processor—Model BNP3xr	1
--	---

CHAPTER 2: Overview

Figure 2, Regional Ad Zone Insertion Illustration.....	7
Figure 3, BNP in SCTE 18 Digital EAS application	8
Figure 4, BNP3xr in a DVB-CA network	9
Figure 5, Example of BNP Grooming of GigE or ASI Input Over GigE Transport Network	10
Figure 6, Example of SDV Architecture over GigE Transport Network	10
Figure 7, Example of Co-Located ASI Architecture	11
Figure 8, 1:1 Chassis Redundancy using Heartbeat and Virtual IP Failover Mechanism	14

CHAPTER 3: Installation

Figure 9, Front panel (with bezel)	16
Figure 10, Front panel (without bezel)	17
Figure 11, LEDs	17
Figure 12, Port mapping and LED indicators	19
Figure 13, Rear panel	19
Figure 14, DC Power Supply	20
Figure 15, BNP3xr chassis, components visible	21
Figure 16, Gigabit Processor - 3 Module	21
Figure 17, Front brackets attached	22
Figure 18, Rack shelf	23
Figure 19, Mounted BNP3xr	24
Figure 20, Grounding terminal, rear of chassis: AC power supply top, DC power supply bottom	25
Figure 21, Connect AC power	26
Figure 22, Connect DC power	28
Figure 23, Connect the power cables	29

CHAPTER 4: System Configuration

Figure 24, Enter the IP address of the BNP to access	32
Figure 25, Launch BNP Element Manager window	33
Figure 26, BNP Element Manager login window (Local login, left; AAA server login, right)	33
Figure 27, BNP3xr title bar	35
Figure 28, Typical BNP Element Manager status bar	36
Figure 29, Chassis tab - AC view	36
Figure 30, Chassis tab - DC view	37
Figure 31, Choosing TOT Time Offset	39
Figure 32, TOT Time Offset Window	39
Figure 33, Global chassis configuration	41
Figure 34, Apply Force Sync	45
Figure 35, Reboot Password Verification window	45
Figure 36, Reboot confirmation	46
Figure 37, Force sync for standby NTP server	46
Figure 38, Ethernet Control Port configuration	51

Figure 39, GigE Port configuration screen	53
Figure 40, Mirroring GigE ports	55
Figure 41, ASI port configuration tab.....	56
Figure 42, Modify Port Name Menu	56
Figure 43, Modifying the Port Name.....	57
Figure 44, Port Name Modified	57
Figure 45, BNP User Authentication Workflow.....	58
Figure 46, User Authentication - Global, AAA disabled.....	59
Figure 47, User Authentication - Global, AAA enabled	60
Figure 48, User Authentication - Local	61
Figure 49, User Authentication - Servers.....	63
Figure 50, Add AAA Server	64
Figure 51, Edit AAA Server	65
Figure 52, Edit AAA Server Order	66
Figure 53, Edit AAA Server Order - modified	66
Figure 54, New Server order	67
Figure 55, Server deletion confirmation	68
Figure 56, Configuration -> Messaging System tab	69
Figure 57, Messaging Zone pop-up window	71
Figure 58, Add EAS Messaging window	72
Figure 59, Modify EAS Zone	75
Figure 60, Delete Output TS-associated messaging zones	76
Figure 61, Messaging Zone pop-up window	77
Figure 62, Add Operator and Advanced Messaging Zone - Operator Messaging tab	77
Figure 63, Advanced Messaging Schedule Window	81
Figure 64, Modify Operator Messaging Zone	82
Figure 65, Messaging Zones pop-up window.....	83
Figure 66, Advanced Messaging Zone tab.....	83
Figure 67, Modify Advanced Zone window	88
Figure 68, Delete Output TS-associated messaging zones	89
Figure 69, Alpha Channel transparency examples	90
Figure 70, Configuration -> Logo Overlay Zones tab	91
Figure 71, Logo Overlay Positioning	93
Figure 72, Logo Overlay Zone pop-up window	93
Figure 73, Add Logo Overlay Zone tab	94
Figure 74, Modify Logo Overlay Zone window	98
Figure 75, Delete Output TS-associated messaging zones	99
Figure 76, Show Program List Pop-up windows	100
Figure 77, Show Program List window.....	101
Figure 78, Show Program List window - drill down	102
Figure 79, Show Program List pop-up menu.....	102
Figure 80, Messaging Zone Icons	103
Figure 81, Scroll-over program status	103
Figure 82, SNMP configuration window	104
Figure 83, Modifying an SNMP Community String.....	105
Figure 84, SNMP reboot prompt	105
Figure 85, BNP unreachable message - SNMP.....	105
Figure 86, Log in - prompt for new SNMP strings	106
Figure 87, Log in - new SNMP strings entered	106
Figure 88, Upgrade Software dialog.....	107
Figure 89, Software Upgrade - Redundant chassis	109
Figure 90, Java control panel.....	110
Figure 91, The License Manager	113
Figure 92, Apply regrooming	114

Figure 93, System Shutdown confirmation dialog	115
Figure 94, Password Verification prompt	115
Figure 95, Password Verification prompt	116
Figure 96, Reboot dialog	117
Figure 97, About BNP dialog	117

CHAPTER 5: Grooming and PSIP

Figure 98, Grooming-Mapping configuration	121
Figure 99, Viewing program-level input source	122
Figure 100, Viewing ES-level input source	123
Figure 101, Existing Mapping	126
Figure 102, Collapse Mapping	126
Figure 103, Create GigE Input TS	127
Figure 104, Selecting multiple UDP/IP ports	128
Figure 105, Input Transport Streams created	129
Figure 106, Input Transport Stream pop-up menu - GigE	130
Figure 107, Input Transport Stream pop-up menu - ASI	130
Figure 108, Creating output TS (MPEG-2, ASI port)	132
Figure 109, Creating output TS (MPEG-2) - GigE port)	133
Figure 110, Create Output TS - ARP field	135
Figure 111, Advanced Transport Stream - SPTS	136
Figure 112, Advance Transport Stream Setting - MPTS	137
Figure 113, Create Output TS (ATSC) - ASI Port	138
Figure 114, Creating output TS (ATSC) - GigE Port	139
Figure 115, Creating output TS (SCTE) - ASI port	141
Figure 116, Creating output TS (SCTE) - GigE port	142
Figure 117, Creating output TS (DVB) - ASI port	143
Figure 118, Creating output TS (DVB) - GigE port	144
Figure 119, Setup Network Information Table screen	146
Figure 120, Using the Editing Feature	147
Figure 121, Choosing a FAT ASI Transport Stream	148
Figure 122, Create Output Transport Stream (FAT ASI)	148
Figure 123, FAT ASI Ports Created	150
Figure 124, FAT ASI - Advance Transport Stream Setting	151
Figure 125, Create Output Program popup	152
Figure 126, Create Output Program dialog	152
Figure 127, Program Messaging System Setting window	155
Figure 128, Modify Input TS - GigE port	156
Figure 129, Modify Input TS - ASI port.	156
Figure 130, Modify Output TS (MPEG-2 shown) - GigE port	158
Figure 131, Modify Output TS - ASI port.	159
Figure 132, Program Pop-Up menu - Modify Program	160
Figure 133, Modify Input program - GigE or ASI port	160
Figure 134, Program Name Changed	160
Figure 135, Program Pop-Up menu - Modify Program	162
Figure 136, Modify Output program - GigE or ASI port	162
Figure 137, Drag input program to output TS	164
Figure 138, Configure Program Mapping window	164
Figure 139, Configure Program Mapping window - program to program	165
Figure 140, ES to Program Drag and Drop	170
Figure 141, Configure Elementary Stream Mapping window	170
Figure 142, ES Grooming - Reserved PID	171
Figure 143, Configure ES Mapping - Reserved PID	171

Figure 144, ES Grooming Replacement window	173
Figure 145, Grooming detail display - TS	174
Figure 146, Grooming schedule	175
Figure 147, Program Redundancy	176
Figure 148, Configure Program Mapping - Program Redundancy	177
Figure 149, Program Redundancy - Manual Recovery	178
Figure 150, Manage Elementary Streams	179
Figure 151, Manage Elementary Streams - New	180
Figure 152, Manage Elementary Streams - ES Type choices	180
Figure 153, Manage Elementary Streams - Stream Type, drop down	181
Figure 154, Manage Elementary Streams - Audio Selection	181
Figure 155, Manage Elementary Streams - Data Selection	181
Figure 156, Manage Elementary Streams - PID	182
Figure 157, Manage Elementary Streams - Dummy	183
Figure 158, Manage Elementary Streams - Preconfigured for PMT	183
Figure 159, Reordering an Elementary Stream	185
Figure 160, ES Reordered	186
Figure 161, Dummy PID: Real data stream groomed	187
Figure 162, Manage ES - New ES for Dummy PID	188
Figure 163, Manage Elementary Streams - Dummy PID fields completed	189
Figure 164, Dummy Data PID in Grooming -> Mapping window	189
Figure 165, Choosing a Ghost Program	191
Figure 166, Create Ghost Program	191
Figure 167, New Program Stream	191
Figure 168, Adding an Elementary Stream	192
Figure 169, Adding Elementary Stream: Single ES left, Multiple ES right	192
Figure 170, New Unreferenced PID	193
Figure 171, Ghost Program With Unreferenced PID	194
Figure 172, Ghost Program Dragged and Dropped to Output TS	195
Figure 173, Ghost Program Passed Through	195
Figure 174, Starting Unreferenced PID Mapping	196
Figure 175, Create Output Transport Stream	197
Figure 176, Configure Program Mapping Window	198
Figure 177, Select Elementary Stream Window	198
Figure 178, Starting Window for Referenced PID Mapping	199
Figure 179, Mapping the Transport Stream	200
Figure 180, Manage Elementary Streams	201
Figure 181, New ES filled In	201
Figure 182, Dummy data PID in Program grayed out	202
Figure 183, Manage ES - Dummy and Reserved status	202
Figure 184, Manage Descriptor Rules pop-up	203
Figure 185, Manage Descriptor Rules window	203
Figure 186, Add Descriptor Rule window	204
Figure 187, Add Descriptor Rule - New status	204
Figure 188, Manage Descriptor Rules - Rules Added	205
Figure 189, Add Descriptor Rule - DEC to HEX toggle	206
Figure 190, Edit Descriptor Rule - Changed status	207
Figure 191, Manage Descriptor Rules - Rules Deleted	208
Figure 192, Input Monitoring bitrates	209
Figure 193, Input bitrate exceeds output	210
Figure 194, Input-Output Bit Rate Monitor tab	211

CHAPTER 6: Digital Program Insertion (DPI)

Figure 195, Regional Ad Zone Insertion Illustration.....	213
Figure 196, Ad server - BNP connection	214
Figure 197, SCTE 30 to SCTE 35 Conversion	215
Figure 198, Configure Program Mapping window	216
Figure 199, Allocated PID for Cue Table	216
Figure 200, Global chassis configuration.....	217

CHAPTER 7: ETV Binary Interchange Format (EBIF)

Figure 201, ETV EBIF Data Source flow	220
Figure 202, Pre-bound Ad Splice flow	221
Figure 203, Input program (without ETV data) groomed to oTS.....	222
Figure 204, Configure Program Mapping window - EBIF/EISS Placeholder	222
Figure 205, Program with placeholders groomed - ESs grayed out	223
Figure 206, Manage Descriptor Rules - EISS & EBIF additions	224
Figure 207, Broadcast EBIF enabled.....	224
Figure 208, Input program (with ETV data) groomed to oTS.....	225
Figure 209, Configure Program Mapping - EBIF/EISS defaults	226
Figure 210, Program with ETV ESs passed through	226
Figure 211, Broadcast EBIF disabled	227
Figure 212, Configure Program Mapping - EBIF/EISS unchecked.....	228
Figure 213, Program with ETV ESs dropped.....	228
Figure 214, Broadcast EBIF groomed as Splice/Keep	229
Figure 215, Configure Program Mapping - Play through ad	230
Figure 216, Program with ETV ESs passed through (Splice/Keep)	230
Figure 217, Pre-bound Network EBIF, late-bind EBIF during ad.....	231
Figure 218, Input program (with ETV data) groomed to oTS; Late-bound	232
Figure 219, Configure Program Mapping - Play during ad only.....	233
Figure 220, Late-Bind Source Dialog window.....	234
Figure 221, Late-Bind Source selected	235
Figure 222, Configure Program Mapping window - Late-bound selected.....	235
Figure 223, Program with late-bound ETV ESs.....	236
Figure 224, View Late-Bind Source in output program.....	236

CHAPTER 8: DVB Conditional Access

Figure 225, BNP3xr in a DVB-CA network	238
Figure 226, DVB-CA Element Manager additions	239
Figure 227, DVB-CA - NTP server setup	240
Figure 228, DVB-CA - Ethernet Control Port mapping	241
Figure 229, Configure GigE - DVB-CA	242
Figure 230, Configure ASI - DVB-CA	243
Figure 231, Create Input TS - DVB-CA	243
Figure 232, Create Output TS - DVB-CA: GigE port (left); ASI port (right).....	244
Figure 233, Configure Program Mapping - DVB-CA.....	245
Figure 234, Reserve ES PIDs - DVB-CA.....	246
Figure 235, Configure Program Mapping - PIDs & Program changed - DVB-CA.....	246
Figure 236, Reserved PIDs to Output (in hex) - DVB-CA.....	247
Figure 237, Create Input TS for PSI/TS - DVB-CA	247
Figure 238, Create Ghost Program - DVB-CA.....	248
Figure 239, Ghost Program in GigE - DVB-CA.....	248
Figure 240, Add Elementary Stream PIDs - DVB-CA.....	248
Figure 241, Ghost Program Elementary Streams - DVB-CA.....	249

Figure 242, Configure Program Mapping - Ghost Program - DVB-CA.....	249
Figure 243, Output grooming window with ghost program added - DVB-CA	250
Figure 244, DVB-CA Global Configuration - Internal EIS mode default.....	251
Figure 245, DVB-CA Global Configuration - External EIS mode default.....	252
Figure 246, DVB-CA tab.....	254
Figure 247, Create CA System popup	255
Figure 248, Create CA System dialog.....	255
Figure 249, New CAS Added	255
Figure 250, Expand CAS Name	256
Figure 251, Create ECMG pop-up	256
Figure 252, Create ECMG.....	256
Figure 253, ECMG Added to ECMG List.....	257
Figure 254, Create EMMG pop-pop	258
Figure 255, Create EMMG	258
Figure 256, EMMG Created	258
Figure 257, Create EMM pop-up.....	259
Figure 258, Create EMM dialog	259
Figure 259, EMM Created.....	259
Figure 260, Join/Disjoin TS - external	261
Figure 261, Join/Disjoin TS to EMM window.....	261
Figure 262, Join/Disjoin TS - port expanded	261
Figure 263, Join/Disjoin TS - TS added to EMM - No PID	262
Figure 264, Join/Disjoin TS - PID entry.....	262
Figure 265, Join/Disjoin TS - PID modified	263
Figure 266, EMM Program joined to TS.....	263
Figure 267, Stream IDs connected.....	264
Figure 268, SCG List - ESs Scrambled.....	265
Figure 269, Create Access Criteria pop-up.....	266
Figure 270, Create Access Criteria dialog.....	266
Figure 271, Access Criteria List - Total ACs	267
Figure 272, Create SCG pop-up	267
Figure 273, Create SCG dialog.....	268
Figure 274, Monitor SCG dialog.....	270
Figure 275, Create ECM pop-up	271
Figure 276, Create ECM dialog.....	271
Figure 277, Join Program and ES pop-up.....	273
Figure 278, Select service list and ES list Objects dialog	273
Figure 279, Select service list and ES list Objects - ES level.....	274

CHAPTER 9: Monitoring the BNP

Figure 280, Alarms & Events tab.....	276
Figure 281, The status bar	277

CHAPTER 10: Troubleshooting

Figure 282, LED Indicator Locations	279
Figure 283, RGB Customer Portal home page	281
Figure 284, Customer Portal home page - Direct and Reseller	281
Figure 285, Knowledge Base search - Direct and Reseller.....	281

CHAPTER 11: Field-replaceable Units

Figure 286, Top view of chassis, with FRUs visible	283
Figure 287, Gigabit Processor - 3 Module.....	284

Figure 288, Power supply handle (AC power supply).....	285
Figure 289, Power supply handle (DC power supply)	285
Figure 290, Power supply removal (AC power, left; DC power, right)	286
Figure 291, Power supply insertion (AC power, left; DC power, right)	287
Figure 292, Fan tray removal.....	288
Figure 293, Fan tray replacement.....	288
Figure 294, Front bezel removal.....	289
Figure 295, Loosen the GBP3 module release screws	289
Figure 296, GBP3 module removal	290
Figure 297, Loosen the insertion/removal screws	291
Figure 298, Remove the module	291
Figure 299, Install the ASI or PROC3 module (ASI shown)	292

CHAPTER 12: Specifications

APPENDIX A: Editing the DVB NIT Table

Figure 300, Window With No Arrays.....	300
Figure 301, Default Array.....	301
Figure 302, Array2 Added.....	301
Figure 303, NIT Configuration File Viewed in XML Format	302
Figure 304, Assigning a Name to a Configuration File	302
Figure 305, Delete Confirmation.....	303
Figure 306, Setup Network Information Table screen	304
Figure 307, Editing Window.....	304
Figure 308, Icon Menu	305
Figure 309, Namespace Qualifier Window	306
Figure 310, Search Window	306
Figure 311, Large Vertical Bar Clicked Fully Compress	307
Figure 312, First Level of Expansion	307
Figure 313, Second Level of Expansion	308
Figure 314, Third Level of Expansion	308
Figure 315, Inserting a Node Before.....	309
Figure 316, Node Inserted Before	309
Figure 317, Error Message from Wrong Type of Data Character	310
Figure 318, Data Type Mismatch Corrected	310
Figure 319, Linkage Deleted.....	311

APPENDIX B: Localized Cautions and Warnings

Introduction

RGB's Broadcast Network Processor 3xr model (BNP3xr) offers a 2 rack unit (RU) platform with hot-swappable redundant fan modules and power supplies.

The BNP3xr delivers the industry's highest density digital video solution for grooming, statistical multiplexing, transrating, digital program insertion (DPI), and the incorporation of DVB Conditional Access for program encryption. Based on RGB's flexible, scalable and modular platform, the BNP simplifies and expedites deployments of advanced video services, simplifies operation and management, and reduces operational and capital costs.

Receiving input through its Gigabit Ethernet or ASI interfaces, the BNP3xr can statistically multiplex while performing grooming and digital ad and overlay insertion.

The BNP3xr can receive both standard definition (SD) and high definition (HD) program services, can concurrently groom and insert digital ads within the same box while providing program-level encryption.

The BNP is fully MPEG compliant and interoperable with leading cable industry equipment. The 3xr unit offers hot-swappable redundant fan modules and power supplies.

The BNP makes configuration more intuitive and simple by providing an easy-to-use Java-based graphical user interface that can be accessed through a standard Web browser. Configuration can be performed through SNMP using any standard network management application. The SNMP MIBs are readily available from the BNP home page.



Figure 1. RGB's Broadcast Network Processor—Model BNP3xr

This guide describes the installation, configuration, and FRU replacement for the BNP3xr.

Document Organization

This guide is organized as follows:

- [Chapter 1, "Introduction,"](#) (this chapter) describes the contents and conventions used in this guide.
- [Chapter 2, "Overview,"](#) provides a detailed description of the BNP3xr and its features.
- [Chapter 3, "Installation,"](#) describes the tools, precautions, and steps necessary to install the system in the network.
- [Chapter 4, "System Configuration,"](#) describes the initial product setup and product configuration using the Java-based *BNP Element Manager*.
- [Chapter 5, "Grooming and PSIP,"](#) shows you how to set up grooming, transrating, and other configuration and operational procedures.
- [Chapter 6, "Digital Program Insertion \(DPI\)"](#) describes DPI using the BNP3xr.
- [Chapter 7, "ETV Binary Interchange Format \(EBIF\),"](#) provides an overview of EBIF and typical use cases for configuration.
- [Chapter 8, "DVB Conditional Access"](#) describes how to set up DVP-CA system using the BNP3xr.
- [Chapter 9, "Monitoring the BNP,"](#) discusses the methods used to monitor the health of the BNP3xr and its status in the network.
- [Chapter 10, "Troubleshooting,"](#) provides information about system status, alarm messages, software upgrades, and contacting technical support.
- [Chapter 11, "Field-replaceable Units,"](#) shows you how to replace all field-replaceable units in the BNP3xr.
- [Chapter 12, "Specifications,"](#) includes information about system specifications including physical, environmental, and regulatory and compliance definitions.
- [Appendix A, "Editing the DVB NIT Table,"](#) shows you how to edit, make additions to, and delete items from the NIT table, one of the DVB tables.
- [Appendix B, "Localized Cautions and Warnings,"](#) lists all of this guide's *Caution* and *Warning* statements in French and German.
- ["Information to Users"](#) provides regulatory compliance information for the BNP3xr.
- The glossary and index can be used to quickly reference information.

Document Audience




This guide is for system administrators and operators who are responsible for installation and maintenance of the BNP3xr and for processing network broadcast. You should be familiar with general video and networking terminology, and should be familiar with basic installation of hardware.

Most importantly, you must be familiar with the basics and principles of broadcast network processing.

Document Conventions

Table 1 provides an easy way to recognize important information in the text.

Table 1. Document Conventions

When you see:	It means:
	Notes point out information that may not be part of the text but provide tips and other helpful advice.
	<p>Cautions let you know that an action may have undesirable consequences if the instructions are not followed correctly. Cautions also indicate that failure to follow guidelines could cause damage to equipment or loss of data.</p> <p>Les symboles "ATTENTION", représentés par l'icône de gauche, indiquent qu'une action peut avoir des conséquences indésirables si les instructions ne sont pas suivies correctement.</p> <p>Les symboles " ATTENTION " indiquent également que le fait de ne pas suivre les instructions peut causer des dommages à l'équipement ou résulter en une perte de données.</p> <p>Das links abgebildete Symbol Vorsicht weist darauf hin, dass ein Vorgang unerwünschte Konsequenzen haben kann, falls die Anweisungen nicht korrekt befolgt werden.</p> <p>Das Symbol Vorsicht weist außerdem darauf hin, dass Geräte beschädigt oder Daten verloren gehen können, wenn die Anweisungen nicht befolgt werden.</p>
	<p>Warnings indicate that failure to take the necessary precautions or to follow guidelines could cause harm to equipment and personnel.</p> <p>Les symboles "AVERTISSEMENT", représentés par l'icône de gauche, indiquent que le fait de ne pas prendre les précautions nécessaires ou de ne pas suivre les instructions peut endommager l'équipement ou provoquer des blessures.</p> <p>Das links abgebildete Symbol Warnung weist darauf hin, dass Geräte beschädigt oder Personen verletzt werden können, wenn die notwendigen Vorsichtsmaßnahmen nicht eingehalten oder die Anweisungen nicht befolgt werden.</p>
<p>Clicking any blue link takes you to the item to which the link refers.</p> <p>For a list of all Caution and Warning statements in French and German, refer to Appendix B, "Localized Cautions and Warnings".</p>	

Graphics Used

In some cases, the screens shown in this manual may have been slightly modified after the manual was released, or may appear slightly different on different browsers.

All efforts have been made to ensure that the latest images are used. In all cases, the functionality described is current at the time of writing.

Overview

This chapter provides an overview of the Broadcast Network Processor 3xr model.

In This Chapter:

- “Product Overview,” next.
- “Product Features” on page 5.
- “BNP3xr Applications” on page 6.
- “BNP Deployment Architecture” on page 9.
- “Redundancy” on page 12.

Product Overview

RGB’s Broadcast Network Processor 3xr is a 2RU (two rack unit) device that provides:

- Support of both standard definition (SD) and high definition (HD) program services in either MPEG-2 or H.264 encoding; the BNP simultaneously grooms and inserts digital ads.
- High density video transrating (rate shaping), statistical multiplexing, grooming and digital program insertion (DPI); transrates video streams with impressively high video quality.
- Multiple levels of redundancy support including service level and 1:1 chassis level redundancy.
- Hot-swappable redundant fan modules and power supplies.
- New Gigabit Processor-3 (GBP3) and Processor-3 (PROC3) hardware modules.
- Up to 8 Gigabit Ethernet (GigE) interfaces for video input or output, as well as up to 18 asynchronous serial interface (ASI) I/O ports in a single rack unit device.
- Incorporation of DVB Conditional Access (CA) common scrambling algorithm, to encrypt programs processed by the BNP3xr.

Product Features

In addition to being software-upgradeable, scalable, and highly reliable, the BNP3xr has the following features:

- Based on RGB's flexible Video Intelligence Architecture™ (VIA).
- 8 GigE interfaces standard and up to 18 optional ASI ports.
- Management via two 10/100BaseT Ethernet ports
- Able to process and encrypt MPEG-2 and H.264 program streams over any of its Gigabit Ethernet or ASI inputs, and route them to any of these interfaces.
- Performs seamless digital ad insertion and program substitution.

- Fully compliant with the SCTE 30 and SCTE 35 standards.
- Fully interoperable ad insertion with SeaChange, Arris, and other industry standard ad servers.
- EBIF support.
- Incorporates DVB Conditional Access common scrambling algorithm (CSA) and is compliant with DVB CSA and DVB SimulCrypt protocols.
- Supports multiple levels of redundancy at the chassis, service (program) and Ethernet port level.
- Supports SCTE 18 Digital Emergency Alert Messaging (EAS), which is used to integrate the BNP with EAS management systems to control the playout of message crawls and audio during an emergency alert event.
- Supports operator-generated text and graphic messages from the BNP GUI based on digital overlay technology.
- Graphic overlays can be inserted anywhere on a program (MPEG-2) using the BNP GUI to import standard graphic files (PNG).
- Supports scheduling for Logo Overlay and Operator Messaging up to one month in advance.
- Interface to Event Information Scheduler (EIS), Entitlement Control Message Generator (ECMG) and Entitlement Management Message Generator (EMMG).
- Dedicated 10/100 BaseT IP management interface for DVB CA encryption.
- Supports H.264 grooming and multiplexing in a MPEG-2 TS format.
- Supports “FAT” ASI transport services, multiple program groups over a single TS / ASI interface.
- Supports program substitution of a primary network source with a secondary source based on SCTE 30 control.
- Supports SCTE 21 to SCTE 20 closed caption conversion.
- A graphical user interface for easy configuration and management.
- ATSC and DVB content support.
- International Time Zones.
- Language-specific GUI support.
- RADIUS/TACACS authentication support.
- Bandwidth-based DVB-CA licensing support.

BNP3xr Applications

The BNP3xr delivers the industry’s highest density digital video processing solution for a variety of applications including:

- Switched digital broadcast grooming, transrating, and statistical multiplexing.
- DPI-based ad insertion.
- Enhanced TV.
- Digital Alert Messaging (including digital EAS, Advanced Messaging, and Logo Overlay applications).
- Advanced Logo Overlay and Operator Messaging scheduling.
- DVB-CA program encryption.

Grooming, Transrating and Multiplexing

Based on RGB's Video Intelligence Architecture™ (VIA), the BNP's ability to transrate program streams with the highest quality is unsurpassed in the industry. The BNP seamlessly grooms multi-program transport streams (MPTS / MUX) and single-program transport streams (SPTS) on both input and output ports. It also offers multiple Quality of Service (QoS) priority levels on any MPEG-2 program stream enabling selection of the desired level of transrating.

DPI-Based Ad Splicing

Additionally, the BNP can concurrently groom and seamlessly splice both SD and HD program streams encoded in either MPEG-2 or H.264 formats. This grooming and splicing capability eliminates the need to dedicate multiple devices for different functions. The simplified installation, wiring and configuration reduces system deployment time. The BNP is fully compliant with SCTE 30 and SCTE 35 standards and is interoperable with the leading digital program insertion (DPI) ad servers. This flexible product can also perform SCTE 30 to SCTE 35 conversion to support digital ad insertion at the hub. The BNP is an ideal solution for both centrally located DPI systems at the headend facility, distributed DPI systems, and zoned and targeted ad insertion.

A BNP deployed in a cable digital broadcast video grooming and ad insertion environment is shown in Figure 2.




Figure 2. Regional Ad Zone Insertion Illustration

Messaging System

Digital EAS and Operator / Advanced Messaging

Leveraging its existing high-density video processing technology, the BNP's digital **Messaging System** capability allows operators to program both digital SCTE 18 Emergency Alert System (EAS) alerts and operator-generated messages. The Advanced Messaging option allows importing graphics and text files into the operator crawl message. EAS and Operator / Advanced Messaging alerts are delivered universally throughout the network, overcoming existing challenges that cable operators face in supporting analog and digital subscribers with an increasing range of decoding technologies.

The BNP's Messaging System support can be applied selectively to any MPEG-2 program being processed. EAS and operator-generated messages are digitally rendered and overlaid directly onto a program, delivered directly to any digital subscriber set-top box or to analog decoders, and presented as an overlay alert crawl to viewers. The BNP also supports operator-configurable audio override or audio stream insertion to complement the text crawl message generated by industry-leading EAS management vendors for a completely customizable deployment.

A BNP in an SCTE 18 digital EAS application is shown below in [Figure 3](#) below.




Figure 3. BNP in SCTE 18 Digital EAS application

Graphic Overlay Insertion

In addition to EAS and operator messaging, the BNP Messaging System Logo Overlay option supports inserting graphic overlays into any MPEG-2 program being processed. Graphic overlays are based on importing static graphic Portable Network Graphics (PNG) files. Importing text files is also supported, meaning that customers can create a library of graphic and text files to routinely use (see workflow example below). Users can preview the imported PNG files before starting the overlay insertion.

The location of the insertion is user configurable with positioning anywhere on the display screen defined by (x,y) screen coordinates based on pixels relating to program resolution (e.g., SD and HD). Logo overlay files can be created with PNG alpha channels to control transparency effects supported by the BNP during the insertion of the overlay. Additionally, background transparency support is available for non-ascii text overlays in order to support foreign markets.

DVB Conditional Access (DVB-CA) Encryption

The BNP3xr supports the DVB-CA common scrambling algorithm (CSA) for encryption of MPEG-2 and H.264 programs. The embedded SimulCrypt Engine is a low cost, high density, scalable encryption and management control implementation that is fully DVB-CA compliant.

The DVB-CA encryption feature includes the following functionalities:

- SimulCrypt Synchronization (SCS).
- Control Word Generation (CWG).
- Common Scrambling Algorithm (CSA).
- ECM / EMM insertion.
- CA-related PSI / SI generation and insertion.
- SimulCrypt EIS Lite GUI configuration and management.

RGB's SimulCrypt engine interfaces with the following external devices:

- Event Information Scheduler (EIS).
- Entitlement Control Message Generator (ECMG).
- Entitlement Management Message Generator (EMMG).

Figure 4 shows the BNP3xr in a DVB-CA network.




Figure 4. BNP3xr in a DVB-CA network

BNP Deployment Architecture

The BNP's modular and programmable platform is designed to provide operators with full processing scalability to meet their specific processing requirements today and in the future. The program density of the BNP is software-configurable and upgradeable, allowing operators to start at lower densities and upgrade to the full hardware capacity through software licenses as their stream densities and network needs grow.

This scalability reduces capital costs and allows operators to allocate budgets accordingly. By paying for processing on an as needed basis, operators can wisely plan budgets based on today's requirements and avoid over-allocation to meet future needs. The programmable and upgradeable architecture of the BNP, as well as its high processing power, eliminates hardware changes and will simplify and expedite future deployments of new video processing applications.

The BNP supports both ASI and Gigabit Ethernet interfaces, allowing operators who have deployed Gigabit Ethernet networks to profit from the increased cost-efficiency offered with this transport, while still providing support for operators with legacy ASI networks. This flexibility enables operators with ASI networks to continue with their existing infrastructures while providing an upgrade path for a future transition to an IP-based network.

The BNP has eight Gigabit Ethernet interfaces and is scalable to support up to 18 ASI interfaces using up to three ASI modules. The Gigabit Ethernet interfaces are part of the BNP's base configuration and

no additional hardware or licensing is required to utilize these ports. Providing added flexibility, each ASI interface is software configurable as input or output via an easy-to-use graphical user interface.




Figure 5. Example of BNP Grooming of GigE or ASI Input Over GigE Transport Network

The BNP3xr deployed for bulk rate capping in a Switched Digital Video (SDV) architecture is shown in Figure 6.




Figure 6. Example of SDV Architecture over GigE Transport Network

Figure 7 shows how the BNP3xr fits within the network for a centralized system architecture using ASI interfaces. GigE interfaces could also be used for both input and output in a co-located headend application.




Figure 7. Example of Co-Located ASI Architecture

Either ASI or GigE interfaces are used for MPEG input or output. Because of the distance, GigE interfaces are typically used for transport between the headend and the hub/node.



Note: *This unit is intended for local (intra-building) connections only and is not designed or evaluated for direct connections to the public telecommunications/cable distribution system. Cable and Ethernet connections should be made in accordance with the National Electrical Code (NEC).*

For example, make sure that at least one of the following conditions are met¹:

- *Cable runs are located in the same building as this unit;*
- *Any copper cables that run through air between buildings are less than 42m (140ft);*
- *Cable runs between buildings are in underground conduit, where a continuous metallic cable shield or a continuous metallic conduit containing the cable is bonded to each building grounding electrode system.*

1. These options are from the US National Electrical Code, Sections 800.10, 800.12, 800.13, 800.31, 800.32, 800.33, and 800.40.

Redundancy

Since a single BNP may deliver advanced video services to hundreds or even tens of thousands of subscribers in a video network, it is critical that the BNP provide a high availability of services. To achieve such reliability, the BNP supports a multi-level redundancy feature to ensure service availability and reduce system downtime. With proper configuration, the BNP can provide full chassis level redundancy. On the hardware level, a BNP3xr provides fan, power, and chassis redundancy; on the software level, the BNP3xr Gigabit Ethernet port redundancy and a configurable program service redundancy feature.

There are three distinct, user-configurable redundancy options supported by a BNP. These are:

- Program Redundancy
- Port Redundancy
- 1:1 Chassis Redundancy

The first two redundancies—Program and Port—operate within a single BNP chassis. The third—1:1 Chassis Redundancy—makes use of two BNP chassis. The redundancy for hot-swappable fan trays and power supply modules happens automatically.

Program Redundancy

The BNP supports program redundancy, sometimes referred to as service-level redundancy. For this type of redundancy, when the primary program is gone, the BNP automatically switches to a redundant or backup program.

In a program redundancy configuration, a switch to backup occurs when:

- Missing MPTS/SPTS streams are identified by checking the PAT.
- Missing program streams are identified by checking the PMT.
- A missing video stream is detected.

You can assign a backup program for every program, and any program can be assigned to backup a running primary program. The backup program can be another program on the same GigE port or it can be on a different GigE port in the same chassis.

Program level redundancy is supported such that when there is a groomed program missing, a designated input program can function as a “standby program” and will take over for the missing program. The detection of a PAT / PMT missing for over 2 seconds is used as the threshold for the detection of the missing input program.

For information about **Program Redundancy** configuration, see “[Program Redundancy](#)” on page 175.

Gigabit Ethernet Port Output Mirroring

The BNP supports Gigabit Ethernet port output mirroring within the same chassis. The mirrored port serves as a standby port in case the primary port fails. The mirroring port must have a unique IP address configured. The BNP delivers identical streams to both the primary port and the mirrored port with the same destination IP address and port number, but a different source IP address.

The multiplexed output on one GigE are delivered to the mirrored GigE port simultaneously as a fully operational, redundant output GigE port. Regardless of mirroring, all active GigE ports must have unique IP addresses assigned.

To set GigE port-level redundancy, see “GigE Port Configuration” on page 53.

1:1 Chassis-level Redundancy

When the ports and global settings are configured to do so, the BNP provides 1:1 redundancy. The BNP supports hot-standby 1:1 chassis redundancy through heartbeat and virtual IP failover mechanism.

Heartbeats provide the ability to synchronize failover to a secondary BNP. A heartbeat daemon on the primary unit will send out unicast heartbeat messages on the management interface every 250 milliseconds. The heartbeat daemon running on the standby BNP listens to the heartbeats coming from the primary BNP. If the standby BNP does not hear the primary BNP's, it initiates a failover and takes ownership. The heartbeat daemon running on the standby BNP checks for heartbeats coming from the primary BNP over both the normal Ethernet 10/100BaseT management connection and optionally the eighth Gigabit Ethernet port (GigE 8) connection (when used as a backup to the Ethernet 10/100BaseT management port).

The Backup LED on the front of the chassis indicates the redundancy role of a chassis: green indicates the active chassis, and orange indicates a standby chassis.

The standby chassis takes over if the primary (active) chassis fails, if there is a system or module overheat, failed fan, failed power supply, or missing heartbeat from the primary unit. The formerly standby (now the active) chassis now becomes configurable through the BNP *Element Manager*.

Virtual IP addressing is used to support the BNP 1:1 chassis redundancy feature. If the active chassis fails, the standby assumes the virtual IP address. Network devices communicate with the virtual IP addresses, not to the physical IP addresses. If the active chassis' input/output changes, the new setting will be synchronized to the standby chassis automatically.

GigE 8 can be configured to send heartbeat messages in the initial setting. If the network Ethernet 10/100 management connection is unplugged, the active chassis remains active. If the input or output GigE link is down, the active chassis shows a hardware fault and becomes the standby.

The standby chassis does not have any separate licenses. The license usage on the active and standby chassis is always synchronized; if the standby chassis becomes the active chassis, it assumes the licenses of the active chassis.

Figure 8 illustrates a typical configuration scenario of the BNP hot-standby 1:1 chassis redundancy feature.




Figure 8. 1:1 Chassis Redundancy using Heartbeat and Virtual IP Failover Mechanism

In this example, the primary BNP has a management IP address of 192.168.21.1 and the secondary BNP has an address of 192.168.21.2. A third IP address in the same subnet 192.168.21.200 is configured as a virtual IP address. The video server and management workstation will use this virtual IP address to communicate to the active BNP unit. During the normal course of operation, the primary BNP assumes the virtual IP address and acts as the active unit. When a failover event happens, the secondary BNP will take ownership of the virtual IP address and assume the active role. It achieves this by sending an ARP request to associate the secondary ports' MAC addresses with the virtual IP addresses. For information about 1:1 chassis redundancy configuration, see “1:1 Redundancy Best Practices and Considerations” on page 50.

Installation

This chapter provides the information necessary to install the BNP3xr into a rack. Read this entire chapter before beginning, and perform the installation in the order described. [Chapter 4, “System Configuration”](#) describes the configuration procedure.

In This Chapter:

- “Before You Begin,” next.
- “Broadcast Network Processor Components” on page 16.
- “BNP3xr Component Layout” on page 20.
- “Rack Mounting the BNP3xr” on page 22.
- “Grounding the BNP3xr” on page 24.
- “Installing SFP Modules” on page 25.
- “Connecting AC Power to the BNP3xr” on page 26.
- “Connecting DC Power to the BNP3xr” on page 27.
- “Connecting External Ports” on page 29.
- “Installing the Compact Flash Card” on page 30.

Before You Begin

Required Equipment

Be sure that you have the required items listed below before you begin the installation of the BNP3xr. You will need:

- Populated BNP3xr chassis, including:
 - 1 GBP3 module;
 - Up to four PROC3 modules;
 - Dual redundant AC or DC power supplies;
 - Dual redundant fan trays;
 - ASI modules, if ordered.
- Compact flash card.
- AC power cord, included.
- DC connector cables, if DC power supply is used.
- Front and rear rack mount brackets, included.
- Rack mount bracket screws, included.
- Two (2) M4 grounding nuts, included.

- Eight (8) rack mount screws, not included.
- Phillips and slotted screwdrivers, not included.
- 1 ring lug for grounding, included.
- Ethernet cable long enough to directly connect the BNP3xr and the management workstation, not included.

Electrostatic Precautions



Warning: Whenever computer components are handled (especially during installation), the equipment can be damaged by the buildup of static electricity. Take precautions before touching any internal components or boards by wearing an ESD wrist strap or working on an antistatic mat. Always hold system modules by the edges and avoid touching any electronic circuitry on the cards.

Broadcast Network Processor Components

This section describes the physical characteristics of the BNP3xr. Before installing, configuring, or replacing any component of the BNP3xr, please be sure that you understand the chassis and its components.

Front Panel

Figure 9 shows the front view of the BNP3xr with the bezel in place. When the front bezel is removed, the RS-232 serial port is visible, as shown in Figure 10.




Figure 9. Front panel (with bezel)



Note: The 10 GigE (XFP) and DTI ports are currently not used.

Each BNP3xr has eight GigE ports. These ports can be used for input and output (full-duplex) of video over IP data streams. The ports, LEDs, and compact flash card are located on the Gigabit Ethernet Processor-3 (GBP-3) module on the front within the chassis enclosure.

For instructions on removing and replacing the GBP3 module, see [“Replacing a Gigabit Ethernet Processor \(GBP3\) Module”](#) on page 289.

The RS-232 serial port, shown in [Figure 10](#), is used only by field service personnel. Under normal circumstances you will not need to access this port.




Figure 10. Front panel (without bezel)

LED Indicators

The primary Light Emitting Diodes (LEDs) visible on the front of the BNP3xr chassis are shown in [Figure 11](#). These LEDs indicate the general health of the BNP3xr.




Figure 11. LEDs

Table 2 describes the patterns used by the LED indicators.

Table 2. LED indicators

LED	Color	Indication
PSU 1 (left, power input)	Solid Green	Power to input of Power Supply 1 is OK.
PSU 1 (left, power input)	Off	Power range to input of Power Supply 1 is incorrect or power not present.
PSU 1 (right, power output)	Solid Green	Power from output of Power Supply 1 is OK.
PSU 1 (right, power output)	Amber	Power range from output of Power Supply 1 is incorrect or power not present.
PSU2 (left, power input)	Solid Green	Power to input of Power Supply 2 is OK.
PSU2 (left, power output)	Off	Power range to input of Power Supply 2 is incorrect or power not present.
PSU2 (right, power output)	Solid Green	Power from output of Power Supply 2 is OK.
PSU2 (right, power output)	Amber	Power range from output of Power Supply 2 is incorrect or not present.
CFG/PWR	Off	No power to chassis
	Solid Green	Power is OK
	Solid Red	Chassis is powering up and configuration load is in progress
Fault	Solid Green	System main process is in wrong state
	Blinking Green	System status is OK
	Blinking Red/Orange	Hardware fault or alarm
Backup	Solid Green	Active or primary chassis
	Solid Red/Orange	Standby chassis
Compact flash ^a	Blinking Green	FPGA configuration load in progress
	Solid Green	Compact flash card is OK
	Blinking Red	Compact flash card not installed
	Solid Red	Compact flash card error is present
GigE 1-8	Solid Green	SFP installed
10/100-0	Solid Green	Autonegotiated link status
	Blinking Yellow	Activity
10/100-1	Solid Green	Autonegotiated link status
	Blinking Yellow	Activity
AC/DC Power On Indicator (Rear Panel Figure 13)	Solid Green	AC/DC Power is on
	Off	No input AC/DC Power
On-Board DC Power Status (Figure 14)	Solid Green	On-board DC power OK
	Solid Yellow	On-board DC power fault

a. The compact flash card is necessary for BNP functionality.

Port Mapping

Figure 12 shows the SFP port location mapping scheme. These port numbers correspond with the port LEDs described in “LED Indicators,” above.




Figure 12. Port mapping and LED indicators

Rear Panel

Figure 13 shows the rear view of the BNP3xr with two network processor (PROC3) and two ASI modules installed. The BNP3xr can be configured with different combinations of modules, depending on the result you desire.




Figure 13. Rear panel

Figure 14 shows the DC power supplies:




Figure 14. DC Power Supply

Configuration Options for PROC3 Combinations

There are a maximum of four modules in each BNP3xr chassis. At least one card must be a processor module. Up to three modules can be ASI.

The right side of the chassis (rear view) holds the power supplies, including the power connectors. The redundant power supplies and fans are hot-swappable. For details about replacing the modules and power supplies, see [Chapter 11, “Field-replaceable Units.”](#)

BNP3xr Component Layout

The BNP3xr consists of four main sections: a network interface module—called the Gigabit Ethernet Processor (GBP3) module, two to four network processing modules or Asynchronous Serial

Interfaces—called PROC3 or ASI modules, up to two redundant power supplies, and dual redundant fan tray modules.




Figure 15. BNP3xr chassis, components visible

The GBP3 module is located underneath the fan trays; its design is shown below in [Figure 16](#)




Figure 16. Gigabit Processor - 3 Module

Rack Mounting the BNP3xr



Caution! Please install the BNP3xr so as to be easily accessible and as close to a power socket outlet as possible.

The BNP3xr requires 2RU of space and is mounted into a standard 19-inch rack using rack mount brackets for both the front and rear of the system.

When choosing the location for the BNP within a rack, make sure that the BNP3xr will be placed within the rack evenly, and that the installation will not cause uneven mechanical loading and weight distribution.

Do not mount the BNP3xr into any rack that obstructs clean air flow either in the front or the rear. Generally, an aisle of at least 15 inches is the minimum distance to ensure proper air flow.



Caution! Be sure that the BNP3xr is mounted in a location that meets the environmental conditions shown in [Table 3](#).

Table 3. Environmental Requirements

Condition	Limits
Storage Temperature	-40° to 70° C (-40° to 158° F)
Operating Temperature	0° to 40° C (32° to 104° F)
Humidity	5% to 95% (non-condensing)

To install the BNP3xr into a rack:

1. Using the provided screws, attach the front rack mount bracket to one side of the chassis as shown in [Figure 17](#).




Figure 17. Front brackets attached

2. Repeat [Step 1](#) on the other side of the chassis.

3. Install the chassis rear rack shelf to the rear mounting rails of the rack using two screws on each side as shown in [Figure 18](#).




Figure 18. Rack shelf

4. Install the BNP3xr chassis in the rack.

The rear edge of the chassis will rest on the rear rack shelf. Secure the front of the chassis to the rack using two screws on each side, as shown in [Figure 19](#).




Figure 19. Mounted BNP3xr

Grounding the BNP3xr



Warning: *The BNP3xr must be properly grounded to ensure safe operation. Before you connect power or turn on the BNP3xr, ground the chassis. This section provides one method of grounding. There may be others: check your network configuration for details.*



Warning: *If you are installing dual redundant power supplies, only ground one of the two power supplies.*

To connect the chassis ground:

1. Using a length of wire, terminate one end with a ring lug.

For use with a DC power supply, the grounding wire must be a minimum of 12 AWG.

- Using the provided M4 nut, install the ring lug on the grounding terminal.

The grounding terminal is at the rear of the BNP3xr chassis, located at the lower left of the power supply, just beneath the power supply handle.




Figure 20. Grounding terminal, rear of chassis: AC power supply top, DC power supply bottom

- Using wire strippers, strip off 3/8 inch of insulation from the other end of the wire.
- Attach the stripped wire into a grounding hole on the equipment rack.

Installing SFP Modules

For optical output, Small Form Factor 1Gbps (SFP) transceivers comply with the current SFP Multi-Source Agreement (MSA) Specification.

- GigE interfaces that meet 1000 Base SX specifications support 850 nm wavelengths for distances up to 550 meters.
- GigE interfaces that meet 1000 Base LX specifications support 1310 nm and 1550 nm wavelengths for distances up to 70 kilometers.

SFPs approved for use with the BNP3xr are based on the Multi-Source Agreement (MSA) and listed in Table 4:

Table 4. Supported SFPs

Manufacturer	Part Number	Description
Finisar	FTLF1519P1BCL	SFP 1550nm GigE optical module
Finisar	FCMJ-8521-3	1000BaseT Copper SFP Transceiver
Fiberdyne	FGE-SFP-T	1000BaseT Copper SFP Transceiver
Avago	ABCU-5710RZ	SFP 1550nm GigE optical module



Note: For updates on the latest SFPs and XFPs approved for use with RGB's products, [log in to RGB's Customer Portal and search for the following term:](#)

SFP
-OR-
XFP

To install an SFP, follow the manufacturer's instructions. General guidelines to SFP installation include:

1. Consider your network and cabling requirements and verify that the SFP you are installing is an approved model as described in [Table 4](#).
2. Insert the SFP into the port.
SFPs are keyed so they can only be installed one way.
3. Slide the SFP into the port until it clicks into place and the LED is activated.

Connecting AC Power to the BNP3xr

Once installed in a rack, connect power to the chassis.

Before you connect power to the chassis, make sure that the circuit, wiring, and connections that you are using to supply the power will not become overloaded by the BNP3xr(s). For power consumption details, see “Specifications” on page 293.



Caution! *The power cord is the disconnect device for the BNP3xr. There is no power switch: once connected to the power outlet, the unit powers up immediately.*

Connect all ports before connecting power.

To connect AC power to a BNP3xr:

1. Locate the AC power cables included with the BNP3xr chassis.
2. Plug one end of the power cables into the BNP3xr power connectors.
3. The AC power connectors are located on the power supplies.




Figure 21. Connect AC power

4. Plug the other end of the power cables into the input power sources.

The unit should now have power. Check the LEDs to verify that power has been applied. See “LED Indicators” on page 17 for details.

When the BNP3xr is installed and powered on, verify that the **Cfg/Pwr** LED and the PSU1 and PSU2 LEDs are solid green. See “LED Indicators” on page 17.

Disconnecting AC Power from the BNP

To remove AC power from the BNP, disconnect the power cables from the power source, that is, pull the plug from the power connectors. This is the only way to ensure that the unit is not receiving power.

Connecting DC Power to the BNP3xr

Before Connecting Power



Caution! *Only trained personnel should install or replace this equipment.*

- Remove all jewelry, including rings, necklaces, and watches. Metal objects will heat up when connected to power and ground, and can cause serious injury or weld the metal object to the terminals.
- The protective earth connection should be connected before proceeding with the power connection.
- The power cables should be attached to the breaker.
- Confirm that the DC power sources are powered off during installation.
- For a centralized DC power connection, the unit must be installed in a restricted access location in accordance with Articles 110-16, 110-17, and 110-18 of the National Electrical Code, ANSI / NFPA 70.
- Damage may occur if the power is connected improperly.

Connecting Power



Caution! *Make sure that the safety screws are in the locked position (turned counterclockwise) after the power supplies are installed, but before connecting power (Figure 22). Note that the locked position may be different than that of similar units. This ensures that the power supplies cannot be accidentally disconnected, causing possible damage.*

Once installed in a rack, connect power to the chassis.

Before you connect power to the chassis, make sure that the circuit, wiring, and connections that you are using to supply the power will not become overloaded by the BNP3xr(s). See “[Specifications](#)” on [page 293](#) for power consumption details.



Caution! *These are +48V DC power supplies, **not** -48V. Please connect accordingly.*

The two inputs to each of the DC power supplies are +48V inputs. If you wish to have redundant inputs, connect the inputs to the DC power supply from two different 48V sources. When both 48V inputs of each power supply are sourced, each power supply will load share across the inputs, each of the inputs drawing half the total power. When one 48V input source fails, the other 48V input will draw the full power. If you choose not to have redundant inputs, connect only one of the two inputs to one of the DC power supplies and leave the other disconnected.

Each DC power supply is configured so that the black (top) cable connects to a -48VDC input and the red (bottom) cable connects to positive ground. Before connecting any cables, measure the output to make sure that you are connecting a -48VDC input to the black cable of the power supply.

Connect all ports before connecting power.

To connect DC power to a BNP3xr:

1. Cut the provided DC connector cables to the correct length to reach the BNP3xr from the power source.
2. The DC power connectors are permanently attached to the power supplies. Attach the connector cables from the power source to the BNP3xr power connectors.

Note: Only one of the two redundant DC power supplies is shown below. The same process described in this section applies to the second DC power supply.




Figure 22. Connect DC power

3. Attach the other end of the power connector cables into the input power source.
The power cables should be attached to an external UL Listed 20 amp circuit breaker.




Figure 23. Connect the power cables

4. To power the unit on, toggle the external circuit breaker to the ON position. There are no circuit breakers on the BNP3xr.

The unit should now have power. Check the LEDs to verify that power is connected. See “[LED Indicators](#)” on page 17 for details.

When the BNP3xr is installed and powered on, verify that the **Cfg/Pwr** LED is solid green. See “[LED Indicators](#)” on page 17.

Disconnecting DC Power from the BNP3xr

To remove DC power from the BNP3xr, toggle the circuit breaker to the OFF position, or remove the fuse from the fuse panel. This is the only way to ensure that the unit is not receiving power.

Connecting External Ports

The BNP3xr chassis has four discrete types of ports. When connecting ports, be sure to use the correct cabling. This section describes the port types and basic cabling, but the actual cabling requirements will depend on your specific network configuration and needs.

Fast Ethernet Management Port 10/100-0

The 10/100BaseT (10/100-0) Ethernet port is used to communicate unencrypted with an external console for SNMP configuration control, maintenance diagnostics, status monitoring, fault notification, and redundancy switching. The external console can be a workstation on the IP network.

Fast Ethernet Management Port 10/100-1

The 10/100BaseT (10/100-1) Ethernet port is used to communicate via CA encryption with an external console for SNMP configuration control, maintenance diagnostics, status monitoring, fault notification, and redundancy switching. The external console can be a workstation on the IP network.

GigE Port

The Ethernet port must be fitted with small-form-factor pluggables (SFPs). See [Table 4](#) for a list of tested and approved SFPs that can be used with the BNP3xr.

ASI Port

The number of ASI ports in your BNP3xr chassis depends on the number of ASI cards that are installed. Up to three ASI cards can be installed, each with six ports.

Installing the Compact Flash Card

The BNP3xr uses a compact flash card to load software and save configuration information. You cannot use your BNP3xr without it.

If the compact flash card was not shipped pre-installed with your BNP, you must install it. Remove the flash card from the shipping container and install it into the compact flash slot located on the front of the BNP chassis.

If your compact flash card fails, contact technical support for details about flash repair or replacement. See [page 280](#) for details on contacting technical support.



Caution! *Your license is attached to the compact flash (CF); do not discard it. Even if a CF card fails, keep the device and contact RGB technical support for instructions on repair or obtaining a working replacement.*

System Configuration

The BNP is configurable through a Java-based graphical user interface (GUI) available through a standard Web browser, or through SNMP using standard network management applications. The easy-to-use interface offers a variety of features that simplify the set-up and operation of the BNP, including program and transport level drag and drop grooming; simultaneous bit rate analysis of input and output transport streams and programs; alarms and logs window; scheduled dynamic grooming with start/end time and calendar entry; redundancy configuration; and full configurability of ASI and Gigabit Ethernet ports.

This chapter describes how to configure the BNP3xr using the *BNP Element Manager*. You can also use the *BNP Element Manager* to define and manage network processing as described in [Chapter 5](#), “Grooming and PSIP,” and to monitor the BNP system as described in [Chapter 9](#), “Monitoring the BNP.”

In This Chapter:

- “Obtaining Java Runtime Environment,” next.
- “Launching the BNP Element Manager” on page 32.
- “Using the Element Manager” on page 34.
- “BNP Element Manager Overview” on page 34.
- “Chassis View” on page 36.
- “Setting the Time Offset Table (TOT)” on page 38.
- “Global Chassis Configuration” on page 41.
- “Ethernet Control Port Configuration” on page 50.
- “GigE Port Configuration” on page 53.
- “Configuring ASI Ports” on page 55.
- “Modifying a Port Name” on page 56.
- “User Authentication ” on page 57
- “Messaging System Configuration” on page 69.
- “SNMP Configuration” on page 103.
- “Upgrading Software” on page 107.
- “Clearing the Web Start Cache” on page 110.
- “The License Manager” on page 111.
- “Regrooming” on page 114.
- “Stopping All Services” on page 115.
- “Rebooting the System” on page 116.
- “Checking for the BNP Element Manager Version” on page 117.

Obtaining Java Runtime Environment

The BNP *Element Manager* requires that the PC on which it is running have Java™ Runtime Environment (JRE) v1.6 or higher. If your PC does not have the correct JRE installed, it is available free from the RGB Customer Portal (see below).

Obtaining JRE from the RGB Customer Portal

To obtain installation instructions and the latest version of JRE that is compatible with the BNP *Element Manager*, [log in to RGB's Customer Portal](#) and [search](#) for the following term:

Download Java Runtime Environment

Launching the BNP *Element Manager*

You do not need to install the BNP *Element Manager* software. It is installed on the BNP at the factory, and you connect via the IP address of the BNP.

To launch the BNP *Element Manager*:

1. Open a browser session on the management workstation or on any computer that has access to the BNP.

The IP address of the workstation being used to access the BNP must be changed to an address on the same subnet as the BNP chassis.

2. Enter the IP address of the BNP into the browser's address field. The default IP address is 10.1.1.1.

For easier access, bookmark the URL or set it as the home page.



Figure 24. Enter the IP address of the BNP to access

3. Click the **Launch BNP Element Manager** link.



Figure 25. Launch BNP *Element Manager* window

Once launched, the window displays the **Login Window**. Log in as described in “Logging In” on page 34.




Figure 26. BNP *Element Manager* login window (Local login, left; AAA server login, right)

Using the *Element Manager*

Use the *BNP Element Manager* to configure your system, perform grooming and ad insertion, monitor system status, and upgrade software as needed.

Logging In

1. Once you have launched the *BNP Element Manager* and clicked the login link at the top of the page, the login screen appears.
2. The BNP's IP address automatically populates the **IP Address or Host Name** field.
3. Select your user account from the **User** drop-down list, or *type* the user name if using an AAA server for authentication.
4. Enter the corresponding password in the **Password** field.



Note: Passwords are case sensitive. To change the password, see “[User Authentication](#)” on [page 57](#). To change an AAA server password, refer to the relevant documentation for the AAA server being used.

Three levels of user, each with specific access to the system, have permission to use the *Element Manager*. If you log in as a user with limited privileges, any option not available to you is grayed out and cannot be selected. **User** levels include:

Table 5. User levels

User name	Default Password	Permission
User	User	Logging in as <i>User</i> provides read-only access. You cannot make any changes to the configuration.
Operator	Operator	Logging in as <i>Operator</i> provides both read and write access. Operators can make changes to the configuration. This is the normal login level.
Administrator	Admin	The <i>Administrator</i> level is typically only used by Field Application Engineers and Technical Support personnel, however access can be granted to key headend personnel. The Admin has the highest rights and can change the password.

5. Click **Log in**.

By default, the *BNP Element Manager* now opens to display the **Grooming -> Mapping** screen.

BNP *Element Manager* Overview

Element Manager Title Bar



Note: Many of the screens across the *BNP Element Manager* platform—whether you are using *BNPxr*, *BNP2xr*, or *BNP3xr*—will appear exactly the same. For this reason, some figures in this manual will not include the title bar. The *BNP3xr* model title bar is shown below.

For the BNP3xr model, the title bar appears as follows:




Figure 27. BNP3xr title bar

Element Manager Main Menu and Tabs

Once installed, the BNP *Element Manager* provides an easy way to configure your BNP system. The BNP *Element Manager* contains the following menus and tabs, which are used to access specific screens:

Table 6. *Element Manager* Menus

Menu	Use
File	Exits the BNP <i>Element Manager</i> .
View	Refreshes the currently active window and allows you to choose whether the program and grooming information will be displayed.
Maintenance	Upgrade software, enter licensing options, change SNMP strings, set up and edit Network Information Tables, Time Offset Tables, reboot, system shutdown, remove chassis redundancy, and regroom.
DVB-CA	Opens the global configuration parameters for setting up a DVB-CA system.
Help	Display online help and application information.

Some primary tabs have subtabs to further refine the view, others use selections that increase the granularity of the information shown and provide access to further activities. The primary tabs include:

Table 7. *Element Manager* Primary Tabs

Tab	Use
Grooming	Create and map programming, or monitor bit rates in real time.
Alarms & Events	Specified events and alarms can be tracked on this tab. Configure the alarms and events to display only the items you are interested in.
Configuration	BNP configuration is performed through the subtabs of the Configuration tab. These tabs include Global, Ethernet Control Ports, GigE Ports, ASI Ports, User Authentication, Messaging System, and SNMP Trap.
Chassis	The Chassis tab has no subtabs, but provides a quick overview of the status of the BNP. Clicking a port opens port information and configuration dialogs.
DVB-CA	Configuration of the DVB Conditional Access encryption features is performed in the DVB-CA tab. Subtabs include: CA System and SCG.

Status Information

The lowest portion of the BNP *Element Manager* window provides status information. The information displayed depends on the current selection and status of the BNP.

The left section displays the IP address of the BNP to which the BNP *Element Manager* is connected. The right portion of the status bar shows the most recent, highest priority alarm triggered, if one exists. Alarms are color-coded for fast identification.




Figure 28. Typical BNP *Element Manager* status bar

Chassis View

The BNP *Element Manager* automatically detects the chassis hardware and provides a graphical display of the product components and their state, as shown in Figure 29 and Figure 30. The exact display that appears will depend upon whether the unit is AC- or DC-powered.

By default, the first port is selected. All active ports appear green on the screen. For easy identification, whenever another port is selected, that port's icon is shown.




Figure 29. Chassis tab - AC view




Figure 30. Chassis tab - DC view

The information on these screens cannot be changed and is displayed for informational purposes only. When you move the cursor over a port on the screen, the cursor changes to a hand, indicating a link. Depending on which port is selected, you can see the information about the 10/100 BaseT port (Ethernet control), the GigE ports, or the ASI ports. If the selected port is active, it appears green on the screen. In Figure 29, for example, the Ethernet Control Port is selected and active.

The information displayed in the main Chassis Information screens is shown in [Table 8](#). This information is available regardless of whether the BNP selected or is the active or standby unit. For standby units, however, some configuration options will not be available.

Table 8. Chassis information window

Field	Description
Chassis Software Version	Version of the software currently installed
Chassis Serial No	Serial number for the chassis; useful when troubleshooting or contacting technical support. The serial number is the same as the 100-BaseT port MAC address.
Chassis Up Time	Amount of time that the chassis has been continuously accessible
Inside Chassis Temperature	The internal junction temperature of the FPGA chip is displayed, enabling easy determination that the FPGA die temperature is within acceptable limits. If the value of any component inside the chassis exceeds 100°, an alarm is generated.
GBP Serial No	Displays the serial number of the Gigabit Processing card.
Power Supply Unit	Provides Status and Serial Numbers for both power supply units (PS1 and PS2). When a power supply is present and operable, status will be <i>Present</i> ; when a power supply is not present or out of range, status will be <i>Not Present</i> .
Fan Module	Provides Status information for FAN1 and FAN2. When a fan is present and operating, status will be <i>OK</i> ; when a fan is not present or inoperable, status will be <i>Failed</i> .
Graphical view of physical configuration	A graphical representation of the front and rear of the chassis configuration: click on any individual module to display its configuration.
GigE port information	Configuration and addresses of the GigE ports; click on the port on the graphical representation to view the information.
Ethernet Control ports	Configuration and addresses of the Ethernet Control Port; click either management port on the graphical representation to view the information.
ASI Port Information	Port, direction, and status; click a port on the representation to see details about the port.
PROC3 Slot Information	Clicking on the card shows: Slot (A, B, C, or D) and Card Serial No.

Setting the Time Offset Table (TOT)

The TOT conveys additional information about summer and winter time periods and gives the local time offset with respect to UTC for different countries or regions. If the TOT is locally generated, user interaction is required to define the country or region in which the receiver is operated.

The BNP supports the required DVB tables, including TOT. To set the TOT time offset:

1. From the *Element Manager*, select **Maintenance -> Setup Time Offset table(TOT)** (Figure 31).




Figure 31. Choosing TOT Time Offset

The window of Figure 32 appears.




Figure 32. TOT Time Offset Window

Table 9 explains these parameters.

Table 9. Tot Time Offset Window Parameters

Field	Description
Country Code	The three character country code.
Region ID	The region identifier, with range 0 to 60. If there is only one time zone in the country, this value is zero. Otherwise, the timezones are numbered from 1 (most easterly) up to 60, (the most westerly).
DST Offset	<p>The DST offset: (range is -2:00, -1:30, -1:00, -0:30, 0, +0:30, +1:00, +1:30, +2:00). The value is 0: when DST is not applicable; otherwise the offset to be applied to current time when DST is in effect.</p> <p>For instance, in the US, the local time offset when DST is not in effect is -8, and when DST is in effect, it is -7. So, the DST offset is +1. polarity is 1 as time is behind UTC.</p>
Start Time	Indicates when DST takes effect in the current year.
End Time	Indicates when DST ends in the current year.
Day	1st, 2nd, 3rd or last Sunday.
Month	January - December.
Hour	0-23.
Minute	0-59.

2. Enter the required information and click **OK**.

Global Chassis Configuration

To view and configure information that is global to the BNP chassis:

- 1. From the *Element Manager*, select **Configuration -> Global**.

The **Global** chassis configuration window appears.

FileViewMaintenanceDVB-CAHelp

BROADCAST NETWORK PROCESSOR

rgbNETWORKS

GroomingAlarms & EventsConfigurationChassisDVB-CA

GlobalEthernet Control PortGigE PortsASI PortsUser AuthenticationMessaging SystemSNMP Trap

System Time Source: NTPForce Sync

	IP Address	Offset (msec)	Jitter (msec)
Server 1:	192.168.18.201	-0.836	0.101
Server 2:		0.000	0.000
Server 3:		0.000	0.000
Server 4:		0.000	0.000
Server 5:		0.000	0.000

Time Zone: GMT-08 Pacific Time(US & Canada)

System Name: System Log Address:

Advanced System Parameters

☒Support SCTE 27 Subtitle (Stream Type 0x82)☐Enable SCTE-21 to SCTE-20 Conversion

☒Enable PSIP processing

☐PAL Mode☐Optimize Messaging for HD

☐Enable Transparency for Messaging System (Enabling this feature will significantly reduce BNP capacity)

Chassis Redundancy

Chassis Active Status: PrimaryRedundancy Switch

Redundant Chassis Configuration

Virtual IP Address Configuration

IP Address for 10/100: IP Address for GigE 1: IP Address for GigE 2: IP Address for GigE 3: IP Address for GigE 4:

IP Address for GigE 8 (Optional): Gateway for 10/100: Gateway for ETH 2: IP Address for GigE 5: IP Address for GigE 6: IP Address for GigE 7: IP Address for GigE 8:

Postblack

Enable Options

☐AD Server Request☐AD Undertlows

Apply Configuration

Cancel

Connected 10.32.96.138

16:14:44

Figure 33. Global chassis configuration

2. Use the fields and selection options to change the global configuration variables.

Table 10 describes the **Global Configuration** values that can be changed.

Table 10. Global Chassis Configuration Fields

Category	Field	Description/Values
System Time Source (NTP)	Force Sync	Click this button to force synchronization between the BNP and the NTP server. This action will prompt for a reboot of the BNP. See “NTP Server Force Sync” on page 45 for details.
	IP Address ^a (Servers 1-5)	Enter up to 5 IP addresses for the NTP server; the first field cannot be blank. Enter one per NTP Address field. A green circle to the left of the Server number field represents the active NTP server. The lack of a green circle would mean the specified server is not active.
	Offset (msec)	This value shows the difference in milliseconds between the reference time and the system clock.
	Jitter (msec)	This value indicates the magnitude of jitter in milliseconds between several time queries.
Time Zone		If Internal is selected, choose the time zone from the pull-down list.
System Name		You can assign a unique system name for this BNP. After you click <i>Apply Configuration</i> , this name will appear at the top of the screen.
System Log Address		Enter the IP address to communicate with a Syslog server.

Table 10. Global Chassis Configuration Fields (Continued)

Category	Field	Description/Values
Advanced System Parameters	Support SCTE 27 Subtitle (Stream Type 0x82) ^a	SCTE 27 Subtitling defines stream type 0x82 for program subtitles and subtitling methods. The default value is checked. When unchecked stream type 0x82 is not treated as a subtitle.
	Enable SCTE-21 to SCTE-20 Conversion ^b	Check this box to enable the input program conversion of SCTE 21 to both SCTE 21 and SCTE 20 closed captioning formats on the output program.
	Enable PSIP processing ^c	Check this box to enable the BNP to detect PSIP tables and pass them from the input to the output. PSIP processing is enabled by default.
	PAL Mode ^d	Check this box to optimize BNP processing of Phase Alternating Line (PAL) content. <ul style="list-style-type: none"> • This setting is recommended if most programming from the BNP uses PAL. • This setting is not recommended with progressive content.
	Optimize Messaging on HD ^e	Check this box when using a 3 to 1 ratio of HD programs per transport stream on which messaging is enabled. This feature will decrease the PROC3 card's capacity. This box is unchecked by default.
	Enable Transparency for Messaging System ^f	Check this box to enable transparency filters in the Messaging System tab. <ul style="list-style-type: none"> • This box must be checked if you wish to enable transparency for Operator Messaging, Advanced Messaging, and Logo Overlay in the <i>Configuration -> Messaging System</i> tab. • Checking this box reduces BNP capacity^g.
Chassis Redundancy	Chassis Active Status	Shows the role of the selected chassis: <i>Primary</i> or <i>Standby</i> .
	Redundancy Switch (button)	Interchanges the Primary and Standby in a redundant configuration.
Redundant Chassis Configuration	IP Address for 10/100	BNP uses the active/redundant designation for failover <ul style="list-style-type: none"> • In the <i>Element Manager</i> GUI for the Active chassis, enter the IP address of the Standby chassis. • In the <i>Element Manager</i> GUI for the Standby chassis, enter the IP address of the Active chassis.
	IP Address for GigE 8 (Optional)	Enter the IP address of the GigE port if used to pass redundancy information. <ul style="list-style-type: none"> • When this port is configured with an IP address, heartbeat messages will be exchanged on this port.

Table 10. Global Chassis Configuration Fields (Continued)

Category	Field	Description/Values
Virtual IP Address Configuration ^h	IP Address for 10/100	Enter the virtual IP address used by the system to manage redundancy for the 10/100 management port. <ul style="list-style-type: none"> This address must be the <i>same</i> on both the active and standby chassis as it is shared by both units. This address must be on the same subnet as the physical IP address. Leave blank if no redundancy system is in place
	Gateway for 10/100	Enter the IP address of the gateway (default router) that the 10/100 virtual IP should use <ul style="list-style-type: none"> This field is optional. This address must be the <i>same</i> on both the active and standby chassis as it is shared by both units.
	IP Address for ETH 2	Enter the virtual IP address used by the system to manage redundancy for the ETH 2 DVB-CA port. <ul style="list-style-type: none"> This address must be the <i>same</i> on both the active and standby chassis as it is shared by both units. This address must be on the same subnet as the physical IP address for ETH 2. Leave blank if no redundancy system is in place
	Gateway for ETH 2	Enter the IP address of the gateway (default router) that the ETH 2 DVB-CA port should use <ul style="list-style-type: none"> This field is optional. This address must be the <i>same</i> on both the active and standby chassis as it is shared by both units.
	IP Address for GigE (1-8)	For each redundant GigE port, (1 through 8) enter the IP address shared by the redundant ports. <ul style="list-style-type: none"> Each GigE port must be on a separate subnet.
Postblack Enable Options	AD Server Request	Check this to play postblack that an ad server specifies be played at the end of an ad. Left unchecked, the BNP ignores postblack requests from ad servers.
	AD Underflows	Check this to insert postblack at the end of an ad that is shorter than the duration specified by the ad server.

- It is recommended that at least one NTP server be used with the BNP. An NTP server is required for Digital Program Insertion (DPI). It is recommended that the NTP server be up and running prior to booting up and / or configuring the primary NTP server for the BNP. To force a sync with the NTP server, click the *Force Sync* button. This will prompt for a reboot of the BNP.
- Checking or unchecking the *SCTE-21 to SCTE-20 Conversion* box requires a mandatory reboot of the BNP. It is recommended that this flag be configured before any input or output transport stream configuration.
- Checking or unchecking the *PSIP Processing* box requires a mandatory reboot of the BNP. It is recommended that this flag be configured before any input or output transport stream configuration.
- Checking or unchecking the *PAL Mode* box requires a mandatory reboot of the BNP. It is recommended that this flag be configured before any input or output transport stream configuration.
- Checking or unchecking the *Optimize Messaging on HD* box requires a mandatory reboot of the BNP. It is recommended that this flag be configured before any input or output transport stream configuration.
- Checking or unchecking the *Enable Transparency for Messaging System* box requires a mandatory reboot of the BNP. It is recommended that this flag be configured before any input or output transport stream configuration.
- Please see the latest *Release Notes* for details on the impact of enabling transparency for load time and bandwidth on the BNP.
- Changing the Virtual IP Address Configuration parameters will require a reboot of the BNP.

3. Click **Apply Configuration**.

Any time changes are made to a configuration, you must click **Apply Configuration** to save and implement the changes.

4. To interchange the active and standby in a redundant configuration, click **Redundancy Switch**. If you choose to force redundancy, there will be a service interruption of approximately two seconds. See “[Forcing Redundancy](#)” on page 50.

NTP Server Force Sync

The BNP can be configured to use up to five NTP servers with which the BNP will attempt to synchronize. In the event of a significant disparity between the BNP’s time and that of the NTP server, the BNP may (by design) take a long time to synchronize with the NTP server. You can manually force a quick synchronization between the server and the BNP.

Forcing a synchronization will prompt for a reboot of the BNP, thus resulting in a service disruption on non-redundant BNP configurations. Forced NTP synchronization on non-redundant BNP configurations should be conducted during a maintenance window.

To force a synchronization of the BNP with an NTP server, proceed as follows:

1. From the **Configuration -> Global** menu, click the **Force Sync** button.

You will be asked if you wish to apply the **Force Sync**:




Figure 34. Apply Force Sync

2. Click **Yes**.

The **Password Verification** window will open.




Figure 35. Reboot Password Verification window

3. Enter the Administrator password and click **OK**.

The **Reboot** confirmation window will open.




Figure 36. Reboot confirmation

4. Click **Yes** to reboot.

Force Sync on Redundant BNP Systems

To force an NTP server sync in a 1:1 redundancy configuration, proceed as follows:

1. Log into the standby chassis using the physical IP address of the standby BNP.
2. Click on the **Configuration** -> **Global** tab.
3. Observe which server is active (a green dot will be next to the active server) and determine if the **Offset** value warrants an NTP sync (offset exceeds +/- 15ms).




Figure 37. Force sync for standby NTP server

4. Click the **Force Sync** button.

You will be asked if you wish to apply the **Force Sync** (Figure 34 on page 45).

5. Click **Yes**.

The **Password Verification** window of Figure 35 on page 45 will open.

6. Enter the Administrator password and click **OK**.

The **Reboot** confirmation window of Figure 36 on page 46 will open.

7. Click **Yes** to reboot the *standby* BNP.

8. Allow the *standby* BNP to reboot and return to its available backup status.

9. Log into the *active* BNP via its Virtual IP (VIP) address.

10. From the **Configuration** -> **Global** window, click the **Redundancy Switch** button.

The *standby* chassis now becomes the *active* chassis, and vice versa.

11. Log into the new *standby* BNP (formerly, the *active* chassis) via its physical IP address.

12. Follow steps 4 through 7 above to **Force Sync** the new *standby* BNP.

The new *standby* BNP will now reboot and return to its available backup status.

Configuring Chassis-level 1:1 Redundancy

Conditions and Restrictions

1. To setup the Virtual IP address for the GigE ports, the 10/100BaseT management port, or the 10/100BaseT DVB-CA port, you must first have valid physical IP addresses for these ports.
2. An ad or video server should only send ads or video streams to the virtual IP addresses.
3. Note that with hot-standby 1:1 chassis redundancy configured with virtual IP failover, unicast inputs can not be received by both the active BNP and the standby BNP simultaneously. This means that unicast stream failover will not be immediate and the standby unit will need to initiate new unicast sessions, which will not allow an immediate failover condition for those streams. As an alternative, two BNP units without virtual IP coordination could be configured with identical streams routed to both units running in parallel with the standby unit output muted.
4. Currently, the BNP does not support the Gigabit Ethernet input port level redundancy. The 1:1 chassis level redundancy will cover the Gigabit Ethernet input port failure case. The indication of the Gigabit Ethernet input port failure includes disconnection of the Gigabit Ethernet cable, loss of the Gigabit Ethernet link.
5. When a Gigabit Ethernet port delivers only one program and the program is missing for over 2 seconds, the 1:1 chassis failover is used, instead of standby program failover.
6. Active and Standby BNPs must use the same software version.

To Configure Redundancy:

Configure the *Standby* Chassis first:

1. Log in to the *Element Manager* of the *standby* chassis as described in “Logging In” on page 34.
2. If you have not already done so, select the **Configuration** -> **Ethernet Control Port** menu and change the IP Configuration, IP Address, Subnet Mask, and Gateway fields for Ethernet Port 1 and

Ethernet Port 2 of the standby chassis to the appropriate parameters for your network. (See “Ethernet Control Port Configuration” on page 50 for more information). If you are changing any of these parameters, the system must be rebooted, which you will be prompted to do when clicking **Apply Configuration**.

3. From the *Element Manager* of the standby chassis, select **Configuration -> Global**.
4. Enter the **IP Address for 10/100** of the *active* chassis’ Ethernet control port as described in Table 10, “Global Chassis Configuration Fields,” on page 42.
5. Under *Virtual IP Address Configuration*, enter the **IP Address for 10/100** that will be shared by both active and standby chassis as described in Table 10, “Global Chassis Configuration Fields,” on page 42.
6. Under *Virtual IP Address Configuration*, enter the **IP Address for ETH 2** that will be shared by both active and standby chassis of for the DVB-CA management port as described in Table 10, “Global Chassis Configuration Fields,” on page 42.
7. Both active and standby chassis *must* have the same virtual IP (VIP) address: one VIP for the 10/100 management port and one VIP for the DVB-CA port (ETH 2).
8. Under *Virtual IP Address Configuration*, enter the IP address in the **Gateway for 10/100** field that will be shared by both active and standby chassis as described in Table 10, “Global Chassis Configuration Fields,” on page 42.
9. If you are using a virtual gateway (optional), both active and standby chassis *must* have the same virtual gateway for the 10/100 management port.
10. Under *Virtual IP Address Configuration*, enter the IP address in the **Gateway for ETH 2** field that will be shared by both active and standby chassis as described in Table 10, “Global Chassis Configuration Fields,” on page 42.
11. If you are using a virtual gateway (optional) for **ETH 2**, both active and standby chassis *must* have the same virtual gateway for ETH 2.
12. *OPTIONAL*: If you wish to enable heartbeat messages on the standby chassis, configure the IP Address for the **GigE 8(Optional)** field as described in Table 10, “Global Chassis Configuration Fields,” on page 42.



Note: *If you configure the GigE 8(Optional) field to enable heartbeat messages and you have directly connected the GigE 8 ports (i.e., you are not using a switch or hub to connect the ports), you **must disable** Auto-negotiation for the GigE 8 port on the standby chassis as described in “GigE Port Configuration” on page 53 for proper chassis functionality.*

13. Click **Apply Configuration**.
14. Wait two minutes for the configuration to be saved. During this time, a change will occur to the BNP GUI status bar: the addition of an indicator showing *Active* and *Standby* BNP IP addresses.
15. Ensure that the standby chassis does *not* have any license keys associated with it:
 - From the main *Element Manager* window, select **Maintenance -> License Manager**.
 - Confirm there are no entries in any of the License Key fields as described in “The License Manager” on page 111.
 - If there are entries in any of these fields, please contact RGB technical support for assistance on how to remove the license keys.

16. Shutdown the standby chassis from the *Element Manager's* **Maintenance -> Shutdown** menu.

17. Turn *off* the standby chassis.

Configure the Active Chassis next:

1. Log in to *Element Manager* of the **active** chassis as described in “[Logging In](#)” on page 34.
2. From the *Element Manager* of the **active** chassis, select **Configuration -> Global**.
3. Enter the **IP Address for 10/100** of the **standby** chassis’ Ethernet control port.
4. In the *Element Manager* configuration for the **active** chassis, under *Virtual IP Address Configuration*, enter the **IP Address for 10/100** that will be shared by both active and standby chassis’.
5. Under *Virtual IP Address Configuration*, enter the **IP Address for ETH 2** that will be shared by both active and standby chassis of for the DVB-CA management port.
6. Both active and standby chassis *must* have the same virtual IP (VIP) address: one VIP for the 10/100 management port and one VIP for the DVB-CA port (ETH 2).
7. In the *Element Manager* configuration for the active chassis, under *Virtual IP Address Configuration*, enter the IP address in the **Gateway for 10/100** field that will be shared by both active and standby chassis’.
8. If you are using a virtual gateway (optional), both active and standby chassis *must* have the same virtual gateway for the 10/100 management port.
9. Under *Virtual IP Address Configuration*, enter the IP address in the **Gateway for ETH 2** field that will be shared by both active and standby chassis.
10. If you are using a virtual gateway (optional) for **ETH 2**, both active and standby chassis *must* have the same virtual gateway for **ETH 2**.
11. Do *not* configure the IP Address of the **GigE 8(Optional)** field on the **active** chassis; this must be done on the **standby** chassis.



Note: *If you configure the GigE 8(Optional) field to enable heartbeat messages and you have directly connected the GigE 8 ports (i.e., you are not using a switch or hub to connect the ports), you **must disable** Auto-negotiation for the GigE 8 port on the active chassis as described in “[GigE Port Configuration](#)” on page 53 for proper chassis functionality.*

12. Click **Apply Configuration**.

13. Make sure that the active chassis *does* have a license key.

14. Turn *off* the active chassis.

15. Turn *on* the active chassis. Wait for it to fully boot up.

16. Turn *on* the standby chassis.

Forcing Redundancy



Caution! *Care is needed when selecting this action: forcing a redundancy change will temporarily (and briefly) interrupt services during the failover process.*

To force the current redundancy configuration to change (the secondary will become the active, or vice versa), click the **Redundancy Switch** button from the **Configuration** -> **Global** tab.

1:1 Redundancy Best Practices and Considerations

The following information must be considered when working with 1:1 chassis-level redundancy:

- The configuration of the standby chassis is not available from the *Element Manager* while the unit is a standby unit.
- Because the virtual subnet mask is not configurable, the virtual IP address must be on the same subnet as the physical chassis IP addresses.
- Any changes to the virtual IP address requires a reboot of the active chassis.
- If the connection to the 10/100 control port on the active chassis is broken, both chassis will have the same output, unless GigE 8 is configured for heartbeat messages. This can be confusing to the network.
- A heartbeat is also sent through the GigE ports.

Ethernet Control Port Configuration

There are two Ethernet control ports for each BNP3xr: one for basic management and access to the *Element Manager*; the other for DVB-CA connectivity and access. To view and configure the *Ethernet Control Port* configuration:

1. From the *Element Manager*, select **Configuration -> Ethernet Control Port**.

The **Ethernet Control Port** configuration window appears.

The screenshot shows the 'BROADCAST NETWORK PROCESSOR' configuration window. The 'Configuration' tab is selected, and the 'Ethernet Control Port' sub-tab is active. Under 'IP Configuration', 'Static' is selected. For 'Ethernet Port 1', the MAC Address is 00:11:07:01:e4:0a, IP Address is 10.32.128.171, Subnet Mask is 255.255.255.0, Gateway is 10.32.128.1, and DNS Server is 10.32.128.50. 'Ethernet Port 2' fields are empty. At the bottom right are 'Apply Configuration' and 'Cancel' buttons. The status bar at the very bottom shows 'Connected 10.32.128.171' and the time '14:20:44'.

Figure 38. Ethernet Control Port configuration

2. Table 11 describes the variables that can be changed. Depending on whether you choose a static configuration or DHCP for obtaining an IP address to login, the variables may be different. By default, a static IP address is used.

Table 11. Ethernet Control Port Configuration Fields

Category	Field	Description
	IP Configuration	Select the source of the BNP boot configuration file from the pull-down menu: choices include <i>BOOTP/ DHCP</i> or <i>Static</i> .

Table 11. Ethernet Control Port Configuration Fields (Continued)

Category	Field	Description
Ethernet Port 1 ^a	MAC Address	A read-only field that displays the MAC address of the 10/100 management port.
	IP Address	If static is selected, enter the IP address of the management port for the BNP; this field cannot be blank.
	Subnet Mask	If static is selected, enter the subnet mask of the management port for the BNP; this field cannot be blank.
	Gateway	If static is selected, enter the IP address where management packets are routed out of the local network (the default router address).
	DNS Server	If static is selected, enter the IP address of the DNS server being used for management of the BNP. • This field is optional.
Ethernet Port 2 ^b	MAC Address	A read-only field that displays the MAC address of the DVB-CA management port.
	IP Address	If static is selected, enter the IP address of the DVB-CA management port.
	Subnet Mask	If static is selected, enter the subnet mask of the DVB-CA management port.
	Gateway	If static is selected, enter the IP address where DVB-CA packets are routed out of the local network (the default router address). • If configuring the BNP3xr in a 1:1 redundancy environment, the Gateway IP Address <i>must</i> be configured for this port.
	DNS Server	If static is selected, enter the IP address of the DNS server being used for DVB-CA. • This field is optional.

a. The IP address for Ethernet Port 1 must be on a different subnet from any of the Gigabit Ethernet IP addresses.

b. The IP address for Ethernet Port 2 must be on a different subnet from the IP address of Ethernet Port 1 and any of the Gigabit Ethernet IP addresses.

3. Click **Apply Configuration** to save and load the changes.

Determining the BNP IP Address for DHCP

If DHCP has been selected to obtain an IP address, the IP address can not be obtained through the *Element Manager*. There are three methods you can use to determine the IP address:

1. Connect to the BNP through the serial console and at a prompt type **ifconfig eth0**.
or
2. If the DHCP server is available, check the MAC and IP mapping on the DHCP server.
or
3. Use a “sniffer” to sniff the network for DHCP traffic.

Note: *If you choose DHCP rather than a static IP address, you will need the assistance of RGB Networks customer support. [Contact them](#) before you choose DHCP.*

GigE Port Configuration

All GigE ports can be configured from the BNP *Element Manager*. The GigE ports support full duplex processing of transport streams; this means that the same GigE port can be used for input and output. The GigE Port configuration screen is shown in [Figure 39](#).




Figure 39. GigE Port configuration screen

To modify a GigE port:

1. From the *Element Manager*, select **Configuration -> GigE Ports**.

All GigE ports are shown in a list. For easy identification, the ports appear with a color-coded icon to recognize active and inactive ports. Active ports are shown in green.

2. Make any necessary changes to the GigE port configuration. Type the changes directly into the appropriate field for the GigE port being modified.

Table 12 describes the variables that can be changed for each GigE port.

Table 12. GigE Port Configuration Fields

Field	Description
Port	The GigE port number, listed sequentially.
Status	Read-only; the current status of the port.
MAC Address	Read-only; the MAC address of the port.
IP Address ^a	The IP address for the interface; if no IP address is used, leave the field empty.
Subnet Mask	The subnet mask address.
Default Gateway	The default gateway (default router) to use, if applicable.
Mirrored To	If the port is mirrored, the port to which the selected port is mirrored appears in a read-only field. When you mirror two GigE ports, in the event of failure of one, the other one takes over without interruption.
Mirroring	Click Set to open a dialog, allowing you to mirror this port.
Autonegotiation	Enable or disable autonegotiation.

a. While the Element Manager allows the IP addresses of the GigE ports to be configured in the same subnet, it is recommended that all GigE ports be configured on different subnets for proper routing.

3. Click **Apply Configuration** to apply the changes to your configuration.

Gigabit Ethernet Port Mirroring

Figure 40 shows an example of Gigabit Ethernet port mirroring. Gigabit Ethernet port 6 is mirrored to Gigabit Ethernet port 3. This means that all output traffic on Gigabit Ethernet 6 is copied over to Gigabit Ethernet 3. The only difference for the traffic coming from Gigabit Ethernet 6 and Gigabit Ethernet 3 is the source IP address.

To mirror one GigE port to another:

1. From the **Configuration -> GigE Ports** menu, click the **Set** button next to the port that is to be mirrored.

- From the drop down menu that appears, select the desired port to which the current port is to be mirrored.

There is no need to click **Apply Configuration** as the mirroring happens as soon as the port is chosen.




Figure 40. Mirroring GigE ports

This configuration is typically used in Source Specific Multicast deployment with IGMPv3 support. The two Gigabit Ethernet ports serve as two different sources for the same video traffic.

Removing Port Mirroring

To remove mirroring from a GigE port, from the GigE port configuration page, locate the mirrored port and click **Remove** from the **Mirroring** column.

Configuring ASI Ports

The ASI ports on each slot can be viewed from the Configuration tab. Only active slots appear on the tab; inactive slots are not shown. Up to four slots are displayed. For each slot, you can see:

- **Port:** the port number.
- **Status:** the current status of the port: *Active* or *Inactive*.
- **Direction:** the direction of dataflow on this port: *Input* or *Output*.



Note: In order for the ASI port to be displayed on the **Inputs** side of the **Grooming -> Mapping** window, the port direction must be **Input**; in order for the ASI port to be displayed on the **Outputs** side of the **Grooming -> Mapping** window, the port direction must be **Output**.

Use the pull-down list for direction to select or to change the data flow direction of a specific port.




Figure 41. ASI port configuration tab

Modifying a Port Name

You can modify or change a port name for either a GigE or an ASI port. Proceed as follows.

1. From the **Inputs** or **Outputs** side of the **Grooming -> Mapping** window, right click the desired port name. The following pop-up menu appears (Figure 42).




Figure 42. Modify Port Name Menu

2. Choose **Modify Port Name**. The **Modify Port Name** menu appears (Figure 43).




Figure 43. Modifying the Port Name

3. Click **OK**. The modified port name appears (Figure 44).




Figure 44. Port Name Modified

User Authentication

The **User Authentication** screen provides a central area from which user control settings can be edited, added, or deleted. The BNP permits both local and remote user authentication. Remote user authentication is performed using an authentication, authorization and accounting (AAA) server that supports RADIUS or TACACS+.

The AAA server handles requests for access to system resources to be configured, allowing maintenance of user profiles to be performed once for any number of clients. When a client wants to access a system resource, it must first get permission from the AAA server.

The BNP provides a local user fallback authentication method enabling users to log in when an AAA server is not available. However, for security and account management reasons, use of AAA is recommended. All passwords configured for AAA—both remote and local—are encrypted.

The following workflow (Figure 45) describes the behavior of the authentication process when a user attempts to login to the BNP.




Figure 45. BNP User Authentication Workflow

The tabs available in the **User Authentication** screen are: **Global**, **Local**, and **Servers**, seen below in Figure 46.

Global Configuration

The **Global** tab is used to configure global AAA options for the BNP system. To configure Global AAA parameters, proceed as follows:

1. From the *Element Manager*, select **Configuration -> User Authentication -> Global**.




Figure 46. User Authentication - Global, AAA disabled

2. Check the **Enable** box to enable and view AAA-related fields.

The **Enable** checkbox is used to activate the AAA settings on this screen. If **Enable** is not checked (Figure 46) the AAA server-related fields are hidden and local user authentication will be used. If **Enable** is checked (Figure 47) a specified AAA server will be used to user authentication.

The screenshot shows the 'User Authentication - Global' configuration screen. The 'Enable' checkbox is checked. The 'Number of Retries' is set to 0, 'Timeout (Sec)' is set to 2, and 'Protocol' is set to Radius. The 'Remote Only' checkbox is unchecked. A yellow circle highlights the 'Number of Retries', 'Timeout (Sec)', and 'Protocol' fields, with a yellow arrow pointing to them from a text box that says 'These fields are hidden when the Enable box is unchecked'. The 'Apply Configuration' and 'Cancel' buttons are at the bottom right. The status bar at the bottom shows 'Connected 10.32.128.171' and the time '14:30:11'.

Figure 47. User Authentication - Global, AAA enabled

3. Fill in the fields according to the parameters listed in Table 13.

Table 13 describes the fields available on the **Global** tab of the **User Authentication** screen:

Table 13. User Authentication - Global Fields.

Field	Description
Enable	Used to enable authentication using AAA. When checked, the remaining fields in this table will appear. Default is <i>unchecked</i> .
Number of Retries	The number of times the system will try connecting to a remote server before trying another server in the list. Default is 0. Valid range is from 0 to 2.
Timeout (sec)	The amount of time (in seconds) to wait for a response from the remote server. Default is 2. Valid range is from 1 to 4.

Field	Description
Protocol	<p>The preferred protocol to use in selecting a server.</p> <p>Valid options are:</p> <ul style="list-style-type: none"> • Radius - Try all RADIUS servers before trying TACACS+ servers. • TACACS+ - Try all TACACS+ servers before trying RADIUS servers. <p>Default is <i>Radius</i>.</p>
Remote Only	<p>Checking this box will require the BNP to use only remote authentication. If enabled and remote authentication fails or connection with the AAA server is not established, local authentication is not performed and the user is not logged in.</p> <p>Default is <i>unchecked</i>.</p> <ul style="list-style-type: none"> • At least one AAA server must first be configured before the Remote Only option is checked and the configuration applied to the BNP. See “Server Configuration” on page 62 for details on configuring an AAA server.

4. Click the **Apply Configuration** button to save changes.

Local Configuration

The Local tab permits the Administrator to configure the local user account passwords for the BNP system. To configure passwords for the local login, proceed as follows:

1. From the *Element Manager*, select **Configuration -> User Authentication -> Local**.

The screenshot displays the 'BROADCAST NETWORK PROCESSOR' interface. The top menu bar includes 'File', 'View', 'Maintenance', 'DVB-CA', and 'Help'. The main navigation tabs are 'Grooming', 'Alarms & Events', 'Configuration', 'Chassis', and 'DVB-CA'. Under the 'Configuration' tab, there are sub-tabs: 'Global', 'Ethernet Control Port', 'GigE Ports', 'ASI Ports', 'User Authentication', 'Messaging System', and 'SNMP Trap'. Within 'User Authentication', the 'Local' sub-tab is active, showing a 'Global' sub-tab and a 'Servers' sub-tab. The 'Local' sub-tab contains a form with the following fields: 'User:' (a dropdown menu showing 'Administrator'), 'Old Password:', 'New Password:', and 'Retype New Password:'. At the bottom right of the form are 'Change Password' and 'Cancel' buttons. The status bar at the bottom left indicates 'Connected 10.32.128.171' and the bottom right shows the time '14:31:43'.

Figure 48. User Authentication - Local

The fields in the **Local** screen are used to manage the three local user account passwords. These settings only apply if AAA is disabled or the AAA server is unreachable, and **Remote Only** is not enabled.

2. From the **User** drop down box, select the user whose password you wish to modify.
3. In the **Old Password** field, type in the existing password for the account.
4. In the **New Password** field, type in the new password.
5. In the **Retype New Password** field, retype the new password.



Note: Passwords are case sensitive. They may be composed of alphanumeric and most special characters.

Table 14 describes the fields available in the **Local** screen.

Table 14. Local User Accounts:

Field	Description
User	Read-only access account. No changes to the configuration are allowed. <ul style="list-style-type: none"> • Default password is: <i>User</i> • Passwords are case-sensitive.
Operator	Read and write access are allowed for all configuration operations except changing passwords. <ul style="list-style-type: none"> • Default password is: <i>Operator</i>. • Passwords are case-sensitive.
Administrator	Full access to the BNP system configuration is allowed. This is the only user account that is authorized to change passwords. <ul style="list-style-type: none"> • Default password is: <i>Admin</i>. • Passwords are case-sensitive.

6. Click the **Change Password** button to save changes. New passwords will be effective the next time the user account is used to log into the *Element Manager*.

Server Configuration

The **Servers** tab is used to set up and configure AAA servers for the BNP system to use.

From the *Element Manager*, select **Configuration -> User Authentication -> Servers**.




Figure 49. User AUthentication - Servers

The **Servers** tab lists the currently configured AAA servers that are to be used by the BNP system for user authentication. From here AAA servers can be added, edited, or reordered.



Note: When deleting an AAA server, it may be necessary to reorder the list of servers so that the desired server may be deleted in descending order. For instructions on changing the server order, see “*Server Order Behavior*” on page 67.

Adding or Editing AAA Servers

The **Edit AAA Server** dialog is used both to add new AAA servers or to edit existing AAA servers. The system allows up to eight AAA servers.

To add a server, proceed as follows:

1. From the **Servers** tab, click **Add**.

The **Edit AAA Server** window will open:




Figure 50. Add AAA Server

2. Fill out the fields according to the parameters in Table 15.
3. If this server is to be available for the BNP to use when logging in via AAA, you must check the Enable field.



Note: *At least one AAA server must be enabled when the **Remote Only** option is selected from the AAA Global Configuration menu. See “Global Configuration” on page 59 for more information.*

Editing an AAA Server

To edit an AAA server, proceed as follows:

1. From the **Servers** tab (Table 49) highlight the desired AAA server to edit and click the **Edit** button. The **Edit AAA Server** window will open.

The screenshot shows a window titled "Edit AAA Server". It contains the following fields and values:

- IP Address: 10.1.1.1
- Port: 1812
- Protocol: Radius (selected from a dropdown)
- Shared Secret: cableTV
- Retype Shared Secret: cableTV
- Enable: ☒

At the bottom right, there are "Apply" and "Cancel" buttons.

Figure 51. Edit AAA Server

2. Edit the fields according to the parameters listed in Table 15 below.
3. Click the Apply button to save changes and modify the server.

Table 15 describes the fields available in the Edit AAA Server dialog.

Table 15. User Authentication - Servers - Add/Edit Server Fields

Field	Description
IP Address	The IP address of the AAA server. When adding a server, default is blank. When editing a server, this field is read-only.
Port	Enter the TCP port to use on the AAA server. Valid range is: 0 to 65535. Default for Radius is 1812. Default for TACACS+ is 49.
Protocol	Select the authentication protocol from the drop-down box to use when communicating with the AAA server. Choose between Radius and TACACS+. Default is <i>Radius</i> .
Shared Secret	Enter the password or passphrase used to authenticate with the AAA server.
Retype Shared Secret	Re-enter the password or passphrase used to authenticate with the AAA server.
Enable	Check this box to enable the AAA server. If an AAA server is not enabled, it will not be available for the BNP to use when logging in via AAA.

Reordering Server List

The **Servers** tab is used to change the order in which the BNP system looks for AAA servers. To set the server order, proceed as follows:

1. From the *Element Manager*, select **Configuration -> User Authentication -> Servers**.

2. Click on the **Apply** button.




Figure 52. Edit AAA Server Order

3. In the **Change Order to** field, enter the new order of the AAA servers. [Figure 53](#) shows an example:




Figure 53. Edit AAA Server Order - modified

4. Click **Apply** to save changes.

The new server order will be displayed in the Servers tab as shown in Figure 54 below:




Figure 54. New Server order

Table 16 describes the fields available in the **Edit AAA Server Order** menu

Table 16. User Authentication - Servers - Edit AAA Server Order Fields.

Field	Description
Current Order	Displays the current server order. The default server order is the order in which the AAA servers were added to the list. This field is read-only.
Change Order To	The new server order to use. <ul style="list-style-type: none"> Separate each number with one space. The same number of servers must be entered that are listed in the current order field. For example, if there are 5 servers listed in the Current Order field, changing the order to 1 2 4 3 would be invalid; changing the order to 1 2 4 3 5 is valid.

Server Order Behavior

The order in which the system attempts to connect to an AAA server is based on the following:

- The preferred authentication protocol specified in the **Protocol** field of the **User Authentication -> Global** tab;
- The current server order as shown in the Order column of the **User Authentication -> Servers** tab.

If the preferred authentication protocol is set to **Radius**, all Radius servers will be tried first, followed by TACACS+ servers. If set to **TACACS+**, all TACACS+ servers will be tried first, followed by RADIUS servers.

For example, if four AAA servers have been added to the AAA server list (see Table 17) and the specified protocol preference is Radius, the order in which the servers are tried is A, D, B, C.

Table 17. AAA Server List Example

AAA Server	Current Server Order	Protocol
A	1	RADIUS
B	2	TACACS+
C	3	TACACS+
D	4	RADIUS

Deleting Servers

To delete an AAA server, proceed as follows:

1. From the *Element Manager*, select **Configuration -> User Authentication -> Servers**.
2. Select the highest numbered AAA server from the **Order** column (see [Figure 49 on page 63](#)) and click the **Delete** button.

The **Delete Confirmation** window will be displayed:




Figure 55. Server deletion confirmation

3. Select **Yes** to delete the server.



Note: The *Servers* tab will only allow deletion of a server in descending order. For example, if there are four servers in the order of 1, 2, 3, 4, the order in which the servers must be deleted is 4 3 2 1.

To delete a server whose order is not last, reorder the servers to change the desired deletion to the last number in that order.

Messaging System Configuration

The **Configuration -> Messaging System** tab allows you to configure parameters for the BNP to integrate with external messaging systems, insert operator messages directly from the BNP GUI, or configure the BNP to use external text or graphic files as overlay messages. You can also configure the BNP to insert a graphics file (PNG) into one or more programs as a digital logo overlay. To configure these features you must create specific Messaging or Logo Overlay zones under the **Messaging System** tab, which are then associated to desired programs through the **Grooming -> Mapping** tab. This section describes how to create both Messaging and Logo Overlay zones. See [“Show Program List” on page 99](#) for instructions on how to associate and enable programs to Messaging or Logo Overlay zones.

Messaging Zones

Up to ten Messaging Zones can be configured for the BNP. Within each zone, two types can be configured: EAS or Operator and Advanced. A Messaging Zone may be sent either SCTE 18 alerts that are used for **EAS Messaging**, **Operator Messaging** based on operator-defined text, or **Advanced Messaging** created from imported graphics (.PNG) or text files, and advanced text parameters.

☞ From the **Configuration -> Messaging System** tab, select the **Messaging Zones** subtab.

The **Messaging Zones** subtab (Figure 56) provides a snapshot view of all messaging zones. It also provides a global parameter associated only with EAS messaging for system-wide configuration of audio EAS override during DPI.




Figure 56. Configuration -> Messaging System tab

Table 18 describes the fields available from the **Messaging Zones** subtab.

Table 18. Messaging Zones subtab

Field	Description
Reject EAS audio override during DPI	When checked, the BNP will reject all external SCTE 18 EAS messages with audio override priority for the duration of an ad insertion (text crawling will still continue).
Zone Index	The sequential index number of the created zone. This field is read-only. Up to ten zones can be added.
Zone Type	Displays what type of zone has been created. Choices are: <i>EAS</i> or <i>Operator and Advanced Messaging</i> .
Zone Status (for EAS Messaging Zones)	The status of the Messaging Zone. This field is read-only. If the zone is an EAS Messaging Zone, possible choices are: <ul style="list-style-type: none"> • <i>Enable</i>: EAS Zone is ready for SCTE 18 EAS message. • <i>Emergency Alert Crawl On</i>: SCTE 18 EAS alert activated, text crawl is displaying. • <i>Emergency Alert Audio Override</i>: SCTE 18 EAS alert activated with Priority 1-14, emergency audio is playing, text crawl will be present. • <i>Emergency Alert Video Switch</i>: SCTE 18 EAS alert activated with Priority 15, emergency video is playing.
Zone Status (for Operator or Advanced Messaging zones)	The status of the Messaging Zone. This field is read-only. If the zone is an Operator or Advanced Messaging Zone, possible choices are: <ul style="list-style-type: none"> • <i>Enable</i>: Messaging zone is ready to start Operator messaging or Advanced Messaging operations. • <i>Operator Messaging Loaded</i>: Operator message is loaded on the BNP and is ready to start the operator message. • <i>Operator Messaging Text On</i>: Operator Alert Message is loaded on the BNP and crawl text is displaying in the zone. • <i>Advanced Messaging Loaded</i>: Text or graphic file is loaded on the BNP and ready to play. • <i>Advanced Messaging On</i>: Advanced Messaging is loaded on the BNP and imported graphic and/or text crawl is displaying in the zone • <i>Scheduled</i>: Operator Messaging or Advanced Messaging has been loaded and scheduled, but currently is not being played.
Zone Name	The name of the zone. This field is read-only and is created when adding or modifying a new Messaging Zone.
UDP	The UDP port used to detect an external SCTE 18 EAS server message. This field is read-only and is populated when adding or modifying a new EAS Messaging Zone. If the zone is Operator or Overlay this field will display "N/A".

EAS Messaging Zones

The BNP Digital EAS feature supports the SCTE 18 (2007) "Emergency Alert Messaging for Cable" standard specification for EAS message control and display, which defines the standard for playout of text message crawls and audio during an emergency alert event. Using the 10/100 BaseT management interface, the BNP supports the following SCTE 18 messages:

- EAS text crawl;
- EAS text crawl with audio override;
- Substitute EAS detail channel for the network feed.

The BNP will respond to any EAS alert based on the following SCTE 18-defined alerts:

- Levels 1-14: The BNP delivers a text crawl and allows adherence to the SCTE 18 specification to override the audio source on defined channel with text information and encoded audio sources from the EAS system.
- Level 15 (highest priority): The BNP offers user configuration to allow adherence to the SCTE 18 specification to override both video and audio on a detailed channel with the encoded service provided by the EAS system, or to use the same configuration options for Levels 1-14.
 - The BNP will force tune to the detailed channel for H.264 and treat it as a data program.

The BNP communicates with an external EAS management system for messaging zone control information, including interpretation of FIPS (Federal Information Processing Standards) announcements. Additionally, user configurable audio muting and audio override of the network program's audio is supported.

To configure a new EAS Messaging zone:



Note: You must be logged in as the Administrator to add, modify, or delete **Messaging Zones** configuration.

1. From the **Configuration -> Messaging System** tab, click on the **Messaging Zones** subtab.
2. Right-click anywhere on the white or light blue rows.

Zone Index	Zone Type	Zone Status
1	Operator and Advanced Messaging	Operator Messaging Text On
2	Add EAS Messaging Zone Add Operator and Advanced Messaging Zone Modify Messaging Zone Delete Messaging Zone Show Program List	essaging Text On
3		essaging Text On
4		essaging Text On
5		essaging Text On
6		essaging Text On
7		essaging Text On

Figure 57. Messaging Zone pop-up window

3. Select **Add EAS Messaging Zone** from the pop-up menu (Figure 57).

4. The **Add EAS Messaging Zone** window of Figure 58 opens:

The screenshot shows the 'Add EAS Messaging Zone' window. It features a blue header bar with the title 'Add EAS Messaging Zone'. Below the header, the window is divided into several sections. The 'Zone Index' section contains a 'Zone Name' text input field. The 'EAS Video Configuration' section includes fields for 'Port' (set to N/A), 'IP Address', 'Source IP Address', 'UDP Port', 'Program Number', and 'Audio Override Delay(In Secs)' (set to 2). The 'EAS Zone Control Configuration' section includes 'UDP Port', 'PID' (set to 0x1FFB), and 'Crawl Only Priority' (set to 0). The 'EAS Crawl Configuration' section includes 'Crawl Position' (set to Top), 'Crawl Speed' (set to Normal), and 'Crawl Background Color' (set to Red). The 'EAS Zone Status' section includes 'Start Time', 'Remaining Time', 'Event Duration', 'Current Status', and 'Priority'. The 'Alert Text' section is a large text area. At the bottom right, there are 'Apply' and 'Cancel' buttons.

Figure 58. Add EAS Messaging window

5. Fill out the appropriate fields according to your desired configuration.

Table 19 provides a description of the fields available in the **Add / Modify EAS Messaging Zone** menu.

Table 19. Add / Modify EAS Messaging Zone menu

Section	Field	Description
Zone Index	Zone Name	Assign a unique name for the zone to be created. This field accepts alphanumeric entries. Up to ten Messaging Zones may be created; these may be a mix of EAS or Operator and Advanced zones.

Table 19. Add / Modify EAS Messaging Zone menu (Continued)

Section	Field	Description
EAS Video Configuration (This defines the EAS video source parameters for substituting over the network program due to alert status or audio override option.)	Port	Select desired GigE or ASI ^a port from the pull down menu on which detailed channel information (transport stream) is received for EAS messaging.
	IP Address	The IP address of the GigE port. Input a valid multicast IP address on which the detailed channel transport stream is received for EAS messaging. (Not required for ASI ports.)
	Source IP Address	The IP address of the source from which the GigE port receives data; the source IP address is optional and should only be included for IGMPv3 transport streams. (Not required for ASI ports.)
	UDP Port	Input a valid UDP port on which the detailed channel transport stream is received for EAS messaging. Valid range is from 1 to 65535. (Not required for ASI ports.)
	Program Number	Input the program number on which the program information is received for EAS messaging.
	Audio Override Delay (In Secs)	Specifies the delay of audio splicing of the EAS program by x number of seconds. Range is from 0-255. A setting of 0 specifies no delay.
EAS Zone Control Configuration	UDP Port	Input the UDP port which will be used to detect an external SCTE 18 EAS server message. The typical port number used for this is 5050. <ul style="list-style-type: none"> • SCTE 18 zone specific messaging will vary by UDP port configuration. • A unique UDP port should be configured for each EAS zone.
	PID	Choice of two hexadecimal values as defined by the SCTE 18 standard. Choose which value corresponds to your server: <i>0x1FFB or 0x1FFC</i>
	Crawl Only Priority	Sets the threshold at which program audio will be overridden by an external EAS source. <ul style="list-style-type: none"> • If the SCTE 18 message is less than or equal to the value set here, then audio override will not occur. • If the SCTE 18 message is higher than this level, but lower than priority 15, audio override will occur. • If the SCTE 18 message is priority 15, then all output programs configured to receive EAS messaging are tuned to the emergency channel and the audio and text crawl is overridden. • If priority is set to 0, then no SCTE 18 messages will be set to Crawl Only.

Table 19. Add / Modify EAS Messaging Zone menu (Continued)

Section	Field	Description
EAS Crawl Configuration	Crawl Position	Select the location on the end user's TV screen in which the crawl text will appear. Choices are: Top, Middle, Bottom. For details on crawl positioning, see Table 20 .
	Crawl Speed	Select the speed at which text will crawl across the end user's TV screen. Choices are: <i>Fast, Normal, Slow</i> .
	Crawl Background Color	Select the background color on which the crawl text will be displayed. Choices are: <i>Red, Green, Blue, Black</i> .
EAS Zone Status	Start Time	Read-only field. Displays the day, date, and time that the crawl has or will begin. Applies to both external SCTE 18 EAS server and Operator Alert messages.
	Remaining Time	Read-only field. If a limit was placed on the duration of the alert (either in the Operator-defined <i>Crawl Duration</i> field or from the external SCTE 18 EAS server), the time remaining is displayed here.
	Event Duration	Read-only field. Displays how long the event is to take place.
	Current Status	This field is read-only and will display one of the following values: <ul style="list-style-type: none"> • Enable • Emergency Alert Crawl On • Emergency Alert Audio Override • Emergency Alert Video Switch See Table 18 for a complete description of these values.
	Priority	Read only field. This field will display the EAS message priority (1-15).
Alert Text		Read only field. Displays the EAS message alert.
Action Buttons at bottom of screen	Show Program List	Clicking this button will open the <i>Show Program List</i> window, which displays all programs associated for the specified zone. <ul style="list-style-type: none"> • This button only appears when <i>modifying</i> a zone, and not when creating a zone.
	Enable Status Update / Disable Status Update	Clicking this button will enable real-time polling of the Zone Status fields as well as any Operator-defined text crawls. <ul style="list-style-type: none"> • When the <i>Enable Status Update</i> button is clicked and real-time polling enabled, the button will change to <i>Disable Status Update</i>. Clicking the <i>Disable Status Update</i> button will disable real-time polling. • This button only appears when <i>modifying</i> a zone, and not when creating a zone.

a. The applicable ASI port (if selecting) must have been configured as an input port in order to appear in the pull down menu

Table 20, below, describes how the BNP displays crawl positioning with various resolutions:

Table 20. Crawl Positioning^a

Resolution	Crawl Height	Top	Middle	Bottom
480 SD	48	32	208	384
576 SD	48	48	256	464
750 HD	80	64	320	576
1080 HD	80	96	496	896

a. Positioning is in pixels, from top of screen to top of crawl. Crawl Height is also in pixels.

6. Click **Apply** to save changes and create the messaging zone.

To modify an EAS Messaging Zone:

1. From the **Messaging System -> Messaging Zones** subtab, double-click the EAS messaging zone you wish to modify, or right-click EAS the zone and select **Modify Messaging Zone** from the pop-up menu (Figure 57).
2. The **EAS Messaging Zone ([Zone Index]:[Zone Name])** window opens.

Figure 59. Modify EAS Zone

3. Modify the desired fields according to the parameters listed in Table 19.
4. Click **Apply** to save changes to the messaging zone.

To Delete an EAS Messaging Zone:

1. From the **Configuration -> Messaging System -> Messaging Zones** menu, highlight and right-click on the EAS Messaging Zone you wish to delete.
2. Select **Delete Messaging Zone** from the pop-up menu (Figure 57).
3. If there are no output transport streams associated with the selected zone, you will be asked to confirm deletion and the zone will be deleted.
4. If there are output transport streams associated with the selected zone, the following message appears:






Figure 60. Delete Output TS-associated messaging zones


5. Click **Yes** to delete the zone and its association to any programs.

Operator and Advanced Messaging Zones

The BNP Messaging System feature supports Operator and Advanced Messaging Zones, which allows the cable operator to generate a text crawl of up to 400 characters in length directly from the BNP *Element Manager* or to specify a text or graphic file as an overlay. Both Operator and Advanced zones can be associated to individual programs. This capability is only allowed using Administrator login privileges.

-  **Note:** *An **Advanced Overlay** license must be purchased in order to view or configure an Advanced Messaging Zone. For more information on **Advanced Overlay** licensing, see “[The License Manager](#)” on page 111.*
-  **Note:** *SCTE 18 EAS messages take precedence over Operator and Advanced Alert Messages. The latter can not be sent to a program that has an active SCTE 18 message alert. An SCTE 18 message alert sent to a zone will immediately override any current GUI generated alert message playout.*

To configure an Operator Messaging Zone:

-  **Note:** *You must be logged in as the Administrator to add, modify, or delete **Messaging Zone** configuration.*

1. From the **Configuration -> Messaging System** tab, click on the **Messaging Zones** subtab.

2. Right-click anywhere on the white or light blue rows.

Zone Index	Zone Type	Zone Status
1	Operator and Advanced Messaging	Operator Messaging Text On
2		
3		essaging Text On
4		
5		Messaging Loaded
6		essaging Text On
7		Messaging Loaded

Figure 61. Messaging Zone pop-up window

3. Select **Add Operator and Advanced Messaging Zone** from the pop-up menu (Figure 61).
The **Add Operator and Advanced Messaging Zone** window opens (Figure 62).
4. Click the **Operator Messaging** tab.

The screenshot shows the 'Add Operator and Advanced Messaging Zone' window with the 'Operator Messaging' tab selected. The window has a blue header and a white body. On the right side, there is a 'Zone Status' panel with fields for Start Time, Remaining Time, Event Duration, Current Status, Next Start Time, and Overlay Image. The main area contains several sections: 'Crawl Configuration' with dropdowns for Crawl Position (Top), Crawl Speed (Normal), Crawl Background Color (Red), and Background Transparency Level (0% (Opaque)); 'Crawl Text' with a text input field; 'Crawl Duration' with radio buttons for One Cycle, Play (30 seconds), and Continuous; 'Frequency' with radio buttons for Once and Every (60 minutes); and 'Schedule' with radio buttons for Start (Now, Time) and Stop (Forever, Time). At the bottom right, there are 'Start' and 'Stop' buttons. At the bottom center, there are 'Apply' and 'Cancel' buttons.

Figure 62. Add Operator and Advanced Messaging Zone - Operator Messaging tab

5. Fill out the appropriate fields according to your desired configuration.

[Table 21](#) provides a description of the fields available in the **Operator Messaging** tab of the **Add / Modify Operator and Advanced Messaging Zone** menu.

Table 21. Operator Messaging tab

Section	Field	Description
Zone Name	Zone Name	This field is common to both Operator and Advanced tabs. Up to ten Messaging Zones may be created; these may be a mix of EAS or Operator and Advanced zones.
	Crawl Position	Select the location on the end user's TV screen in which the crawl text will appear. Choices are: <i>Top, Middle, Bottom.</i> For details on crawl positioning, see Table 20 .
	Crawl Speed	Select the speed at which text will crawl across the end user's TV screen. Choices are: <i>Fast, Normal, Slow.</i>
	Crawl Background Color	Select the background color on which the crawl text will be displayed. Choices are: <i>Red, Green, Blue, Black.</i>
	Background Transparency Level	Specifies the level of transparency in which the background color will be displayed. At 0%, the background color will be opaque; at 100% there will be no background color. You may type in any value from 0 to 100 or choose a value from the drop-down box as follows: <i>0% (opaque), 25%, 50%, 75%, and 100%</i> <i>NOTE: This box will not display unless Transparency was enabled in the Global Configuration window.</i>

Table 21. Operator Messaging tab (Continued)

Section	Field	Description
Crawl Text, Duration, & Frequency	Crawl Text	Input the desired alert message up to 400 alphanumeric characters.
	Crawl Duration	<p>This section provides the following options for the duration of the text crawl:</p> <ul style="list-style-type: none"> • <i>One Cycle</i>: Plays the full message one time all the way through. • <i>Play xxx Seconds</i>: Plays the message for the specified number of seconds (with a 5 second or one cycle minimum). Message will play for the duration that is <i>longest</i>: Specified value of seconds OR one cycle. • <i>Continuous</i>: Continuously plays message until the <i>Stop Crawl</i> button is clicked.
	Frequency	<p>Choose between two options for how often message is played:</p> <ul style="list-style-type: none"> • <i>Once</i>: Plays message once, either for one cycle or specified number of seconds (see above). • <i>Every</i>: Select either <i>30</i> or <i>60</i> to play message every thirty or sixty minutes, either for one cycle or for specified number of seconds (see above) from the moment <i>Start</i> is clicked until the moment <i>Stop</i> is clicked.
Schedule	Start	<p>The BNP permits you to start a message immediately or schedule it.</p> <ul style="list-style-type: none"> • <i>Now</i>: Starts play immediately. • <i>Time</i>: Allows you to schedule start time. Click on the pulldown arrow to display a popup window (seen in Figure 63 on page 81) to set start.
	Stop	<ul style="list-style-type: none"> • <i>Forever</i>: If message is set to play once (see <i>Frequency</i>, above) this is the default. • <i>Time</i>: When <i>Frequency</i> is set to every <i>30</i> or <i>60</i> minutes, the Scheduler popup is enabled. Click on the pulldown arrow to display (see Figure 63 on page 81) and set.

Table 21. Operator Messaging tab (Continued)

Section	Field	Description
Zone Status	Start Time	Read-only field. Displays the day, date, and time that the crawl has or will begin.
	Remaining Time	Read-only field. If a limit was placed on the duration of the alert, the time remaining is displayed here.
	Event Duration	Read-only field. Displays how long the event is to take place.
	Current Status	<p>This field is read-only and will display one of the following values:</p> <ul style="list-style-type: none"> • <i>Enable</i> • <i>Operator Messaging Loaded</i> • <i>Operator Messaging Text On</i> • <i>Advanced Messaging Loaded</i> • <i>Advanced Messaging On</i> • <i>Scheduled</i> <p>See Table 18 on page 70 for a complete description of these values.</p>
	Next Start Time	Read-only field. Displays the time that the next round of messaging will begin.
	Overlay Image	<p>Read-only field. Applicable to <i>Advanced Messaging</i> tab. Displays the status of the graphic and/or text overlay. Possible values are:</p> <ul style="list-style-type: none"> • <i>Complete</i>: An image or text file has been uploaded to the BNP. • <i>None</i>: No image or text file has been uploaded to the BNP.
Action Buttons at bottom of screen	Show Program List	<p>Clicking this button will open the <i>Show Program List</i> window, which displays all programs associated for the specified zone.</p> <ul style="list-style-type: none"> • This button only appears when modifying a zone, and not when creating a zone.
	Enable Status Update/ Disable Status Update	<p>Clicking this button will enable real-time polling of the Zone Status fields as well as any Operator-defined text crawls.</p> <ul style="list-style-type: none"> • When the <i>Enable Status Update</i> button is clicked and real-time polling enabled, the button will change to <i>Disable Status Update</i>. Clicking the <i>Disable Status Update</i> button will disable real-time polling. • This button only appears when modifying a zone, and not when creating a zone.

6. Click **Apply** to save changes and create the messaging zone.

To Schedule Messaging in Advance :

1. Click the **Time** button.

2. Click the pulldown arrow in the **Time** field. The **Advanced Messaging Schedule Window** appears.
3. Click the **Month**, **Day**, and **Time** fields to schedule the message.
4. Press **OK**.




Figure 63. Advanced Messaging Schedule Window

To modify an Operator Messaging zone:

1. From the **Messaging System** -> **Messaging Zones** subtab, double-click the messaging zone you wish to modify, or right-click the zone and select **Modify Messaging Zone** from the pop-up menu (Figure 57 on page 71).

- The **Operator and Advanced Messaging Zone ([Zone Index])** window below opens.

Figure 64. Modify Operator Messaging Zone

- Modify the desired fields according to the parameters listed in [Table 21 on page 78](#).
- Click **Apply** to save changes to the messaging zone.

To configure an Advanced Messaging Zone:

- Note:** You must be logged in as the Administrator to add, modify, or delete **Messaging Zone** configuration.
- Note:** An **Advanced Overlay** license must be purchased in order to view or configure an Advanced Messaging Zone. For more information on **Advanced Overlay** licensing, see *"The License Manager"* on page 111.

- From the **Configuration -> Messaging System** tab, click on the **Messaging Zones** subtab.

2. Right-click anywhere on the white or light blue rows.

Zone Index	Zone Type	Zone Status
1	Operator and Advanced Messaging	Operator Messaging Text On
2		
3		essaging Text On
4		
5		Messaging Loaded
6		essaging Text On
7		Messaging Loaded

Figure 65. Messaging Zones pop-up window

3. Select **Add Operator and Advanced Messaging Zone** from the pop-up menu (Figure 65).
4. The **Add Operator and Advanced Messaging Zone** window of Figure 66 opens.
5. Click the **Advanced Messaging** tab.

Add Operator and Advanced Messaging Zone

Zone Name:

Operator Messaging **Advanced Messaging**

Overlay Crawl Configuration

Foreground Color: Select Color ... Background Color: Select Color ...

Crawl Position: Background Transparency Level:

Crawl Speed: Font: Select Font ...

Text: Import Text ...

Graphic: Import Graphic ...

Preview: ☒ Graphic+Text ☐ Text+Graphic Crawl Resolution: ☒ SD (Wx48) ☐ HD (Wx80)

Crawl Duration: ☒ One Cycle ☐ Play Seconds ☐ Continuous
(Min 5 seconds or at least one cycle)

Frequency: ☒ Once ☐ Every Minutes

Schedule:

Start: ☒ Now ☐ Time:

Stop: ☒ Forever ☐ Time:

Zone Status:

Start Time:

Remaining Time:

Event Duration:

Current Status:

Next Start Time:

Overlay Image:

Figure 66. Advanced Messaging Zone tab

6. Fill out the appropriate fields according to your desired configuration.

[Table 22](#) provides a description of the fields available in the **Advanced Messaging** tab of the **Add / Modify Operator and Advanced Messaging Zone** menu.

Table 22. Advanced Messaging tab

Section	Field	Description
Zone Name	Zone Name	This field is common to both Operator and Advanced tabs. Up to ten Messaging Zones may be created; these may be a mix of EAS, Operator, or Advanced zones.

Table 22. Advanced Messaging tab (Continued)

Section	Field	Description
Overlay Crawl Configuration	Foreground Color	Specifies the foreground color of the imported text file. Click the <i>Select Color</i> button to choose which color and color scheme to use.
	Background Color	Specifies the background color of the imported text file. Click the <i>Select Color</i> button to choose which color and color scheme to use.
	Crawl Position	Select the location on the end user's TV screen in which the imported crawl text or graphic will appear. Choices are: Top, Middle, Bottom. For details on crawl positioning, see Table 20 on page 75 .
	Background Transparency Level ^a	Specifies the level of transparency at which the background color will be displayed for ASCII and Non-Ascii text. At 0%, the background color will be opaque; at 100% there will be no background color ^b . <ul style="list-style-type: none"> You may type in any value from 0 to 100 or choose a value from the drop-down box as follows: 0% (opaque), 25%, 50%, 75%, and 100%. NOTE: This box will not be displayed unless Transparency was enabled in the Global Configuration window.
	Crawl Speed	Select the speed at which the imported text or graphic will crawl across the end user's TV screen. Choices are: <i>Fast, Normal, Slow</i> .
	Font	Choose the font in which the imported or typed text should be displayed. Click the <i>Select Font</i> button to choose font style, size, and attributes.
	Text	Input the desired alert message up to 400 alphanumeric characters, or use the <i>Import Text</i> button to select a text file from the hard drive of the computer on which the <i>Element Manager</i> is running. The text file will then be uploaded to the BNP's memory.
	Graphic	Displays the name of the .PNG file being used for overlay crawl. If no file has been specified, this field will be blank. To select a graphic file as an overlay crawl, click on the <i>Import Graphic</i> button and choose a .PNG file from the local computer on which the <i>Element Manager</i> is running. The graphic will be uploaded to the BNP's memory when <i>Apply</i> is clicked.

Table 22. Advanced Messaging tab (Continued)

Section	Field	Description
Preview, Crawl Resolution, Crawl Duration, and Frequency	Preview ^c	Allows you to choose in which order the overlay (if using both text and graphics) will appear. Choose from: <i>Graphic+Text</i> : Graphic on the left, text on the right <i>Text+Graphic</i> : Text on the left, graphic on the right NOTE: The Background Transparency setting only applies to the text portion (ASCII or Non-ASCII) of the overlay.
	Crawl Resolution	Allows you to choose at which resolution the overlay will appear. Choose from: SD (Wx48): Standard definition, width of overlay by 48 pixels in height. HD (Wx80): High definition, width of overlay by 80 pixels in height.
	Crawl Duration	This section provides the following options for the duration of the text crawl: <ul style="list-style-type: none">• <i>One Cycle</i>: Plays the full message one time all the way through.• <i>Play xxx Seconds</i>: Plays the message for the specified number of seconds (with a 5 second or one cycle minimum). Message will play for the duration that is <i>longest</i>: Specified value of seconds OR one cycle.• <i>Continuous</i>: Continuously plays message until the <i>Stop Crawl</i> button is clicked.
	Frequency	Choose between two options for how often message is played: <ul style="list-style-type: none">• <i>Once</i>: Plays message once, either for one cycle or specified number of seconds (see above).• <i>Every</i>: Select either <i>30</i> or <i>60</i> to play message every thirty or sixty minutes, either for one cycle or for specified number of seconds (see above) from the moment <i>Start</i> is clicked until the moment <i>Stop</i> is clicked.
Schedule	Start	The BNP permits you to start a message immediately or schedule it. <ul style="list-style-type: none">• <i>Now</i>: Starts play immediately.• <i>Time</i>: Allows you to schedule start time. Click on the pulldown arrow to display a popup window (seen in Figure 63 on page 81) to set start.
	Stop	<ul style="list-style-type: none">• <i>Forever</i>: If message is set to play once (see <i>Frequency</i>, above) this is the default.• <i>Time</i>: When <i>Frequency</i> is set to every <i>30</i> or <i>60</i> minutes, the Scheduler popup is enabled. Click on the pulldown arrow to display and set (see Figure 63 on page 81).

Table 22. Advanced Messaging tab (Continued)

Section	Field	Description
Zone Status	Start Time	Read-only field. Displays the day, date, and time that the crawl has or will begin.
	Remaining Time	Read-only field. If a limit was placed on the duration of the alert, the time remaining is displayed here.
	Event Duration	Read-only field. Displays how long the event is to take place.
	Current Status	This field is read-only and will display one of the following values: <ul style="list-style-type: none"> • <i>Enable</i> • <i>Operator Messaging Loaded</i> • <i>Operator Messaging Text On</i> • <i>Advanced Messaging Loaded</i> • <i>Advanced Messaging On</i> • <i>Scheduled</i> See Table 18 on page 70 for a complete description of these values.
	Next Start Time	Read-only field. Displays the time that the next round of messaging will begin.
	Overlay Image	Read-only field. Displays the status of the graphic and/or text overlay. Possible values are: <ul style="list-style-type: none"> • <i>Complete</i>: An image or text file has been uploaded to the BNP. • <i>None</i>: No image or text file has been uploaded to the BNP.
Action Buttons at bottom of screen	Show Program List	Clicking this button will open the <i>Show Program List</i> window, which displays all programs associated for the specified zone. <ul style="list-style-type: none"> • This button only appears when modifying a zone, and not when creating a zone.
	Enable Status Update / Disable Status Update	Clicking this button will enable real-time polling of the Zone Status fields as well as any Operator-defined text crawls. <ul style="list-style-type: none"> • When the <i>Enable Status Update</i> button is clicked and real-time polling enabled, the button will change to <i>Disable Status Update</i>. Clicking the <i>Disable Status Update</i> button will disable real-time polling. • This button only appears when modifying a zone, and not when creating a zone.

- The *Background Transparency Level* setting in the *Advanced Messaging* tab is applicable only to ASCII and Non-ASCII text characters. Background Transparency Level is not applied to graphic overlays within text crawls. [Alpha Channel Transparency](#) settings for the graphic overlay, if present in the .PNG file, will be preserved.
- Please see the latest *Release Notes* for details on the impact of enabling transparency for load time and bandwidth on the BNP.
- When importing a .PNG or .TXT file for the first time, the graphic will appear in the *Preview* box; however, after the graphic has been uploaded to the BNP and the *Advanced Message* tab is closed, the graphic is no longer available for preview, even though it remains stored in the BNP.

7. Click **Apply** to save changes and create the messaging zone.

To modify an Advanced Messaging Zone:

1. From the **Messaging System -> Messaging Zones** subtab, double-click the messaging zone you wish to modify, or right-click the zone and select **Modify Messaging Zone** from the pop-up menu (Figure 57 on page 71).
2. The **Operator and Advanced Messaging Zone ([Zone Index])** window opens.
3. Click on the **Advanced Messaging** tab.




Figure 67. Modify Advanced Zone window

4. Modify the desired fields according to the parameters listed in Table 22 on page 84.
5. Click **Apply** to save changes to the messaging zone.

To Delete an Operator or Advanced Messaging Zone:

1. From the **Configuration -> Messaging System -> Messaging Zones** menu, highlight and right-click on the Messaging Zone you wish to delete.
2. Select **Delete Messaging Zone** from the pop-up menu (Figure 61 on page 77).
3. If there are no output transport streams associated with the selected zone, you will be asked to confirm deletion and the zone will be deleted.

4. If there are output transport streams associated with the selected zone, the following message appears:




Figure 68. Delete Output TS-associated messaging zones

5. Click **Yes** to delete the zone and its association to any programs.

Operator and Advanced Messaging Zones Best Practices and Considerations

The following guidelines should be used when creating and modifying Operator and Advanced Messaging zones:

1. Only one type of **Messaging Zone** (Operator or Advanced) may be loaded or actively playing as a crawl in each zone.
2. Anytime you wish to make changes to an actively playing or loaded **Messaging Zone**, you must stop the active crawl, make the desired changes, apply the changes to load them onto the BNP's memory, and start or restart the crawl.
3. If you wish to change an actively playing **Messaging Zone** from one type to another (e.g., from an **Operator Message** to an **Advanced Message**), follow these guidelines:
 - Click the **Enable Status Update** button and check the current status of the **Messaging Zone** (see [Table 18 on page 70](#) for a description of status messages).
 - If the current status of either **Operator** or **Advanced Messaging** is *ON*, stop the crawl by clicking **Stop** in the active zone's subtab.
 - Make any changes to the desired subtab (**Operator** or **Advanced**).
 - Click **Apply** to load the new message to the BNP's memory.
 - Click the **Start** button to begin playing the message.
 - If the **Enable Status Update** button has been clicked, the new status will be appear as *[Operator Messaging Text or Advanced Messaging] On* in the **Current Status** field.
4. If you wish to change a loaded but not actively playing **Messaging Zone** from one type to another (e.g., from an **Operator Message** to an **Advanced Message**), follow these guidelines:
 - Ensure the **Enable Status Update** button has been clicked.



Note: Use caution when opening multiple windows with the **Enable Status Update** option activated as multiple GUI queries can place additional processing load on the BNP.

- Confirm the current status of the **Messaging Zone** is **not ON** (see [Table 18 on page 70](#) for a description of status messages).
- Make any changes to the desired subtab (**Operator** or **Advanced**).
- Click **Apply** to load the new message to the BNP's memory.
- If the **Enable Status Update** button has been clicked, the new status will be appear as *[Operator or Advanced] Messaging Loaded* in the Current Status field.

Logo Overlay Zones

Overview

In addition to EAS and operator messaging, the BNP Messaging System Logo Overlay option supports inserting graphic overlays into any MPEG-2 program being processed. Graphic overlays are based on importing static graphic Portable Network Graphics (PNG) files. You can preview the imported PNG files before starting the overlay insertion, but once the graphic has been saved and uploaded to the BNP, you can only see the name of the last file uploaded.

The location of the logo insertion is user configurable with positioning anywhere on the display screen defined by (x,y) screen coordinates based on pixels relating to program resolution (e.g., SD and HD). Additionally, the BNP will support alpha channel transparency inherent in the PNG file's creation. logo overlay files can be created with PNG alpha channels to control transparency effects supported by the BNP during the insertion of the overlay.

Alpha Channel Transparency

In general, a graphics file consists of three layers, or channels: RGB for red, green, and blue. Another type of channel may be added to a graphics file to allow for the configuration of transparency in the pixels when the RGB colors are merged, or layered, one on top of the other. This is known as an *alpha channel*. Alpha channels define the importance of each pixel in the layering process so that certain portions of the image can either be completely or partially masked. This allows for rectangular-shaped images to appear as irregular-shaped by controlling the pixel opacity, which is important when overlaying a logo to a TV screen.

PNG files are the most common and advanced file extension for supporting alpha channel transparency. The BNP will support any transparency mask inherent to the alpha channel of a PNG file as long as the **Enable Mask** field is checked in the **Logo Overlay Zone** menu.



Note: The **Enable Mask** field is only visible when the **Enable Transparency for Overlays** option is checked in the **Configuration -> Global** window.

Below are two examples of PNG files in which alpha channel transparency has been configured for 100% background transparency. In the first example, transparency is not enabled on the BNP; in the second example, transparency is enabled.




Alpha channel transparency has been configured in the PNG file but not enabled on the BNP




Alpha channel transparency has been configured in the PNG file and enabled on the BNP.

Figure 69. Alpha Channel transparency examples

Overlay Zone Configuration

 **Note:** *An **Advanced Overlay** license must be purchased in order to view or configure a Logo Overlay Zone. For more information on **Advanced Overlay** licensing, see “[The License Manager](#)” on page 111.*

 **Note:** *SCTE 18 EAS alerts (highest priority) and Operator and Advanced Alert messages (second priority) take precedence over Logo Overlays. A Logo Overlay can not be sent to a program that has an active SCTE 18 message or Operator and Advanced Messaging alert. An SCTE 18 message alert sent to a zone will immediately override any current GUI generated alert message playout.*

☞ From the **Configuration** -> **Messaging** System tab, click on the **Logo Overlay Zones** subtab.

The **Logo Overlay Zones** subtab (Figure 70) provides a snapshot view of all configured **Logo Overlay** zones.




Figure 70. Configuration -> Logo Overlay Zones tab

Table 23 describes the fields available from the **Messaging Zones** subtab.

Table 23. Logo Overlay Zones subtab

Field	Description
Zone Index	The sequential index number of the created zone. This field is read-only. Up to 32 zones can be added.
Zone Name	The name of the zone. This field is read-only and is created when adding or modifying a new Messaging Zone.
Position	Displays the X,Y position (in multiples of 16 pixels) of the logo placement and whether the X axis is from the Left or Right (L or R) and the Y axis is from Top or Bottom (T or B).
Zone Status	The status of the Logo Overlay Zone. This field is read-only. Possible choices are: <ul style="list-style-type: none"> • <i>Enable</i>: Logo Overlay zone is ready to start Logo Overlays. • <i>Logo Loaded</i>: Logo is loaded on the BNP and is ready to start overlay. • <i>Logo On</i>: Logo is loaded on the BNP and is currently displaying in the zone. • <i>Scheduled</i>: Logo has been loaded and scheduled, but currently is not being displayed.

Recommendations for Logo TV Screen Positioning

In order to simplify logo positioning for both SD and HD programs, the TV screen of either SD or HD has been divided into 4 quadrants with the X,Y coordinates positioned relative to each corner: On the X axis, the screen has been divided into left and right from 0 to 960 pixels (based on half the width of a typical HD 1920 pixel screen). On the Y axis, the screen has been divided into top and bottom from 0 to 540 pixels (based on half the height of a typical HD 1080i screen).

In this manner a static overlay graphic may be accurately positioned regardless of SD or HD as long as the X, Y coordinates for an SD program do not exceed an SD's resolution. *In order to ensure accurate positioning, it is recommended that the X, Y coordinates be kept to a relatively low number.*

Figure 71 shows an example of Logo Overlay positioning for an HD program (top graphic) and an SD program (bottom graphic). The X, Y coordinates for the green logo boxes have been set to relatively low numbers (x=64, y=64) so as to remain positioned closer to the corners of the TV screen for both HD and SD resolutions. The X, Y coordinates for the blue logo have been set to high numbers (x=900, y=500). As such, while the logo for an HD resolution of 1920 x 1080i is positioned in the center of the

screen, the X, Y values are too large for the blue logo to be placed within the bounds of an SD screen at 720 x 480i resolution.




Figure 71. Logo Overlay Positioning

To configure a Logo Overlay Zone:



Note: You must be logged in as the Administrator to add, modify, or delete **Logo Overlay Zone** configuration.

1. From the **Configuration -> Messaging System** tab, click on the **Logo Overlay Zones** subtab.
2. Right-click anywhere on the white or light blue rows.

Zone Index	Zone Name
1	1
2	2
3	3
4	Eastern Zone
5	Midcoast Zone
6	Western Zone
7	7

Figure 72. Logo Overlay Zone pop-up window

3. Select **Add Logo Overlay Zone** from the pop-up menu (Figure 72).

4. The **Add Logo Overlay Zone** window of Figure 73 opens.

The screenshot shows the 'Add Logo Overlay Zone' window. It features a blue header bar with the title 'Add Logo Overlay Zone'. The main content area is divided into several sections. At the top, there are input fields for 'Zone Index' and 'Zone Name'. Below this, the 'Logo Configuration' section includes input fields for 'X Position(0 to 960):' and 'Y Position(0 to 540):', both with a note '(Multiple of 16 pixels)'. There are radio buttons for 'From Left', 'From Right', 'From Top', and 'From Bottom', and a checkbox for 'Enable Mask'. To the right of this is the 'Zone Status' section with fields for 'Start Time:', 'Remaining Time:', 'Event Duration:', 'Current Status:', and 'Next Start Time:'. Below these is the 'Logo Image' section with an 'Import Graphic ...' button and a 'Logo Render Preview (Max logo image size is 256x176):' area with a note '(Preview is available only during image upload)'. The bottom section contains 'Crawl Duration' with 'Play' and 'Continuous' radio buttons, a 'Frequency' section with 'Once' and 'Every' options, and a 'Schedule' section with 'Start' and 'Stop' radio buttons. At the very bottom are 'Start' and 'Stop' buttons, and an 'Apply' button.

Figure 73. Add Logo Overlay Zone tab

5. Fill out the appropriate fields according to your desired configuration.

Table 24 provides a description of the fields available in the **Add Logo Overlay Zone** menu.

Table 24. Logo Overlay tab

Section	Field	Description
Top Section	Zone Index	Read only field; indicates the index number of the zone. Up to 32 Logo Overlay zones may be created.
	Zone Name	Enter a name for a zone. Accepts alphanumeric characters.

Table 24. Logo Overlay tab (Continued)

Section	Field	Description
Logo Configuration	X Position (0 to 960) (Multiple of 16 pixels)	Enter the pixel number (in multiples of 16) where the logo will begin for the X position (horizontal) of either the left or right quadrants of the TV screen.
	(X Position) From Left	Click this button if the logo's X position is to start from the left quadrant of either the top or bottom quadrant. For example, if the X position were set to 32 and the <i>From Left</i> button selected, the logo's left most edge would start 32 pixels from the left quadrant of either the top or bottom quadrant (whichever is selected).
	(X Position) From Right	Click this button if the logo's X position is to start from the right quadrant of either the top or bottom quadrant. For example, if the X position were set to 32 and the <i>From Right</i> button selected, the logo's right most edge would start 32 pixels from the right quadrant of either the top or bottom quadrant (whichever is selected).
	Y Position (0 to 540) (Multiple of 16 pixels)	Enter the pixel number (in multiples of 16) where the logo will begin for the Y position (vertical) of either the top or bottom quadrants of the TV screen.
	(Y Position) From Top	Click this button if the logo's Y position is to start from the top quadrant of either the left or right quadrants. For example, if the Y position were set to 32 and the <i>From Top</i> button selected, the logo's top most edge would start 32 pixels from the top quadrant of either the left or right quadrants (whichever is selected).
	(Y Position) From Bottom	Click this button if the logo's Y position is to start from the bottom quadrant of either the left or right quadrants. For example, if the Y position were set to 32 and the <i>From Bottom</i> button selected, the logo's bottom most edge would start 32 pixels from the bottom quadrant of either the left or right quadrants (whichever is selected).
	Enable Mask	Check this box if the BNP is to display and support alpha channel transparency configurations inherent to the imported graphic. For more information, see "Alpha Channel Transparency" on page 90 .

Table 24. Logo Overlay tab (Continued)

Section	Field	Description
Zone Status	Start Time	Read-only field. Displays the day, date, and time that the crawl has or will begin.
	Remaining Time	Read-only field. If a limit was placed on the duration of the alert, the time remaining (in a running-down counter) is displayed here.
	Event Duration	Read-only field. Displays how long the event is to take place.
	Current Status	This field is read-only and will display one of the following values: <ul style="list-style-type: none"> • Enable • <i>Logo Loaded</i> • <i>Logo On</i> • Scheduled See Table 23 for a complete description of these values.
	Next Start Time	Read-only field. Displays the time that the next round of messaging will begin.
Logo Import Section	Logo Image	Displays the location and name of the imported graphic that has been uploaded to the BNP.
	Import Graphic...	Click this button to select a PNG file from the local computer on which the <i>Element Manager</i> is running.
	Logo Render Preview (Max logo image size is 256x176 pixels)	When uploading a new graphic to the BNP, it will be displayed here. After the logo has been uploaded (i.e., <i>Apply</i> has been clicked), and the <i>Logo Overlay</i> window is closed, the graphic will not be displayed again, however, the file name will still be displayed in the <i>Logo Image</i> field.
	Crawl Duration	This section provides the following options for the duration of the text crawl: <ul style="list-style-type: none"> • <i>Play xxx Seconds</i>: Displays the graphic for the specified number of seconds (with a 5 second or one cycle minimum). Logo will display for the duration that is <i>longest</i>: specified value of seconds OR one cycle. • <i>Continuous</i>: Continuously displays logo until the <i>Stop</i> button is clicked.
	Crawl Frequency	Choose between two options for how often message is played: <ul style="list-style-type: none"> • <i>Once</i>: Displays graphic once or for specified number of seconds (see above). • <i>Every</i>: Select either 30 or 60 to display graphic every thirty or sixty minutes, either for one cycle or for specified number of seconds (see above) from the moment <i>Start</i> is clicked until the moment <i>Stop</i> is clicked.

Table 24. Logo Overlay tab (Continued)

Section	Field	Description
Schedule	Start (button)	<p>The BNP permits you to start a message immediately or schedule it.</p> <ul style="list-style-type: none"> • <i>Now</i>: Starts play immediately. • <i>Time</i>: Allows you to schedule start time. Click on pulldown arrow to display a popup window (seen in Figure 63 on page 81) to set start.
	Stop (button)	<ul style="list-style-type: none"> • <i>Forever</i>: If message is set to play once (see <i>Frequency</i>, above) this is the default. • <i>Time</i>: When <i>Frequency</i> is set to every 30 or 60 minutes, the Scheduler popup is enabled. Click on the pulldown arrow to display (seen in Figure 63 on page 81) and set.
Action Buttons at bottom of screen	Show Program List	<p>Clicking this button will open the <i>Show Program List</i> window, which displays all programs associated for the specified zone.</p> <ul style="list-style-type: none"> • This button only appears when modifying a zone, and not when creating a zone.
	Enable Status Update/ Disable Status Update	<p>Clicking this button will enable real-time polling of the Logo Overlay Zone Status fields.</p> <ul style="list-style-type: none"> • When the <i>Enable Status Update</i> button is clicked and real-time polling enabled, the button will change to <i>Disable Status Update</i>. Clicking the <i>Disable Status Update</i> button will disable real-time polling. • This button only appears when modifying a zone, and not when creating a zone.

To modify a Logo Overlay Zone:

1. From the **Messaging System -> Logo Overlay Zones** subtab, double-click the zone you wish to modify, or right-click the zone and select **Modify Logo Overlay Zone** from the pop-up menu ([Figure 72 on page 93](#)).

- The **Logo Overlay Zone ([Zone Index: Zone Name])** window opens.

Figure 74. Modify Logo Overlay Zone window



Note: If a Logo Overlay is currently On (click the **Enable Status Update** button to see real time status updates of the zone), stop the overlay first before modifying desired parameters.

- Modify the desired fields according to the parameters listed in Table 24 on page 94.
- Click **Apply** to save and upload new changes to the overlay zone.

To Delete a Logo Overlay Zone:

- From the **Configuration -> Messaging System -> Logo Overlay Zones** menu, highlight and right-click on the Logo Overlay Zone you wish to delete.
- Select **Delete Logo Overlay Zone** from the pop-up menu (Figure 72 on page 93).

3. If there are no output transport streams associated with the selected zone, you will be asked to confirm deletion of the zone and the zone will be deleted.
4. If there are output transport streams associated with the selected zone, the following message appears:




Figure 75. Delete Output TS-associated messaging zones

5. Click **Yes** to delete the zone and its association to any programs.

Messaging System Zone Priority

At any given time there can be only one Messaging System zone active for a particular program, even though each type of zone (EAS, Operator and Advanced, or Logo Overlay) can be enabled or associated to a particular program at the same time. If all associated zones have been activated, the priority of message playout is as follows:

1. **EAS Messaging** - will always override any Operator-defined crawl or Logo Overlay for the duration of EAS playout.
2. **Operator and Advanced Messaging** - will override an active Logo Overlay for the duration of playout. If playout is continuous and Logo Overlay is also active, then no Logo Overlay will be seen.
3. **Logo Overlay** - no override.

As an example, let us assume that a program playing on Channel 2 has all three zones configured with EAS, Operator and Advanced, and Logo Overlay zones, with a scheduled **Operator Messaging** text crawl scheduled to playout one cycle every hour and a continuously active **Logo Overlay**. During the time that the Operator Messaging crawl is scheduled to play, the Logo Overlay will not be present, however, when the crawl has finished its cycle the Logo Overlay will return. If, at any time, an EAS message is generated, both the Operator crawl and the Logo Overlay (after the crawl has finished) will be overridden until the EAS message has completed its cycle.

Show Program List

Within each Messaging System zone you can view which active programs have been configured and enabled for messaging services.

Programs Configured for Messaging Services

When a program is groomed from an input source to an output transport stream, you can specify which **Messaging System Settings** are configured (or associated) on a per program basis. A program can be associated with any or all three Messaging zone types (EAS, Operator and Advanced, and Logo Overlay). For more information on associating programs for Messaging Zones, see [“Creating MPEG-2 Output Transport Streams”](#) on page 131.

Managing Program Activity for Messaging Service Zones

An output program may join or leave a Messaging Service zone at any time, the changes taking effect the next time a message event starts.

Once a program has been associated with a Messaging Service zone, the program can then be enabled or disabled for the specified zone either from the **Grooming -> Mapping** window (see “[Creating MPEG-2 Output Transport Streams](#)” on page 131) or through the **Show Program List** window.

The **Show Program List** window displays all output programs across all transport streams on all ports (GigE and ASI) that are currently enabled for the selected zone. Through this window you can enable or disable Messaging Service operation for one or all programs in a zone.

There are two ways to view programs associated with Messaging System zones:

- 1. From the **Configuration -> Messaging System -> Messaging Zones** or **Logo Overlay Zones** menu, highlight the desired zone, right-click, and select **Show Program List** from the pop-up window (Figure 76).




Figure 76. Show Program List Pop-up windows

Or:

2. Click on the **Show Program List** button from either the **Modify Messaging Zone** window (Figure 59, Figure 64, Figure 67) or the **Modify Logo Overlay Zone** windows (Figure 74).

The **Show Program List** window for the selected zone will open.




Figure 77. Show Program List window

The **Show Program List** window will display all transport streams that have programs configured for the specific Messaging zone. To view the specific programs and whether or not they are enabled for

Messaging Services, you must drill down to the program level in the window by clicking the + icon next to each listed transport stream.




Figure 78. Show Program List window - drill down

Show Program List Options

- Enable or Disable specific programs for messaging: Highlight, then right-click on desired program and choose either **Enable** or **Disable** from the pop-up menu (Figure 78) or click the **Enable** or **Disable** button at the bottom of the window (Figure 79).




Figure 79. Show Program List pop-up menu

- Enable or Disable all configured programs for messaging: Click the **Enable All** or **Disable All** button at the bottom of the window (Figure 78).
- View Messaging status: View which programs under a specific transport stream are configured only or configured and enabled for messaging by identifying its associated program icon.
 - An icon with a dark brown line under the green arrow is configured *but not* enabled for messaging.

- An icon with a pink line under the green arrow is configured *and* enabled for messaging.




Figure 80. Messaging Zone Icons

- **Refresh Program list:** Click the **Refresh** button at the bottom of the **Show Program List** window (Figure 77 on page 101).
- **Scroll-over Program Status:** Scroll over the program name with your mouse to view its current status.




Figure 81. Scroll-over program status

Creating Messaging Zone Transport Streams and Output Programs

To create a transport stream or output program to use a Messaging Zone, see “[Creating MPEG-2 Output Transport Streams](#)” on page 131 and “[Creating Programs](#)” on page 151.

SNMP Configuration

The SNMP (Simple Network Management Protocol) tab lets you set the IP addresses for the SNMP traps. These traps then issue event notifications to the network management station. SNMP is the network management protocol used in TCP/IP networks. You can use SNMP to monitor and control network devices as well as manage configurations and collect statistics. You can change the SNMP information at any time.

You can configure an SNMP trap agent or an SNMP community string.

Configuring an SNMP Trap Agent

Configure an SNMP agent to send traps to an SNMP manager to report significant events. Use either an in-band or an out-of-band IP interface to manage the system with SNMP. To configure SNMP for system management with SNMP, assign an IP address to an in-band Ethernet port, then set the destination IP address to which the traps are forwarded by the system agent.

1. From the *Element Manager*, select **Configuration -> SNMP Trap**. The **SNMP Configuration** window appears.




Figure 82. SNMP configuration window

2. Enter the IP address for each SNMP trap desired: up to eight addresses can be specified. This indicates up to eight ports.
3. Click **Apply Configuration** to save your configuration.

Changing a Community String

SNMP community strings control read and write access to BNP configuration. To *read* the BNP's configuration, an SNMP Network Manager must provide a community string that matches the BNP's **Read Community String**. To *change* the BNP's configuration, the SNMP Network Manager must provide a string that matches the BNP's **Write Community String**.

To change an SNMP community string:

1. From the *Element Manager*, select **Maintenance -> Change SNMP Community String**.




Figure 83. Modifying an SNMP Community String

2. Change either or both the **Read** and **Write** strings to the desired values (as shown above in Figure 83).
3. Click **OK**.

The BNP will prompt for a reboot:




Figure 84. SNMP reboot prompt

4. After the system reboots, log in to the *Element Manager* as described in “[Logging In](#)” on page 34.

Note: You will not be able to change the **SNMP Community String** at this point. You will need to log in as normal and allow the system to produce an error, thus prompting for new SNMP Community String entries.

5. After clicking the **Log in** button, the BNP will timeout and produce the following message:




Figure 85. BNP unreachable message - SNMP

6. Click **OK**.

The following **Log in** screen will appear, with prompts for new **SNMP Community Read** and **Write** strings:


The image shows a screenshot of the 'BNP Element Manager' window. The title bar says 'BNP Element Manager'. The main window has a blue background with the 'rgb NETWORKS' logo in the top right. The title 'Log in' is in the top left. There are four input fields: 'IP Address or Host Name:' with the value '10.32.128.170', 'User:' with a dropdown menu showing 'Administrator', 'Password:' with a masked field of six dots, and two empty fields for 'SNMP Read Community String:' and 'SNMP Write Community String:'. At the bottom right are two buttons: 'Log in' (green) and 'Cancel' (grey).

Figure 86. Log in - prompt for new SNMP strings

7. Enter the new **Read** and/or **Write** community strings to match the entries you changed in [Step 2](#) above.


The image shows the same 'BNP Element Manager' window as Figure 86, but now the 'SNMP Read Community String:' field contains the text 'snmpread' and the 'SNMP Write Community String:' field contains the text 'snmpwrite'. All other fields and buttons remain the same.

Figure 87. Log in - new SNMP strings entered

8. Click the **Log in** button.

The BNP will log you in as normal.



Note: You will need to log in as described above for any workstation that is accessing the Element Manager for the first time after the **SNMP Read / Write Community Strings** have been changed.

Upgrading Software

To upgrade to the latest BNP software, download the software from an FTP server and use the BNP *Element Manager* upgrade feature to perform the upgrade. You will receive the specific information about the upgrade software when you purchase an upgrade, or when you are notified that an upgrade is available. Upgrade support software includes upgrades for both active and standby units in a redundant system.



Note: Please contact RGB Networks' customer support for assistance in performing a software downgrade process.

To Upgrade Software in a Single Chassis Environment

1. From the main *Element Manager* menu, select **Maintenance -> Software Upgrade**.

The **Upgrade Software** dialog appears.

Upgrade Software

FTP Host: 192.168.12.1

User Name: ftpuser

Password: ftppass

Directory and File Name: /pub/coyote/release_1_2/sys.tgz
(i.e. /pub/coyote/release_1_2/sys.tgz)

☒ Reboot chassis after successful software upgrade

Upgrade Log:

Upgrade 10.32.97.97 starting...
Getting ftp://ftpuser:ftppass@192.168.12.1/pub/coyote/release_1_2

Time: 01:13 **Upgrade** Cancel

Figure 88. Upgrade Software dialog

2. Enter the information required to perform the upgrade as described in [Table 25](#):

Table 25. Upgrade Software Configuration Fields

Field	Description
FTP Host	Enter the IP address of the FTP server on which the upgrade software package resides.
User Name	Enter the user name needed to access the FTP server.
Password	Enter the password for the user name provided above.
Path	Enter the directory and file name for the upgrade software.
Reboot chassis after successful software upgrade	To reboot the chassis automatically, enable this feature; otherwise, you will have to reboot the chassis manually.

3. Click the **Upgrade button** to begin the upgrade procedure.

As the software is upgraded, you will see information appear in the **Upgrade Log** portion of the dialog. This helps you follow the upgrade progression.

4. After the upgrade is complete and the status shows 100%, the upgrade is installed.
5. If you chose not to auto reboot, manually reboot the system as described in [“Rebooting the System” on page 116](#).

To Upgrade Software in a Redundant Chassis Environment

The steps for upgrading software in a redundant chassis environment are slightly different than in a single chassis scenario. Follow the steps below if you have an active and standby chassis you wish to upgrade (Figure 89 shows the **Software Upgrade** menu you will see with a redundant chassis):

Figure 89. Software Upgrade - Redundant chassis

1 Upgrade the Active chassis first

1. From the **Maintenance -> Software Upgrade** menu, enter the **FTP Host**, **User Name**, **Password**, **Directory** and **File Name**.
2. Select the **Both Active and Standby** radio button.
3. *Uncheck* the **Reboot chassis after successful software upgrade** option.
4. Click the **Upgrade** button at the bottom of the screen.

2 Shutdown the Standby, then Active chassis next

1. Log into the Standby's *Element Manager* via its **Virtual IP** address and use the **Maintenance -> System Shutdown** menu to shutdown the system.
2. Log into the Active's *Element Manager* via its **Virtual IP** address and use the **Maintenance -> System Shutdown** menu to shutdown the system.

3 Remove power from the Standby chassis

After shutting down the Standby through the *Element Manager*, wait one minute (or until the Fault LED has stopped blinking) and unplug the power cord from the standby chassis.

4 Power cycle Active, then power on Standby chassis

1. Power cycle the active chassis.
2. Wait until the active chassis is accessible through the GUI and output streams are verified.
3. Replace power to the standby chassis and proceed with boot up.

Clearing the Web Start Cache

Any time that you downgrade software, you must clear the cache from the Java Web Start. Older versions of the *Element Manager* use Web Start when the BNP *Element Manager* is started. This is only needed when you change to a software version lower than the current one.

To clear the Java Web Start cache (on a Windows system):

1. From the Start Menu, select **Settings -> Control Panel -> Java**.

The **Java Control Panel** is launched.




Figure 90. Java control panel

2. From the **Temporary Internet Files** section, click the **Settings** button.

The *Temporary Files Settings* screen appears.

3. Click **Delete Files**.
4. Ensure that the **Application and Applets** and **Trace and Log Files** boxes are checked.
5. Click **OK** to clear the cache and close the screen.

The License Manager

Overview

There are seven types of licenses for the BNP: Grooming with DPI, Grooming, Messaging System, Advanced Overlay, Program with DPI, SPTS, and DVB-CA.

The standard **Grooming with DPI** license enables all product features including grooming, statistical multiplexing, transrating, DPI (ad insertion), PSIP, all redundancy options, Gigabit Ethernet, and SCTE 30 to SCTE 35 conversion.

The **Grooming** license offers all features except DPI, with the option to add support for these features with a DPI license upgrade at a later time.

The **Messaging System** license enables the use of integration with an external digital SCTE 18 EAS server with the option for Operator-defined message alerts. The **Messaging System** license must be used in conjunction with either the **Grooming with DPI** or the **Grooming** non-DPI license.

The **Advanced Overlay** license provides the ability to import external text or graphics for playout, as well as static logo insertion. The **Advanced Overlay** license must be used in conjunction with either the **Grooming with DPI** or the **Grooming** non-DPI license. You will also need a **Messaging System** license for the Advanced Overlay feature to work.

The **Program with DPI** license allows Digital Program Insertion on a per program basis. This license is used in conjunction with the standard Grooming license and the SPTS license which enable grooming, statistical multiplexing, and transrating.

The **SPTS** license allows only a Single Program Transport Stream to be created on the output. Functionality is the same as a standard MUX license, however, the creation of an MPTS on the output is not allowed.

The **DVB-CA** license allows DVB Conditional Access on a per TS / MUX bandwidth basis. This license is available in 4Mbps or 40Mbps increments and is tracked at the TS level.

Functionality

The determination of what type of license is used for a particular transport stream and its bandwidth is made when you configure an output transport stream. A transport stream can only be assigned to a license type after the license has been installed. For more information on configuring various types of

output transport streams, see the relevant sections beginning on [page 131](#) of [Chapter 5](#), "Grooming and PSIP."

BNP licensing is based on the total bandwidth of output multiplexes where each Mux can be MPTS or SPTS.

An associated license allows the creation of as many Mux or programs as will fit in the licensed bandwidth. Example: A 40 Mbps Mux allows a MPTS with programs averaging at around 2.5 Mbps, or 10 CBR SPTS programs at 4 Mbps.

All license keys are tied to the serial number of the compact flash card, which allows flash portability and access to stored configurations.

Purchasing Licenses

The BNP will be shipped with a license key pre-loaded on the system.

To purchase an upgrade license, submit your request and PO to your reseller or to RGB if you purchased the product directly. Your request will then be processed and a new license key will be sent to you.

Please include the serial number of your compact flash card and the current number of licenses you have for that particular system. RGB will issue a new license key that will be for the total number of licenses for that system. For example, if you currently have a 4-Mux license (160 Mbps) for a single BNP and you are ordering two more licenses for this system, RGB will issue a new license key for 6 Muxes (240 Mbps).

If purchasing licenses for multiple systems, you will need to indicate how many licenses per system with the serial number of the compact flash of each system clearly indicated. RGB will then issue separate license keys for each system.

Activating a License Key

Once you have received the license key, activate the license as follows:

1. From the main *Element Manager* menu, select **Maintenance -> License Manager**.
2. Verify that the current information shown is correct.
3. In the **New License Key** field, enter the license key ([Figure 91](#)).



Note: *There is only one field in which to input a license key; this field is applicable to all types of licenses.*




Figure 91. The License Manager

4. Click **Apply New License**.



Note: Adding a Messaging System, Advanced Overlay, or DVB-CA license key also requires a reboot to take effect.

The new license is applied, and the updated information now appears in the **License Manager**.

Figure 91 shows the currently installed license key and Compact Flash ID (serial number).

Hardware Capacity Status

The License Manager also shows hardware capacity information—i.e. the maximum number of licenses and bandwidth that the system can currently support based on the hardware installed. There are three fields of information that display the bandwidth status for hardware capacity: Total Installed, Available License, and Used License.

Total Installed shows the number of licenses residing in the compact flash and the resulting potential bandwidth available in each license category. This number of licenses may exceed your current hardware capability.

Available License will be based on either the installed licensed bandwidth or hardware capacity bandwidth, whichever is less. This means that Used Bandwidth + Available Bandwidth will equal either the Total Installed licensed bandwidth or the Hardware Capacity depending on which one is lower.

Used License indicates the bandwidth actually in operation.

Flash Portability

One of the advantages of the BNP's licensing structure is flash portability. In the unlikely case that your system suffers a catastrophic failure and you need to replace the hardware, remove the compact flash from the old BNP chassis and install it into the new hardware. The new system should now operate just like the old system as long as the hardware in the new system can support the same configuration. So, if the failed system had two processor cards with two ASI cards, your new system would need to have the same hardware to support the same configuration.

Regrooming

Regrooming lets you reset all of the programs that are currently configured in Program Redundancy to their Active Programs. Once initiated, the command will check to see that the active program has been restored. If the active program has not been restored, no change will occur to the current state of the program.

The Regrooming feature resets all programs with a properly detected primary program available. This feature cannot be used to regroom a selected stream.

To reset all of the grooming to the active chassis:

1. From the main *Element Manager* menu, select **Maintenance -> Regroom**.
2. You are prompted to confirm that you want to reset the grooming. Click **Apply regroom**.






Figure 92. Apply regrooming

Stopping All Services

A system shutdown will stop all video services on the BNP. You perform a system shutdown as a means of gracefully stopping all video services prior to a power cycle of the system. If you have chassis-level redundancy configured and you are stopping all services on the active BNP, the standby BNP will become active.

-  **Note:** *The only way to restart video services following a system shutdown is to manually power cycle the chassis by removing and reinserting the power cord.*
-  **Note:** *Prior to performing the steps in this section, ensure there is a technician standing by at the physical location of the BNP.*

1. From the main menu, choose **Maintenance -> System Shutdown**.

The **System Shutdown** confirmation (Figure 93) appears.




Figure 93. System Shutdown confirmation dialog

2. Click **Yes** to stop all video services, or **No** to cancel the process and leave all services running.

The **Password Verification** prompt (Figure 94) appears.





Figure 94. Password Verification prompt

3. Enter the appropriate password according to your login level.

-  **Note:** *If you have Administrator privileges, enter your administrator password. If you have Operator privileges, enter that password. Only Administrators and Operators may shut down the system.*

4. Click **OK** to stop all services.

It will take several seconds for the BNP video services to halt. An indication that the services have stopped will be either a *solid* green or *off* Fault LED.

5. Remove the power cord (or both cords in the case of power supply redundancy) from the power connector(s) on the rear of the chassis.

6. Wait until the power supply LEDs are off.
7. Reinsert the power cord (or both cords in the case of redundancy) into the connector(s) on the rear of the chassis.

The BNP will proceed through its normal boot up process.

Rebooting the System

Any time you load a new software image, you must reboot the system. When a power cycle or reboot is performed, the BNP will retain previously saved configuration settings. Only the parameters of newly introduced features need to be set when the system is upgraded and rebooted.

The BNP is rebooted using a power cycle or using the *BNP Element Manager*.

The BNP does not have a power switch. To power the unit down, disconnect the power cable from the connector as described in [“Replacing a Power Supply” on page 284](#). To reboot the switch from the *BNP Element Manager*:

1. From the main menu, select **Maintenance -> Reboot**.
2. At the prompt, enter your password ([Figure 95](#)).




Figure 95. Password Verification prompt

Note: *If you have Administrator privilege, enter your administrator password. If you have Operator privilege, enter that password. Only Administrators and Operators may reboot the system.*

3. Click **OK** to proceed with the reboot.

4. The reboot confirmation screen appears, as shown in Figure 96.




Figure 96. Reboot dialog

5. Click **Yes**.
6. To reboot other units, select the unit and repeat the procedure.

Checking for the BNP *Element Manager* Version

To determine the currently installed version of the BNP *Element Manager*, from the main menu select **Help -> About**.



Figure 97. About BNP dialog

Grooming and PSIP

This chapter describes how to perform grooming and Program and System Information Protocol (PSIP) tasks on the BNP3xr using the BNP *Element Manager*.

In This Chapter:

- “Before You Begin,” next.
- “Using the Mapping Tab” on page 120.
- “Creating Input Transport Streams” on page 127.
- “Managing Input Transport Streams” on page 129.
- “Creating MPEG-2 Output Transport Streams” on page 131.
- “Advanced Transport Stream Settings” on page 135.
- “Creating ATSC Output Transport Streams” on page 137.
- “Creating SCTE Output Transport Streams” on page 141.
- “Creating DVB Output Transport Streams” on page 142.
- “Creating a FAT ASI Port Output Transport Stream” on page 148.
- “Creating Programs” on page 151.
- “Modifying and Deleting Streams or Programs” on page 156.
- “Drag and Drop Grooming” on page 163.
- “Program Redundancy” on page 175.
- “Elementary Streams” on page 179.
- “Elementary Stream Ghost PID Management” on page 193.
- “Managing PMT and ES Descriptors” on page 203.
- “Monitoring Bitrates” on page 208.

Before You Begin

Before you begin performing grooming tasks, complete the general configuration described in Chapter 4, “System Configuration”.

Overview

The *Element Manager*’s **Grooming** tab has three subtabs from which you can perform mapping and view bit rates. The tabs are: **Mapping**, **Input Bitrate Monitor**, and **Input-Output Bitrate Monitor**. This chapter focuses on the functions in these subtabs.

Using the Mapping Tab

The **Grooming -> Mapping** subtab allows you to:

- Create both input and output transport streams. See “[Creating Input Transport Streams](#)” on page 127.
- Create an output program. See “[Creating Output Programs Manually](#)” on page 151.
- Perform drag and drop grooming on individual programs or full transport streams. See “[Drag and Drop Grooming](#)” on page 163.
- Set your program schedule. See “[Scheduling Grooming - One time event](#)” on page 174.

To perform the procedures above, from the *Element Manager*, select **Grooming -> Mapping**. The **Mapping** subtab window appears ([Figure 98](#)), displaying existing transport streams, program names, and elementary streams for input on each appropriate port.

Output information appears only after there is output content. This can be achieved by either creating an output transport stream or program, or by dragging and dropping input transport streams or programs to the output.

All GigE ports are shown in the **Inputs** (left) portion of the window. Active ports are shown with a green icon, and inactive ports are shown with a gray icon. These are the ports that you configured in the configuration portion of the BNP as described in “[GigE Port Configuration](#)” on page 53.

You create transport streams which are then picked up and put into the grooming window.




Figure 98. Grooming-Mapping configuration

Expand or collapse each “container” object (transport stream or program) by either double-clicking the object or clicking the plus or minus sign to the left of the object name.

Each input transport stream has associated PSIP information where appropriate. Other types of transport streams may show similar information.

Programs appear under the transport stream in which they arrive (or to which they are outputted), and the elementary streams appear under the program. Each transport stream has an associated set of programs and PSIP tables. Each program includes video, audio, and PSIP tables.

Viewing Program-Level Input Source

To view the input source of an output program, proceed as follows:

1. Right-click the desired program on the **Outputs** (right-hand) side of the screen (Figure 99).
2. From the pop-up box, select **View Grooming Source**.
3. Observe the highlighted grooming source from the Inputs (left-hand) side of the screen (Figure 99).




Figure 99. Viewing program-level input source

Viewing ES-Level Input Source

To view the input source of an Elementary Stream (ES), proceed as follows:

1. Expand the desired program whose ES you wish to view on the **Outputs** (right-hand) side of the screen (Figure 100).
2. Right-click the desired ES under the program on the **Outputs** (right-hand) side of the screen (Figure 100).
3. From the pop-up box, select **View Grooming Source**.
4. Observe the highlighted grooming source from the Inputs (left-hand) side of the screen (Figure 100).











Figure 100. Viewing ES-level input source

Interpreting the Program Status Icons

All programs on both the **Inputs** and **Outputs** sides have program status icons associated with them, which appear directly to the left of the word **Program**. These icons represent the program source.

Table 26 shows the name of each icon.







Table 26. Program Status Icons

Symbol	Name
	Network Program
	Messaging Services Configured, Program Disabled
	Messaging Services Configured and Program Enabled
	Digital Program Insertion (DPI)
	Messaging Services Configured with DPI
	Encrypted Program
	Inactive

Interpreting Elementary Stream Status Icons

All Elementary Streams (ESs) on both the **Inputs** and **Outputs** sides have ES status icons associated with them, which appear directly under the program when the view is expanded. [Table 26](#) shows the name of each icon.

Table 27. Elementary Stream Icons

Symbol	ES Type	Stream Type	Description
	Video	MPEG2 2 (0x2) H.264 27 (0x1b) SCTE 128 (0x80)	Represents the presence of a video elementary stream on an input or output program.
	Audio	MPEG1 MPEG2 AC-3 (0x06) AC-3 (0x81) AAC (0x0f) HE-AAC (0x11)	Represents the presence of an audio elementary stream on an input or output programs. Available audio options are: None Arabic English French German Hindi Italian Japanese Mandarin Chinese Portuguese Russian Spanish
	Data	5 6 Teletext 6 Sub Title 7 – 191 192 193-255	Represents the presence of a data elementary stream with all stream types <i>except</i> : 5 EBIF 5 EISS 192 EBIF 192 EISS A blue data stream icon can be displayed on either an input or an output program.
	Data	5 EBIF 5 EISS 192 EBIF 192 EISS	Represents the presence of an EBIF or EISS data elementary stream. A blue data stream icon can be displayed on either an input or an output program.
	Data	5 6 Teletext 6 Sub Title 7 – 191 192 193-255	Represents the presence of an ES-level groomed data stream with all data stream types <i>except</i> : 5 EBIF 5 EISS 192 EBIF 192 EISS A green data stream icon can only be displayed on an output program.
	Data	5 EBIF 5 EISS 192 EBIF 192 EISS	Represents the presence of an ES-level groomed EBIF or EISS data stream. A green data stream icon can only be displayed on an output program.

Expanding and Collapsing Mapping

You can expand and collapse the mapping views. Expanding and collapsing only affect the display; they do not change the underlying grooming.

Figure 101 shows an example of existing mapping.




Figure 101. Existing Mapping

To collapse mapping, select **View -> Collapse Mapping** (Figure 102).




Figure 102. Collapse Mapping

To restore the expanded mapping view, choose **View -> Expand Mapping**. The expanded screen of Figure 101 is restored.

Creating Input Transport Streams

The information required to create a transport stream (TS) depends on whether you are creating a transport stream on an input port or an output port, and on the type of TS created. Each TS creation dialog is described here.

Basic Input Transport Stream Creation

To create a new input transport stream:

1. From the **Inputs** side of the **Grooming -> Mapping** subtab, choose the input port on which you want to create the transport stream and right-click.
2. From the pop-up menu that appears select **Create Transport Stream**.
3. Enter the information about the new input transport stream.

Figure 103. Create GigE Input TS

Table 28 describes the fields available in the **Create Input Transport Stream** window.

Table 28. Input Transport Stream Creation

Input Transport Stream	Description
GigE Port	This is the read-only port ID, and is based on the selected GigE port (GigE 1, GigE 2, etc.)
TS Name	Enter the desired name of the transport stream.
Multicast	If this is a multicast stream, check this box to enable multicast.

Table 28. Input Transport Stream Creation

Input Transport Stream	Description
IP Address	The unicast or multicast IP address on which the stream is received.
UDP Port	Enter the UDP port to use for transmitting data.
Source IP Address	The IP address of the source from which the stream is originating; the source IP address is optional and should only be included for IGMPv3/SSM transport streams.
Multiple TS	Click this button if you are creating multiple transport streams. You can create incrementing IP addresses, incrementing UDP ports, or incrementing IP Addresses and UDP ports simultaneously. See the following paragraphs for details.

Multiple IP and UDP Creation

If you have chosen to create multiple transport streams, clicking **Multiple TS** opens the **Select Multiple IP and UDP** dialog.




Figure 104. Selecting multiple UDP/IP ports

Table 29. Selecting Multiple IP and UDP

Field	Description
Start IP Address	A read-only field indicating the starting IP address.
End IP Address	A read-only field indicating the ending IP address.
Start UDP	A read-only field indicating the starting UDP port number.
End UDP	A read-only field indicating the ending UDP port number.
Increment IP Address	When checked, the starting IP address will be incremented by one for each multiple chosen.
Increment UDP	When chosen, the UDP port number will be incremented by one for each multiple chosen.
Increment both IP Address and UDP	When checked both the IP address and UDP port number will be incremented by one for each multiple chosen.
Multiple Number	The number of multiple creations, either or both, IPs or UDPs.
Excluded UDP Ports	UDP ports that you want excluded from any automatic numbering.

1. Choose to increment only the IP address, UDP port, or both simultaneously.
2. Enter the number of multiple creations desired.
3. If you have chosen either UDP or Both, enter any UDP ports to exclude, separated by commas.
4. Click **OK** to apply the selections and return to the creation window.

Figure 105 shows transport streams configured under a GigE input port:




Figure 105. Input Transport Streams created

- Note:** Each TSID is a unique number used to identify a transport stream. It is a partition of two 16-bit hex numbers. The lower 16 bits is the MPEG transport stream ID. The upper 16 bits (0x) is used strictly internally.
- Note:** There are no configuration parameters required for creating a transport stream on an input ASI port. Each input ASI port is automatically configured with one transport stream.

Managing Input Transport Streams

After an input transport stream has been created, various options are available for managing the stream. The options are slightly different based on whether or not you have selected a GigE port transport stream or an ASI port transport stream.

GigE Port Transport Stream Options

To view available options for a GigE port, proceed as follows:

1. From the **Inputs** side of the **Grooming -> Mapping** window, select a desired transport stream under a GigE port.
2. Right-click on the transport stream.

3. A pop-up menu will appear as follows:




Figure 106. Input Transport Stream pop-up menu - GigE

Table 30 describes the options available from the pop-up menu.

ASI Port Transport Stream Options

To view available options for an ASI port, proceed as follows:

1. From the **Inputs** side of the **Grooming -> Mapping** window, select a desired transport stream under an ASI port.
2. Right-click on the transport stream.
3. The following pop-up menu will appear:




Figure 107. Input Transport Stream pop-up menu - ASI

Table 30 describes the options available from the pop-up menu.

Table 30. Input Transport Stream pop-up menu options

Menu	Description
Modify Transport Stream	Allows you to modify only the name of the transport stream. If you wish to modify any other parameter, you must delete the transport stream and create it again.
Refresh Transport Stream Tables	When this option is selected, the internal Program Association Table (PAT) for this transport stream is invalidated, and the next incoming PAT will be used for the associated PSIP and DVB tables for selected transport stream.

Table 30. Input Transport Stream pop-up menu options

Menu	Description
Delete Transport Stream (GigE only)	Deletes the transport stream and all grooming for associated output programs. • Option available for GigE port transport streams only
Recreate Input Transport Stream (ASI only)	Deletes the transport stream, all grooming for associated output programs, and recreates the transport stream with no associated grooming. • Option available for ASI port transport streams only
Create Ghost Program	Used for created programs with unreferenced PIDs. See “Adding an Unreferenced PID as an Elementary Stream” on page 190 for details.
Bitrate Monitor	Allows you to monitor bitrates for the selected transport stream.

Creating MPEG-2 Output Transport Streams

To create a new MPEG-2 output transport stream:

1. From the **Outputs** side of the **Grooming -> Mapping** subtab, choose the output port on which you wish to create the transport stream and right-click.
2. From the pop-up menu that appears select **Create Transport Stream**.
The screen will be different if the output port is an ASI ([Figure 108](#)) or a GigE port ([Figure 109](#)).
3. From the **TS Type** pull down menu, select MPEG-2.
4. Fill out the remaining fields of the dialog according to the parameters listed in [Table 31](#) or [Table 32](#), depending on which port is in use.
5. Click **OK** to save changes and create the transport stream.

The stream now appears in the **Grooming -> Mapping** window and can be assigned programs.

ASI Port MPEG-2 Transport Streams

Figure 108 shows the **Create Output Transport Stream** window for an ASI port.

Figure 108. Creating output TS (MPEG-2, ASI port)

Table 31. MPEG-2 Output Transport Stream Creation (ASI Port)

Field	Description
Port	Read-only, shows either ASI or GigE depending on the port selected.
SPTS	Check if the output is a single program transport stream (SPTS).
Non-DPI	Check this box if the transport stream is to use a Grooming-only (Non-DPI) license.
TS Name	The (optional) name you want to assign to this output transport stream.
Bitrate (Mbps)	The bitrate at which the stream is transported.
Unique TS ID	<p>Allows you to assign a unique numeric ID to this transport stream.</p> <ul style="list-style-type: none"> When this option is <i>checked</i>, the TS ID value placed in this field will be reserved as unique for the entire chassis. When this option is <i>unchecked</i>, a TS ID value may still be entered, however the value may be the same as another TS ID as long as that TS ID's value has not been reserved as a Unique TS ID. Note that each TSID is a unique number used to identify a transport stream. It is a partition of two 16-bit hex numbers. The lower 16 bits (user-specified in decimal and converted to hex) is the MPEG transport stream ID. The upper 16 bits (0x) is strictly used internally. Default value is "1" if no value is specified. Broadcasters must configure this value with a unique ID to meet FCC standards.
Reserved Bandwidth	Enter any bandwidth value to be reserved from the total bitrate of transport stream.
Network PID	The program ID on which network information is received.
TS Type	<p>The type of stream. The type of stream you choose determines what other information is required. Choices are:</p> <p><i>MPEG-2, ATSC, SCTE, or DVB</i></p>

Table 31. MPEG-2 Output Transport Stream Creation (ASI Port)

Field	Description
Enable Messaging System	Check this box to allow configuration of Messaging System zones for specific programs in this transport stream. See “Messaging System Configuration” on page 69 for information on configuring Messaging Zones.
Advanced Setting	Clicking this button will open a new menu that allows you to configure advanced settings for the selected transport stream. See “Advanced Transport Stream Settings” on page 135.

GigE Port MPEG-2 Transport Streams

Figure 109 shows the window for a GigE port.

Figure 109. Creating output TS (MPEG-2) - GigE port

Table 32 describes the parameters fields available in the MPEG-2 **Create Output Transport Stream** dialog.

Table 32. MPEG-2 Output Transport Stream Creation (MPEG-2, GigE Port)

Field	Description
Port	This is read-only and is used for identification purposes.
SPTS	Check if the output is a single program transport stream (SPTS).
Non-DPI	Check this box if the transport stream is to use a Grooming-only (Non-DPI) license.
Multicast	Check if the output is for multicast operation.
Bitrate (Mbps)	The bitrate at which the stream is transported.
Destination IP	The IP address to which the output stream is routed. <ul style="list-style-type: none"> • If <i>Multicast</i> is checked, this must be a valid multicast IP address. • If <i>Multicast</i> is unchecked, this must be a valid unicast IP address.
Reserved Bandwidth (Mbps)	Enter any bandwidth value to be reserved from the total bitrate of transport stream.

Table 32. MPEG-2 Output Transport Stream Creation (MPEG-2, GigE Port) (Continued)

Field	Description
UDP Port	Enter the UDP port to use for transmitting data.
TS Name	The (optional) name you want to assign to this output transport stream.
Subnet Mask	If <i>Multicast</i> is unchecked, enter the subnet mask IP for the unicast IP address entered in the <i>Destination IP</i> field.
Unique TS ID	<p>Allows you to assign a unique numeric ID to this transport stream.</p> <ul style="list-style-type: none"> When this option is <i>checked</i>, the TS ID value placed in this field will be reserved as unique for the entire chassis. When this option is <i>unchecked</i>, a TS ID value may still be entered, however the value may be the same as another TS ID as long as that TS ID's value has not been reserved as a Unique TS ID. Note that each TSID is a unique number used to identify a transport stream. It is a partition of two 16-bit hex numbers. The lower 16 bits (user-specified in decimal and converted to hex) is the MPEG transport stream ID. The upper 16 bits (0x) is strictly used internally. Default value is "1" if no value is specified. Broadcasters must configure this value with a unique ID to meet FCC standards.
ARP	<p>If Multicast is checked, this field is <i>hidden</i>.</p> <p>If Multicast is unchecked, this box will appear. Unchecking this box will allow you to disable the use of Address Resolution Protocol (ARP) and to manually specify a MAC address. See Figure 110.</p>
Network PID	The program ID of transport stream packets which contain the network information table.
MAC Address	<p>If <i>Multicast</i> or <i>ARP</i> are checked, this field is read-only.</p> <p>If <i>Multicast</i> and <i>ARP</i> are unchecked, this field can be modified to include a hardcoded MAC address to be used to transport this stream. See Figure 110.</p>
TS Type	<p>The type of stream. The type of stream you choose determines what other information is required. Choices are:</p> <p><i>MPEG-2, ATSC, SCTE, or DVB.</i></p>
Multiple TS	Click if multiple transport streams are used. See "Multiple IP and UDP Creation" on page 128 for details.
Enable Messaging System	Check this box to allow configuration of Messaging System zones for specific programs in this transport stream. See "Messaging System Configuration" on page 69 for information on configuring Messaging Zones.
Advanced Setting	Clicking this button will open a new menu that allows you to configure advanced settings for the selected transport stream. See "Advanced Transport Stream Settings" on page 135 .

Hidden Fields in Create Output Transport Stream Menu (GigE)

The **Create Output Transport Stream** menu hides the **ARP** field when the **Multicast** box is checked. Figure 110 shows an example of the **ARP** field (checked and unchecked) as described in Table 32.

The figure consists of two screenshots of the 'Create Output Transport Stream' dialog box. The top screenshot shows the 'ARP' checkbox checked, and the bottom screenshot shows it unchecked. Both screenshots show the same configuration for other fields: Port: GigE 2, Multicast unchecked, Bitrate: 38.0, Reserved B/W: 0.0, TS Name: empty, Subnet Mask: 255.255.255.0, Unique TS ID: 1, Network PID: 16, TS Type: MPEG-2, and MAC Address: empty. The 'Advanced Setting' button is visible at the bottom of both windows.

Figure 110. Create Output TS - ARP field

Advanced Transport Stream Settings

The **Advanced Setting** button from the **Create Transport Stream** menu provides the following additional configuration options when creating an output transport stream:

SPTS Advanced Options

Note: These options only apply when configuring a single program transport stream (SPTS) from the **Create Transport Stream** window (Figure 108 or Figure 109)

SPTS MPEG-2 Advance Rate Control

This is an MPEG-2 transrating setting for SPTS output transport streams that require more aggressive rate control due to severe oscillations from the input bitrate.

To enable MPEG-2 Advance Rate Control, proceed as follows:

1. From the **Create Transport Stream** menu, click the **Advanced Setting** button.

The **Advanced Transport Stream Setting** window of Figure 111 is displayed.




Figure 111. Advanced Transport Stream - SPTS

2. Check the box next to **MPEG-2 Advance Rate Control**.
3. Click **OK**.

MPTS Advanced Options



Note: These options only apply when configuring multiple program transport streams (MPTSs) from the **Create Transport Stream** window (Figure 108 or Figure 109)

H.264 Alarm Bitrate Level

This setting can assist in maintaining video quality for MPEG-2 video content in the presence of other content, such as H.264, which bypasses the BNP's transrater. This is done by generating an alarm when H.264 program bandwidth exceeds the percent of the TS bandwidth specified in this setting.

To set the H.264 Alarm Bitrate Level, proceed as follows:

1. From the **Create Transport Stream** menu, ensure the SPTS option is not checked.

2. Click the **Advanced Setting** button.

The **Advanced Transport Stream Setting** window of Figure 112 is displayed.




Figure 112. Advance Transport Stream Setting - MPTS

3. Enter a percent of the transport stream's aggregate bandwidth at which an alarm should be generated. Choices are: 0%, 25%, 50%, 75%, 100%.
4. Click **OK**.

Table 33 provides a summary of the **Advanced Transport Stream Setting** window parameters.

Table 33. Advanced Transport Stream Settings

Field	Description
SPTS: MPEG-2 Advance Rate Control	When checked, the output SPTS is aggressively rate controlled.
MPTS: H.264 Alarm Bitrate Level (Mbps)	Specify the percent at which an alarm will be issued when H.264 program bandwidth of the MPTS TS exceeds this level. By default this rate is set to 50% of the aggregate rate of the entire transport stream.

Creating ATSC Output Transport Streams

If the selected output transport stream is an ATSC type, additional information is necessary. The upper portion of the dialog is the same as that of the MPEG-2 type and are described in Table 31 for an ASI port and Table 32 for a GigE port.

To create a new ATSC output transport stream:

1. From the **Outputs** side of the **Grooming** -> **Mapping** subtab, choose the output port on which you want to create the transport stream and right-click.
2. From the pop-up menu that appears select **Create Transport Stream**.

The screen will be different if the output port is an ASI or a GigE port.

3. From the **TS Type** pull down menu, select ATSC.

The lower portion of both ASI and GigE port screens is used to define the PSIP tables. PSIP tables are described in [Table 34](#).

4. Fill out the remaining fields of the dialog according to the parameters listed in [Table 31](#) or [Table 32](#), depending on which port is in use.
5. Click **OK** to save changes and create the transport stream.

The stream now appears in the **Grooming -> Mapping** window and can be assigned programs.

Figure 113 shows the window for an ATSC transport stream on an ASI port.

Create Output Transport Stream

Port: ASI B1 ☐ SPTS ☐ Non-DPI

TS Name: Bitrate (Mbps): 38.0

☐ Unique TS ID: 1 Reserved B/W (Mbps): 0.0

Network PID: 8175 TS Type: ATSC

☐ Enable Messaging System

EIT PID	EIT Interval(ms)
EIT 0: 7936	EIT 0: 400
EIT 1: 7937	EIT 1: 2400
EIT 2: 7938	EIT 2: 48000
EIT 3: 7939	EIT 3: 48000

MGT Interval(ms): 120 Modulation Mode: SCTE 256 QAM

☐ Generate TVCT CVCT/TVCT Interval(ms): 320

STT Source:

EIT Source: Groomed Input

RRT Source:

Advanced Setting OK Cancel

Figure 113. Create Output TS (ATSC) - ASI Port

Figure 114 shows the window for an ATSC transport stream on a GigE port.




Figure 114. Creating output TS (ATSC) - GigE Port

Table 34 provides a description of the additional PSIP fields in the bottom portion of the **Create Output Transport Stream** window for an ATSC stream on either an ASI or GigE port.

Table 34. ATSC TS Creation: PSIP Table Information Configuration Parameters

PSIP Table Information ^a	Description
For an ASI port, all fields in the top portion of the <i>Create Output Transport Stream</i> window are the same as described in Table 31.	
For a GigE port, all fields in the top portion of the <i>Create Output Transport Stream</i> window are the same as described in Table 32.	
For ATSC transport types, you must include the information about PSIP tables. The PID values of major and minor channels are automatically numbered across the multiplex, reducing the chance of conflict.	
EIT PID (0-3)	The Event Information Table (EIT) packet identifier (PID) values can be set manually, overriding the PID in the MGT.
EIT PID Interval(ms)	This value can be set manually, overriding the PID in the MGT. Value in milliseconds.

Table 34. ATSC TS Creation: PSIP Table Information Configuration Parameters (Continued)

PSIP Table Information ^a	Description
MGT Interval(ms)	The Master Guide Table (MGT) is highest order in the ATSC transport stream table hierarchy; it also provides program-identification (PID) locations so that receivers can locate other tables; the MGT can also inform the receiver of changes or table updates.
Modulation Mode	Choose one of the following modes from the pull-down menu: Analog, SCTE 64 QAM, SCTE 256 QAM, ATSC 8 VSB, and ATSC 16 VSB.
Generate TVCT	Check this box to generate TVCT tables <i>instead</i> of CVCT tables. A Terrestrial Virtual Channel Table (TVCT) is a mandatory PSIP table for terrestrial broadcast that lists all the virtual channels available in an ATSC transport stream. This feature is required for broadcasted channels. <ul style="list-style-type: none"> When <i>Modulation Mode</i> is set to ATSC 8 VSB or ATSC 16 VSB, you must enable this option.
CVCT/TVCT Interval(ms)	Specifies the interval in milliseconds at which CVCT/TVCT tables are generated. If the <i>Generate TVCT</i> option has been enabled, this field sets the interval for TVCT; if the <i>Generate TVCT</i> option has <i>not</i> been enabled, this field sets the interval for CVCT. The Cable Virtual Channel Table (CVCT) provides information about the channels, such as channel name, navigation identifier, and stream components.
STT Source	The System Time Table (STT) defines the GPS time and the daylight-savings time indicator to the consumer's decoder, synchronizing the concept of "now" between the decoder and the broadcaster. This configuration is not generated by the BNP and requires a proper source to be valid on the output transport. Choose an appropriate value from the pull-down menu. There must be a valid STT source to be ATSC compliant.
EIT Source	Specifies how an EIT table is generated by the BNP. When <i>Groomed Input</i> (default) is selected, an Event Information Table (EIT) is generated based on that which is received from the groomed input program of the ATSC TS. Choose an appropriate value from the pull-down menu.
RRT Source	The Rating Region Table (RRT) source transmits the program rating information Choose an appropriate value from the pull-down menu. There must be a valid RRT source to be ATSC compliant.

- a. PSIP (Program and System Information Protocol) is a collection of tables operating within the terrestrial broadcast Transport Stream (TS) of every digital (and sometimes analog) television. PSIP settings are configured as part of the transport stream.

These tables contain system information and program data:

- System information allows navigation and access of the channels within the DTV transport stream.
- Program data provides necessary information for efficient browsing and event selection.
- Some PSIP tables contain the information to locate digital streams.

If you are not sure of the PSIP guidelines, there are many good references on the Internet, including the *ATSC Recommended Practice: Program and System Information Protocol Implementation Guidelines for Broadcasters* at http://www.atsc.org/cms/standards/a_69-2009.pdf

Creating SCTE Output Transport Streams

If the selected output transport stream is an SCTE type, the configurable parameters are the same as that of the MPEG-2 type and are described in [Table 31](#) for an ASI port and [Table 32](#) for a GigE port.

To create a new SCTE output transport stream:

1. From the **Outputs** side of the **Grooming -> Mapping** subtab, choose the output port on which you want to create the transport stream and right-click.
2. From the pop-up menu that appears select **Create Transport Stream**.
The screen will be different if the output port is a GigE or an ASI port.
3. From the **TS Type** pull down menu, select SCTE.
4. Fill out the remaining fields of the dialog according to the parameters listed in [Table 31 on page 132](#) or [Table 32 on page 133](#), depending on which port is in use.
5. Click **OK** to save changes and create the transport stream.

The stream now appears in the **Grooming -> Mapping** window and can be assigned programs.

Figure 115 shows the window for an SCTE transport stream on an ASI port.

Port:	ASI B5	<input type="checkbox"/> SPTS	<input type="checkbox"/> Non-DPI
TS Name:		Bitrate (Mbps):	38.0
<input checked="" type="checkbox"/> Unique TS ID:	1	Reserved B/W (Mbps):	0.0
Network PID:	8175	TS Type:	SCTE
<input type="checkbox"/> Enable Messaging System			
		Advanced Setting	OK Cancel

Figure 115. Creating output TS (SCTE) - ASI port

Figure 116 shows the window for an SCTE transport stream on a GigE port.

The screenshot shows a window titled "Create Output Transport Stream". The "Port" is set to "GigE 3". There are checkboxes for "SPTS" (unchecked) and "Non-DPI" (unchecked). The "Multicast" checkbox is checked. The "Bitrate (Mbps)" is set to "38.0" and "Reserved B/W (Mbps)" is set to "0.0". The "Destination IP:", "UDP Port:", and "Subnet Mask:" fields are empty. The "TS Name:" field is empty. There is a "Pick TS ID:" checkbox (unchecked). The "Network PID:" is set to "8175". The "TS Type:" dropdown menu is set to "SCTE". There is an "Enable Messaging System" checkbox (unchecked). A "Multiple TS" button is at the bottom right of the main area. At the bottom of the window are "Advanced Setting", "OK", and "Cancel" buttons.

Figure 116. Creating output TS (SCTE) - GigE port

Creating DVB Output Transport Streams

If the selected output transport stream is a DVB type, additional information is necessary. The upper portion of the dialog is the same as that of the MPEG-2 type and are described in [Table 31 on page 132](#) for an ASI port and [Table 32 on page 133](#) for a GigE port.

To create a new DVB output transport stream:

1. From the **Outputs** side of the **Grooming -> Mapping** subtab, choose the output port on which you want to create the transport stream and right-click.

2. From the pop-up menu that appears select **Create Transport Stream**.

The screen will be different if the output port is a GigE or an ASI port.


3. From the **TS Type** pull down menu, select DVB.

The lower portion of both ASI and GigE port screens is used to define additional information relative to Digital Video Broadcast (DVB) and is described in [Table 35 on page 145](#).

4. Fill out the remaining fields of the dialog according to the parameters listed in [Table 31 on page 132](#) or [Table 32 on page 133](#), depending on which port is in use.
5. Click **OK** to save changes and create the transport stream.

The stream now appears in the **Grooming -> Mapping** window and can be assigned programs.

Figure 117 shows the window for a DVB transport stream on an ASI port.




The image shows a software window titled "Create Output Transport Stream". The window has a blue header bar with the title and a close button (X) in the top right corner. The main area is white and contains various input fields and checkboxes. The "Port" is set to "ASI C2". There are checkboxes for "SPTS" and "Non-DPI", both of which are unchecked. The "TS Name" field is empty. The "Bitrate (Mbps)" field is set to "38.0". The "Unique TS ID" checkbox is checked, and the "Unique TS ID" field is set to "1". The "Reserved B/W (Mbps)" field is set to "0.0". The "Network PID" field is set to "16". The "TS Type" dropdown menu is set to "DVB". There is a checkbox for "Enable Messaging System" which is unchecked. The "Network ID" field is set to "160". The "Modulation Mode" dropdown menu is set to "SCTE 256 QAM". The "Original Network ID" field is set to "160". The "MIT Source" dropdown menu is set to "N/A". The "TDT/TOT Source" dropdown menu is set to "N/A". The "SDT Source" dropdown menu is set to "LocalSDT". The "EIT Source" dropdown menu is set to "Groomed Input". At the bottom of the window, there are three buttons: "Advanced Setting", "OK", and "Cancel".

Port:	ASI C2	<input type="checkbox"/> SPTS	<input type="checkbox"/> Non-DPI
TS Name:		Bitrate (Mbps):	38.0
<input checked="" type="checkbox"/> Unique TS ID:	1	Reserved B/W (Mbps):	0.0
Network PID:	16	TS Type:	DVB
<input type="checkbox"/> Enable Messaging System			
Network ID:	160	Modulation Mode:	SCTE 256 QAM
Original Network ID:	160		
MIT Source:	N/A		
TDT/TOT Source:	N/A		
SDT Source:	LocalSDT	EIT Source:	Groomed Input

Advanced Setting OK Cancel

Figure 117. Creating output TS (DVB) - ASI port

Figure 118 shows the window for a DVB transport stream on a GigE port.



The image shows a software window titled "Create Output Transport Stream". The window has a blue header bar with the title. Below the header, there are several sections of controls. The top section includes "Port:" set to "GigE 3", checkboxes for "SPTS" and "Non-DPI" (both unchecked), and a checked "Multicast" checkbox. To the right are input fields for "Bitrate (Mbps):" (38.0) and "Reserved B/W (Mbps):" (0.0). Below these are fields for "Destination IP:", "UDP Port:", and "Subnet Mask:". Further down are "Mac Address:" and "TS Name:" fields. A "Pick TS ID:" checkbox is unchecked. The "Network PID:" field contains "16". The "TS Type:" dropdown is set to "DVB". There is an "Enable Messaging System" checkbox (unchecked) and a "Multiple TS" button. The bottom section contains "Network ID:" (160), "Original Network ID:" (160), "Modulation Mode:" (SCTE 256 QAM), "NIT Source:" (N/A), "TDT/TOT Source:" (N/A), "SDT Source:" (LocalSDT), and "EIT Source:" (Groomed Input). At the bottom right are "Advanced Setting", "OK", and "Cancel" buttons.

Port:	GigE 3	<input type="checkbox"/> SPTS	<input type="checkbox"/> Non-DPI
	<input checked="" type="checkbox"/> Multicast	Bitrate (Mbps):	38.0
Destination IP:		Reserved B/W (Mbps):	0.0
UDP Port:		TS Name:	
Subnet Mask:		<input type="checkbox"/> Pick TS ID:	
Mac Address:		Network PID:	16
		TS Type:	DVB
	<input type="checkbox"/> Enable Messaging System	Multiple TS	
Network ID:	160	Modulation Mode:	SCTE 256 QAM
Original Network ID:	160		
NIT Source:	N/A		
TDT/TOT Source:	N/A		
SDT Source:	LocalSDT	EIT Source:	Groomed Input

Figure 118. Creating output TS (DVB) - GigE port

Table 35 provides a description of the additional fields in the bottom portion of the **Create Output Transport Stream** window for a DVB stream on either an ASI or GigE port.

Table 35. DVB Output Transport Stream Configuration Parameters

Field	Description
For an ASI port, all fields in the top portion of the <i>Create Output Transport Stream</i> window are the same as described in Table 31 on page 132 .	
For a GigE port, all fields in the top portion of the <i>Create Output Transport Stream</i> window are the same as described in Table 32 on page 133 .	
Network ID	Input the Network ID of the current transport stream.
Modulation Mode	Use the pull-down menu to select the modulation mode used for the TS. Choice between <i>SCTE 64 QAM</i> and <i>SCTE 256 QAM</i> .
Original Network ID	Input the Network ID from which this stream has originated.
NIT Source	Use the pull-down menu to select the source for the network information table.
TDT/TOT Source	Use the pull-down menu to select the source for the time and date table or the time offset table.
SDT Source	Source of the service description table for this transport stream. If you select N/A then SDT is not generated for this output TS.
EIT Source	Source of the Event Information Table (EIT) for the programs in this transport stream. If you select N/A then EIT will not be generated.

Setting Up Network Information Tables (NIT) for DVB

You can generate a NIT table using one of three methods:

- Locally generated, using the NIT editor
- NIT pass through, with editing at the output transport stream.
- Complete pass through of NIT from the input to the output transport stream.

This manual describes the first method.

To set up a NIT:

1. From the main *Element Manager* menu, select **Maintenance -> Setup Network Information Table (NIT)**.

2. In the NIT window that appears, click **Add** to add a new NIT or **Edit** to edit an existing NIT. The **Setup Network Information Table (NIT)** appears (Figure 119).




Figure 119. Setup Network Information Table screen

3. Highlight an existing table, and choose **Edit**. The window of Figure 120 appears.




Figure 120. Using the Editing Feature

4. Edit the Network Information Table as described in [Appendix A, “Editing the DVB NIT Table”](#).
5. When you are finished editing, click **OK** to apply any changes.
6. To view the NIT as an XML file, click **View NIT in XML** format.
7. To import the NIT from another BNP, click **Import NIT File**.

Creating a FAT ASI Port Output Transport Stream

You can create a FAT ASI port with up to four groups. Proceed as follows:

1. Right click the ASI port on which to create a FAT ASI port (Figure 121).




Figure 121. Choosing a FAT ASI Transport Stream

2. Choose **Create Transport Stream (FAT ASI)**. The window of Figure 122 appears.

Group #	Group Name	Group Bitrate(Mbps)	Reserved B/W(Mbps)
A		38.80	1.80
B		38.80	1.80
C		38.80	1.80
D		38.80	1.80

Figure 122. Create Output Transport Stream (FAT ASI)

3. Enter the value of each parameter as described in [Table 36](#).

Table 36. Creating a FAT ASI Transport Stream

Field	Description
Port	Read-only, shows either ASI or GigE depending on the port selected.
Non-DPI	Check this box if the transport stream is to use a Grooming-only (Non-DPI) license.
TS Name	The (optional) name you want to assign to this output transport stream.
Bitrate (Mbps)	The bitrate at which the stream is transported.
Unique TS ID	<p>Allows you to assign a unique numeric ID to this transport stream.</p> <ul style="list-style-type: none"> When this option is <i>checked</i>, the TS ID value placed in this field will be reserved as unique for the entire chassis. When this option is <i>unchecked</i>, a TS ID value may still be entered, however the value may be the same as another TS ID as long as that TS ID's value has not been reserved as a Unique TS ID. Note that each TSID is a unique number used to identify a transport stream. It is a partition of two 16-bit hex numbers. The lower 16 bits (user-specified in decimal and converted to hex) is the MPEG transport stream ID. The upper 16 bits (0x) is strictly used internally. Default value is "1" if no value is specified. Broadcasters must configure this value with a unique ID to meet FCC standards.
Reserved B/W (Mbps)	Enter any bandwidth value to be apportioned to the transport stream.
Network PID	The program ID on which the stream is received.
TS Type	<p>The type of stream. The type of stream you choose determines what other information is required. Choices are:</p> <p><i>MPEG-2, ATSC, SCTE, or DVB</i></p> <ul style="list-style-type: none"> For information on additional fields for ATSC transport streams, see Table 34. For information on additional fields for DVB transport streams, see Table 35.
Enable Messaging System	Check this box to allow configuration of Messaging System zones for specific programs in this transport stream. See " Messaging System Configuration " on page 69 for information on configuring Messaging Zones.
Number of Group	The number of groups you want to assign to this port. Choose from 1 to 4. The default is 4.
Group Name (A-D)	The name you want to assign to each group.
Group Bitrate(Mbps) (A-D)	The bitrate, in megabits per second, that you want to assign to groups. The value entered will be applied to all Groups. The total bitrate for all groups cannot exceed the value in the <i>Bitrate</i> field in the top portion of the window.
Reserved B/W (Mbps)	The reserved bandwidth you want to assign for each group. The total bandwidth for all groups cannot exceed the value in the <i>Reserved B/W</i> field in the top portion of the window.
Advanced Setting	Clicking this button will open a new menu that allows you to configure advanced settings for the selected FAT ASI transport stream. See " Advanced FAT ASI Transport Stream Settings " on page 150 .

4. When you are done click **OK**. Figure 123 shows the result.




Figure 123. FAT ASI Ports Created

Advanced FAT ASI Transport Stream Settings

The **Advanced Setting** button from the **Create Transport Stream (FAT ASI)** menu provides the following additional configuration option when creating a FAT ASI transport stream:

ASI Group H.264 Alarm Bitrate Level

This setting can assist in maintaining video quality for MPEG-2 video content in the presence of other content, such as H.264, which bypasses the BNP's transrater. This is done by generating an alarm when H.264 program bandwidth exceeds the percent of the TS bandwidth specified in this setting.

To set the each group's H.264 Alarm Bitrate Level, proceed as follows:

1. From the **Create Transport Stream** menu, click the **Advanced Setting** button.

The **Advanced Transport Stream Setting** window of Figure 124 is displayed.




Figure 124. FAT ASI - Advance Transport Stream Setting

2. Enter a percent of the transport stream's aggregate bandwidth at which an alarm should be generated for each group in the FAT ASI stream. Choices are: 0%, 25%, 50%, 75%, 100%.
3. Click **OK**.

Creating Programs

An input program cannot be created; it must be autodetected from the GigE or ASI port. The only type of input program that can be manually created is a Ghost Program. See [“Elementary Streams” on page 179](#) for more information on Ghost Programs.

You can create output programs in one of two ways: manually or by drag and drop grooming. For either method, the program mapping configuration is the same. You can also schedule programs by either manual or drag and drop methods.

Creating Output Programs Manually

To create a program manually, follow this procedure:

1. From the outputs side of the *Element Manager*'s **Grooming** -> **Mapping** subtab, select or create the transport stream under which the new program will appear.

2. Right-click the transport stream name.





Figure 125. Create Output Program popup

3. Select **Create Program**.

The **Create Output Program** dialog appears.

The image on the *left* displays the default **Create Output Program** dialog when the **PIDs Priority** setting is configured for **Ad**. The image on the *right* displays the default **Create Output Program** dialog when the **PIDs Priority** setting is configured for **Network**.



PIDs Priority set to Ad

PIDs Priority set to Network

Figure 126. Create Output Program dialog

4. Enter all of the information for the program. Some fields will be read-only.

Table 37 describes the fields available in the **Create Output Program** dialog for manual creation.

Table 37. Create Output Program Configuration Parameters

Category	Field	Description
Port	Port ID	Read-only field. The GigE or ASI port on which the program resides.
	IP Address	Read-only field. The destination IP address of the transport stream.
	UDP Port	Read-only field. UDP port the program uses, based on UDP port of the transport stream.
TS	TS ID	Read-only field. The ID number of the transport stream on which this program streams.
	TS Type	Read-only field. Indicates the type of transport stream for the program.
Program / Channel Info	Program Number	MPEG number assigned to this program
	Program Name	Name assigned to this program. Output program names must be unique.
	PMT PID	Select this option to activate the PMT ID box, into which you can then enter the PMT ID, or the ID of the program map table (PMT)
	Major Channel Number	Operator-defined channel number: for terrestrial broadcast, the major channel number is limited to the range 1 to 99 for ATSC digital television or audio services. For cable, major channel numbers may range from 1 to 999. Only editable when ATSC is enabled.
	Minor Channel Number	Operator-defined minor channel number: any whole number in the range from 0 to 999. Only editable when ATSC is enabled.
	Enable DPI ^a	Select this option to enable DPI for the program only, rather than the whole TS. <ul style="list-style-type: none"> This option is hidden unless a PROGRAM WITH DPI license key has been entered in The License Manager.
	Allow SCTE 30- to-SCTE 35 conversion	When checked, enables SCTE 30 to SCTE 35 conversion.

Table 37. Create Output Program Configuration Parameters (Continued)

Category	Field	Description
ETV Configuration ^b	ETV PIDs Priority	<p>Indicates the source of EBIF ES data for the duration of the ad time and provides the option to replace or not replace the pre-bound EBIF ESs during ad splicing.</p> <ul style="list-style-type: none"> When <i>Ad</i> is selected, the spliced ad will provide the EBIF and EISS elementary streams (ESs). If the EBIF and EISS ESs from the ad do not match the stream type and descriptors of the network EBIF and EISS ESs, then the network EBIF and EISS ESs will be dropped. If no EBIF and EISS data are pre-configured at the output program or no EBIF and EISS data are present at the output then the EBIF and EISS ESs from the ad are dropped. When <i>Network</i> is selected, the EBIF and EISS ESs from the ad server will be <i>ignored</i>, even if they are present. <p>Default is set to <i>Ad</i>.</p>
	Play Preference	<p>When the <i>ETV PIDs Priority</i> is set to <i>Network</i>, the following three options will appear in a drop down box:</p> <ul style="list-style-type: none"> <i>Play through ad</i>: any EBIF ES data that is part of the output program will continue to be played during the ad. <i>Drop during ad</i>: any EBIF ES data that is part of the output program will be dropped during the ad. <i>Play during ad only</i>: provides the ability to select the input EBIF ES source that will be playing only during the ad time; if an EBIF ES source is not available, the EBIF ES that currently exists in the output program will be played. <p>Default setting is <i>Play through ad</i>.</p>
	Late-Bind Source	<p>This option is only available when the <i>ETV PIDs Priority</i> is set to <i>Network</i> and the <i>Play Preference</i> is set to <i>Play during ad only</i>.</p> <ul style="list-style-type: none"> When the above two conditions have been met, an additional field with ellipses (. . .) will appear. Clicking on the ellipses will open the <i>Late-Bind Source Dialog</i> window, which will allow the option to choose a valid pair of EBIF/ EISS ES from the BNP's input.
Messaging System	Messaging System Setting	Click this button to open the Program Messaging System Setting window to configure and enable messaging zones for the program. See “ Program Messaging System Setting ,” below for details.

a. A GROOMING WITH DPI license key (which enables DPI for the TS) cannot co-exist with a PROGRAM WITH DPI license key.

b. For additional information in ETV configuration including details on various EBIF and EISS use cases, see [Chapter 7](#), “ETV Binary Interchange Format (EBIF).”

5. Click **OK** to save the changes and create the program.

Program Messaging System Setting

When the **Messaging System Setting** button from the **Create Output Program** menu is clicked, the **Program Messaging System Setting** window will open ([Figure 127](#)).

This setting allows you to configure and enable one of each of the three types of Messaging Zones per program.




Figure 127. Program Messaging System Setting window

Note: In order to select a zone from each of the three types of zone choices in the **Program Messaging System Setting** window, the zones must first be created from the **Configuration -> Messaging System** menu as described in “*Messaging System Configuration*” on page 69 in Chapter 4.

You may select one of each zone type to configure and enable per program. Only previously created zones will appear in the drop-down menu. Table 38 describes the fields available in the **Program Messaging System Setting** window.

Table 38. Messaging System Setting window

Field	Description
EAS Zone	<p>Select an EAS zone from the pull-down menu to associate with the program. See “EAS Messaging Zones” on page 70 in Chapter 4 for additional information.</p> <p>Click the <i>Enable Zone</i> button next to the selection to enable the EAS messaging zone for the specified program.</p>
Operator Messaging Zone	<p>Select an Operator or Advanced Messaging zone from the pull-down menu to associate with the program. See “Operator and Advanced Messaging Zones” on page 76 in Chapter 4 for additional information.</p> <p>Click the <i>Enable Zone</i> button next to the selection to enable the Operator or Advanced Messaging zone for the specified program.</p>
Logo Overlay Zone	<p>Select a Logo Overlay zone from the pull-down menu to associate with the program. See “Logo Overlay Zones” on page 90 in Chapter 4 for additional information.</p> <p>Click the <i>Enable Zone</i> button next to the selection to enable the Logo Overlay zone for the specified program.</p>

Modifying and Deleting Streams or Programs

Modifying Streams or Programs

If a transport stream or a program configuration needs to be modified, use the main **Grooming -> Mapping** window to access the change options:

Modifying Input Transport Streams

The only item that can be modified on an input transport stream is the TS Name.

1. From the inputs side of the **Grooming -> Mapping** window, select the transport stream that requires a name change.
2. Right-click on the TS and choose **Modify Transport Stream** from the popup menu.

The menu to modify an input TS on a GigE port will be similar to [Figure 128](#).




Figure 128. Modify Input TS - GigE port

The menu to modify an input TS on an ASI port will be similar to [Figure 129](#).




Figure 129. Modify Input TS - ASI port.

3. Enter a new name in the **TS Name** field.
4. Click **OK** to save changes.

Modifying Output Transport Streams - GigE

The fields that can be modified on a GigE output transport stream for **all** TS Types are as follows:

- **TS Name**
- **Multicast**
- **Destination IP**
- **UDP Port**
- **Subnet Mask**
- **ARP**
- **MAC Address**
- **Enable Message System**

The following additional fields may be modified for an **ATSC** transport stream:

- **Generate TVCT**
- **STT Source**
- **EIT Source**
- **RRT Source**

The following additional fields may be modified for a **DVB** transport stream:

- **Network ID**
- **Original Network ID**
- **NIT Source**
- **TDT/TOT Source**
- **SDT Source**
- **EIT Source**

To modify a GigE transport stream, proceed as follows:

1. From the outputs side of the **Grooming** -> **Mapping** window, select the GigE transport stream that requires modification.

2. Right-click on the TS and choose **Modify Transport Stream** from the popup menu.

The menu to modify an input TS on a GigE port will be similar to Figure 130.

Figure 130. Modify Output TS (MPEG-2 shown) - GigE port

3. Make any desired modifications to the editable fields.
4. Click **OK** to save changes.

Modifying Output Transport Streams - ASI

The fields that can be modified on an ASI output transport stream for **all** TS Types are as follows:

- **TS Name**
- **Enable Message System**

The following additional fields may be modified for an **ATSC** transport stream:

- **Generate TVCT**
- **STT Source**
- **EIT Source**
- **RRT Source**

The following additional fields may be modified for a **DVB** transport stream:

- **Network ID**
- **Original Network ID**
- **NIT Source**
- **TDT/TOT Source**
- **SDT Source**
- **EIT Source**

To modify an ASI transport stream, proceed as follows:

1. From the inputs side of the **Grooming -> Mapping** window, select the ASI transport stream that requires modification.
2. Right-click on the TS and choose **Modify Transport Stream** from the popup menu.

The menu to modify an output TS on an ASI port will be similar to Figure 131.




Figure 131. Modify Output TS - ASI port.

3. Make any desired modifications to the editable fields.
4. Click **OK** to save changes.

Modifying Input Programs

The only field that can be changed on an input program is the **Program Name**.

1. From the inputs side of the **Grooming -> Mapping** window, select the program that requires a name change.

2. Right-click on the program and choose **Modify Program Name** from the popup menu. (Figure 132).




Figure 132. Program Pop-Up menu - Modify Program

The menu to modify an input program on a GigE or an ASI port will be similar to [Figure 133](#).




Figure 133. Modify Input program - GigE or ASI port

3. Enter a new name in the **Program Name** field.
4. Click **OK** to save changes.

The Program Name is changed ([Figure 134](#)).




Figure 134. Program Name Changed

Modifying Output Programs

The fields that can be changed on an output program are as follows:

- Program Name
- Any relevant **ETV Configuration** fields:
 - PIDs Priority
 - Play Preference
 - Late-Bind Source
- Any relevant **Messaging System Setting** fields:
 - EAS Zone
 - Operator Messaging Zone
 - Logo Overlay Zone



Note: *Any other attributes that you wish to change on a program must be changed on the program's Elementary Stream(s).*

1. From the outputs side of the **Grooming** -> **Mapping** window, select the program that requires a name change.

2. Right-click on the program and choose **Modify Program** from the popup menu. (Figure 135).




Figure 135. Program Pop-Up menu - Modify Program

The menu to modify an output program on a GigE or an ASI port will be similar to Figure 136.




Figure 136. Modify Output program - GigE or ASI port

3. Make any desired modifications to the editable fields.
4. Click **OK** to save changes.

Deleting Streams and Programs

Deleting grooming items is similar to modifying them.

To delete an item:

1. Navigate to the **Grooming** -> **Mapping** window.

2. Select the item to be deleted and right-click.

The options that appear on the right-click menu differ depending on the item selected. In each case, if the item can be deleted, the **Delete** option appears on the menu.

3. Choose **Delete** from the popup menu.

4. Click **Yes** in the confirmation window to confirm that you want to delete this item.

5. Type the new Program Name and click **OK**.

Drag and Drop Grooming

You can drag and drop transport streams, programs, or data elementary streams. When you drag an input transport stream to the output transport stream, all of the programs are moved to the new output stream with it. You can drag a transport stream to a port, or over an existing transport stream. You can drag a program to a transport stream, or over an existing program. You can also drag an elementary stream to a program or to an existing elementary stream.

Drag and drop grooming details are shown in [Table 39](#).

Table 39. Drag and drop grooming

When you drag:	The grooming behavior:
Transport Stream to Transport Stream	Deletes all current programs and replaces them with the dragged Transport Stream
Transport Stream to GigE Port	The entire Transport Stream is copied to the output port
Program to Transport Stream	The program is created in the Transport Stream; the <i>Configure Program Mapping</i> window appears, allowing you to modify the program mapping information
Program to Program	Deletes the existing program and replaces it with the dragged program
Elementary Stream to Elementary Stream	For EBIF, EISS, and regular data streams only; deletes existing ES and replaces it with the dragged ES. Opens the <i>Configure Elementary Stream Mapping</i> window. Only supports replacing the ES, not modification.
Elementary Stream to Program	For EBIF, EISS, and regular data streams only; adds the dragged ES to the program. If the ES already exists in the program, the dragged ES will replace the existing ES.



Caution! *If you replace one transport stream with another, the original will be completely deleted.*

Drag and Drop Grooming Options

Following are configuration explanations of the various drop grooming options available from the *Element Manager's* **Grooming -> Mapping** window.

Program to Transport Stream Grooming

1. Drag the desired input program and drop it onto the desired output transport stream.




Figure 137. Drag input program to output TS

All of the PSIP tables and schedules that are part of the program will be set to the specified output port.

2. As soon as you drop the program, the **Configure Program Mapping** window appears.




Figure 138. Configure Program Mapping window

3. Make any changes necessary as described in [Table 40](#), below.

If this is a backup program, click the Program Redundancy tab and enter the input ports, transport streams, and programs. (See “[Program Redundancy](#)” on page 175 for details)

4. Click **OK** to finalize the output program information.

Program to Program Grooming

1. Drag the desired input program and drop it into the desired output program.
2. The **Configure Program Mapping** window appears ([Figure 139](#)).

Configure Program Mapping

Grooming | Program Redundancy

Source

Port: GigE 2
TS ID: 0x5c

Ghost Program: Ghost Program 1

☐ Synchronize input and output program names

☐ Forward SCTE-35 Cue

Destination

Port: GigE 4
TS ID: 0x1

Program Number: 2
Program Name: G4-t4-2

☐ PMT PID: 36

☐ SCTE 30 to 35 Conversion

ETV Configuration

PIDs Priority: Network
Play Preference: Drop during ad

Grooming Schedule

☒ Now or Start Time:
☒ Never or Stop Time:
(MM/DD/YY HH:MM:SS)

Quality of Service

Service Level: 0
Max Video Bitrate(Mbps):

Component PIDs

	Input Type	PID	Output Type	PID
<input checked="" type="checkbox"/>	Data	452		

☐ Stay Unreferenced ☐ Treat As Async Data

Placeholder ETV ES: None

TS Type ATSC

Major Channel Number: 40
Minor Channel Number: 41

OK **Cancel**

Figure 139. Configure Program Mapping window - program to program

3. Make any changes necessary as described in [Table 40](#) below.

If this is a backup program, click the Program Redundancy tab and enter the input ports, transport streams, and programs. (See “[Program Redundancy](#)” on page 175 for details)

4. Click **OK** to finalize the output program information.

The descriptions in [Table 40](#) are applicable to both the program-to-transport stream and program-to-program procedures described above.



Note: If you are using the drag and drop method of program creation and you wish to configure or enable Messaging System Settings for this program, you must modify the program after drag

and drop and then associate zones for the program as described in “*Program Messaging System Setting*” on page 154.

Table 40. Configure Program Mapping

Category	Field	Description
Source	Port	Read-only. Specifies the input GigE or ASI port used for the input program. The GigE port to use, transport stream ID, program name and number for both the source and the destination of this program must be defined. For input streams, you can choose to Forward SCTE 35 Cue. For output streams, you can enable and specify PMT PID, and enable SCTE 30 to 35 Conversion.
	TS ID	Read-only. Specifies the input Transport Stream ID used for the input program.
	Program Number	Read-only. Specifies the program number for the input program.
	Program Name	Read-only. Specifies the program name (if one was given) for the input program.
	Synchronize input and output program names	Check this box to synchronize the input program name with the output program name,
	Forward SCTE 35 Cue	Check this box to forward SCTE 35 cue tones from the input program. <i>You cannot select this option and SCTE 30 to 35 Conversion for the same output program.</i>
Destination	Port	Displays the destination GigE or ASI port of the output port to which the program will be groomed.
	TS ID	Displays the destination Transport Stream ID of the output TS to which the program will be groomed.
	Program Number	Displays the destination program number of the output program to which the program will be groomed.
	Program Name	Displays the destination program name of the output program name to which the program will be groomed.
	PMT PID	Select this option to activate the PMT ID box, into which you can then enter the PMT ID, or the ID of the program map table (PMT)
	Enable DPI ^a	Select this option to enable DPI for the program only, rather than the whole TS. • This option is hidden unless a PROGRAM WITH DPI license key has been entered in The License Manager .
	SCTE 30 to 35 Conversion	When checked, converts SCTE 30 messages to SCTE 35 cues for transport to the destination. <i>You cannot select this option and Forward SCTE 35 Cue for the same output program.</i>

Table 40. Configure Program Mapping (Continued)

Category	Field	Description
ETV Configuration ^b	ETV PIDs Priority	<p>Indicates the source of EBIF ES data for the duration of the ad time and provides the option to replace or not replace the pre-bound EBIF ESs during ad splicing.</p> <ul style="list-style-type: none"> When <i>Ad</i> is selected, the spliced ad will provide the EBIF and EISS elementary streams (ESs). If the EBIF and EISS ESs from the ad do not match the stream type and descriptors of the network EBIF and EISS ESs, then the network EBIF and EISS ESs will be dropped. If no EBIF and EISS data are pre-configured at the output program or no EBIF and EISS data are present at the output then the EBIF and EISS ESs from the ad are dropped. When <i>Network</i> is selected, the EBIF and EISS ESs from the ad server will be <i>ignored</i>, even if they are present. <p>Default is set to <i>Ad</i>.</p>
	Play Preference	<p>When the <i>ETV PIDs Priority</i> is set to <i>Network</i>, the following three options will appear in a drop down box:</p> <ul style="list-style-type: none"> <i>Play through ad</i>: any EBIF ES data that is part of the output program will continue to be played during the ad. <i>Drop during ad</i>: any EBIF ES data that is part of the output program will be dropped during the ad. <i>Play during ad only</i>: provides the ability to select the input EBIF ES source that will be playing only during the ad time; if an EBIF ES source is not available, the EBIF ES that currently exists in the output program will be played. <p>Default setting is <i>Play through ad</i>.</p>
	Late-Bind Source	<p>This option is only available when the <i>ETV PIDs Priority</i> is set to <i>Network</i> and the <i>Play Preference</i> is set to <i>Play during ad only</i>.</p> <ul style="list-style-type: none"> When the above two conditions have been met, an additional field with ellipses (. . .) will appear. Clicking on the ellipses will open the <i>Late-Bind Source Dialog</i> window, which will allow the option to choose a valid pair of EBIF/ EISS ESs from the BNP's input.
Grooming Schedule	Now or Start Time	<p>To specify the time the program should start, or to continue until either manually stopped or to stop at a specified time, enable these features. If you choose to specify a start or stop time, enable the feature and type the time directly into the appropriate field. A check mark appears when the feature is active.</p> <p>See “Scheduling Grooming - One time event” on page 174 for additional information.</p>
	Never or Stop Time	<p>To tell the program the time to start, or to continue until either manually stopped or to stop at a specified time, enable these features. If you choose to specify a start or stop time, enable the feature and type the time directly into the appropriate field. A check mark appears when the feature is active.</p> <p>See “Scheduling Grooming - One time event” on page 174 for additional information.</p>

Table 40. Configure Program Mapping (Continued)

Category	Field	Description
Quality of Service	Service Level	<p>This sets bit rate adaptation techniques applied to MPEG-2 encoded streams to further enhance bandwidth efficiency.</p> <p>Valid values for this field are as follows:</p> <ul style="list-style-type: none"> Any integer from -8 to +8 0 for off Bypass Transrater^c Handle as Data^d No Rateshaping <p>For additional configuration parameters on each of these values, see Table 41, “Service Level Configuration Details,” on page 169.</p>
	Max Video Bitrate	Sets the limits for the maximum bitrate (in Mbps) for this program. Choosing a specific max rate will bypass automatic transrating based on priorities.
Component PIDs		For this program input, this category allows stream grooming by deselecting specific input PIDs.
	Input Type	Specifies the stream type of the input ESs for this program.
	PID	Specifies the PID of the input ESs for this program.
	Output Type	If clicking in the blue space under this field, opens the <i>Select Elementary Stream</i> window, which will allow you to change the PID of the chosen ES.
	PID	If clicking in the blue space under this field, opens the <i>Select Elementary Stream</i> window, which will allow you to change the PID of the chosen ES.
	Stay Unreferenced	If the input program is a <i>Ghost Program</i> , the <i>Stay Unreferenced</i> option will appear in this section. Check this box if the PIDs in this stream are to remain unreferenced in any PSI tables. See “Adding an Unreferenced PID as an Elementary Stream” on page 190 for more information.
	Treat As Async Data	If the input program is a data-only program or all video and audio streams in the Component PIDs section are unchecked, the <i>Treat as Async Data</i> option will appear in this section. Check this box to disable PCR timing information for this program.
	Placeholder ETV ESs	<p>If the input program does not contain EBIF and EISS elementary streams, a drop down box for the <i>Placeholder ETV ES</i> field will be displayed and editable. This option allows preconfiguration of an EBIF and EISS ES pair with a stream type of 5 or 192. When selecting either <i>EBIF/EISS 5</i> or <i>EBIF/EISS 192</i> the system will automatically generate the following:</p> <ul style="list-style-type: none"> 1 new ES with a <i>Preconfigured for PMT</i> setting of Yes for each EBIF and EISS stream. (See “Elementary Streams” on page 179.) 2 new Descriptor Rules for each new EBIF and EISS ES. (See “Managing PMT and ES Descriptors” on page 203.)

Table 40. Configure Program Mapping (Continued)

Category	Field	Description
TS Type	TS Type	The type of stream: <i>MPEG-2</i> , <i>ATSC</i> , <i>SCTE</i> , or <i>DVB</i> .
	Major Channel Number	Operator-defined channel number: for terrestrial broadcast, the major channel number is limited to the range 1 to 99 for ATSC digital television or audio services. For cable, major channel numbers may range from 1 to 999. Only editable when ATSC is enabled.
	Minor Channel Number	Operator-defined minor channel number: any whole number in the range from 0 to 999. Only editable when ATSC is enabled.

- A GROOMING WITH DPI license key (which enables DPI for the TS) cannot co-exist with a PROGRAM WITH DPI license key.
- For additional information on ETV configuration including details on various EBIF and EISS use cases, see [Chapter 7, "ETV Binary Interchange Format \(EBIF\)."](#)
- This option should not be selected when grooming a DPI-enabled program.
- This option should not be selected when grooming a DPI-enabled program.

Configure Program Mapping Service Level Configuration Options

The **Service Level** field allows the assignment of transrating priorities and conditions for each program. [Table 41](#) provides additional details for configuring the **Service Level** field.

Table 41. Service Level Configuration Details

QoS Service Level Configuration	Video Processing	Can DPI be performed?	Effect on Video Output Bandwidth
Transrating Service Level Values	Video elementary stream (ES) is processed through the transrater. <ul style="list-style-type: none"> -8: highest transrating, lowest quality. +8: lowest transrating, highest quality. 	YES ^a	Transrated output video ES requires less bandwidth than input video ES.
No Rateshaping	Video ES processing is limited through the transrater with null packet removal. <ul style="list-style-type: none"> Video quantization level is unchanged 	YES ^b	Output video ES bandwidth will vary depending on level of ES null packet removal.
Bypass Transrater	Video ES is not processed through the transrater. <ul style="list-style-type: none"> Video can be displayed. 	YES	Output video ES uses the same bandwidth as input video ES. <ul style="list-style-type: none"> Can not use more than the bandwidth of output TS.
Handle As Data	Video ES is not processed through the transrater. <ul style="list-style-type: none"> Video cannot be displayed. 	NO	Output data ES is treated as data and will therefore use the same bandwidth as input video ES. <ul style="list-style-type: none"> Can not use more than the bandwidth of output TS. Total bandwidth should not exceed 4Mbps per TS.

- DPI sessions carry same QOS settings as network.
- DPI sessions carry same QOS settings as network.

Elementary Stream Grooming

You can groom an elementary data stream from the input of a program to another program in the output or to replace an existing elementary data stream within an output program.

To groom an ES from an input program to an output program, proceed as follows:

- 1. From the **Inputs** side of the **Grooming -> Mapping** window, select either the generic data or the EBIF / EISS elementary streams you wish to groom.

Note: For information on the various data stream types and their icons, see Table 27 on page 125.

- 2. Drag the ES to the desired output program on the **Outputs** side of the **Mapping** window.




Figure 140. ES to Program Drag and Drop

The **Configure Elementary Stream Mapping** window will open.




Figure 141. Configure Elementary Stream Mapping window

All fields in the **Configure Elementary Stream Mapping** window are read-only *except* for the **Output Type** and corresponding **PID** value. For a description of the fields in this window as relates to ES mapping, see Table 42.

3. If desired, you can change the PID value of the ES by clicking in the blue space under **Output Type** or **PID**. This will open the following window:




Figure 142. ES Grooming - Reserved PID

4. Enter the desired New Reserved PID.
5. Click **OK** to save changes.

The new ES PID will be displayed in the **Configure Elementary Stream Mapping** window.




Figure 143. Configure ES Mapping - Reserved PID

6. Click **OK** to complete grooming the ES to the output program.

Table 42 describes the fields available in the **Configure Elementary Stream Mapping** window.

Table 42. Configure Elementary Stream Mapping


Category	Field	Description
Source	Port	Displays the source GigE or ASI port of the elementary stream's input program.
	TS ID:	Displays the source Transport Stream ID of the ES's input TS.
	Program Number	Displays the source program number of the ES's input program.
	Program Name	Displays the source program name of the ES's input program.

Table 42. Configure Elementary Stream Mapping (Continued)

Category	Field	Description
Destination	Port	Displays the destination GigE or ASI port of the output port to which the ES will be groomed.
	TS ID:	Displays the destination Transport Stream ID of the output TS to which the ES will be groomed.
	Program Number	Displays the destination program number of the output program to which the ES will be groomed.
	Program Name	Displays the destination program name of the output program name to which the ES will be groomed.
	PMT PID	Displays the Program Map Table PID assigned to the output program.
	SCTE 30 to 35 Conversion	Displays whether or not <i>SCTE 30 to 35 Conversion</i> has been enabled for the output program to which the ES will be groomed.
Component PIDs	Input Type & PID Output Type & PID	Displays the ES <i>Input Type</i> and <i>PID</i> , <i>Output Type</i> and <i>PID</i> . For <i>Input Type</i> , the options that will be seen are as follows: <ul style="list-style-type: none"> • Data • EBIF • EISS Click the blue space under Output Type or PID to enter a reserved PID for this ES.
	Treat as Async Data	When grooming a data, EBIF, or EISS ES to an output program, the <i>Treat as Async Data</i> option will always be enabled. When data is treated as <i>Async Data</i> , then the timing information in the data stream is not processed.

To groom an ES from an input program directly onto an output ES, proceed as follows:

1. From the **Inputs** side of the **Grooming -> Mapping** window, select either the generic data or the EBIF / EISS elementary streams you wish to groom.
2. Drag the ES to the desired output ES on the **Outputs** side of the **Mapping** window.





Note: *An elementary stream may only be groomed on top of an existing ES-level groomed elementary stream (not a program-level groomed stream), and the Stream Types of the input ES and the output ES must match.*

The following ES confirmation message will appear:




Figure 144. ES Grooming Replacement window

3. Click **Yes** to replace the output ES.

Elementary Stream Grooming Icon Colors

When grooming an ES from an input program to an output program or directly onto an output ES, the icon representing that data stream will be displayed in **green** on the **Outputs** side of the **Grooming -> Mapping** window.

When grooming a complete program (and therefore all of its ESs) to an output TS or to replace an existing output program, the icons representing the data ESs will remain **blue** on the **Outputs** side of the **Grooming -> Mapping** window.

See [Table 27 on page 125](#) for additional information.

Viewing Grooming Details

1. In the **Outputs** side of the **Grooming -> Mapping** window, select the transport stream or program whose details and schedule you want to see.
2. Right-click and select **Display Grooming**.

The BNP *Element Manager* will display the currently defined mapping and scheduling window. If you chose to view grooming for the whole TS, all grooming for the programs in that TS will be

displayed; if you chose to view grooming for a specific program, only the grooming for that program will appear.

Current Program Mapping and Schedule

Input Port	Input TS ID	Input Program	Start Time	End Time	Service Level	Current Grooming	Output Port	Output TS ID	Output Program Num
GigE 1	0x7e5	2	Now	Never	0	Primary	GigE 5	0x1	1
GigE 1	0x1	2	Now	Never	0	Primary	GigE 5	0x1	2
GigE 2	0x5c	12	Now	Never	0	Primary	GigE 5	0x1	3
GigE 2	0x5c	13	Now	Never	0	Primary	GigE 5	0x1	4
GigE 2	0x5c	51	Now	Never	0	Primary	GigE 5	0x1	5

Source
 Port: GigE 1
 TS ID: 0x1
 TS IP & UDP: 235.5.5.7 5557
 Program Number: 2
 Program Name:
☐ Synchronize input and output program names

Destination
 Port: GigE 5
 TS ID: 0x1
 TS IP & UDP: 235.3.3.3 3333
 Program Number: 2
 Program Name: G5-I2-2
☐ Forward SCTE-35 Cue

Component PIDs

	Output Type	Output PID
1	MPEG-2 Video	34
2	AC-3 Audio eng	35
3*	EIS	333

Indicates ES-level grooming

ETV Configuration
 PIDs Priority: Ad

Grooming Schedule
☒ Now or Start Time:
☒ Never or Stop Time:
 (MM/DD/YYYY HH:MM:SS)

Quality of Service
 Service Level: 0
 Max Video Bitrate(Mbps):

☐ Program Backup
 Port:
 TS ID(IP & UDP):
 Program Number:
 Program Name:

* ES Grooming

Refresh Cancel

Figure 145. Grooming detail display - TS

The presence of ES-level grooming is indicated by a black asterisk (*) next to the relevant ES in the **Component PIDs** section of the **Current Program Mapping and Schedule** window.

- Click **Refresh** to refresh the view, or **Cancel** to close the window.

Note: In Figure 145, the times specified in the Grooming Schedule section (see Figure 146 for a sample) are from the NTP server. Your PC that is used for configuration may show a different time. This “PC time” should be disregarded; the start and stop times you enter will be referenced to the NTP server.

Scheduling Grooming - One time event

Note: It should be noted that proper use of BNP’s scheduled grooming feature depends on an NTP server as an accurate timing source. Additionally, when scheduling grooming, only a single event can be scheduled, rather than an ongoing occurrence.

To schedule grooming at a specific time for a one-time occurrence, perform steps 1 through 4 in the last section, “[Creating Output Programs Manually](#)” above in order to open the **Configure Program Mapping** window. Then proceed as follows:

1. From the **Configure Program Mapping** window, uncheck **Now or Start time** and click on the pull-down menu that appears. The following dialog opens:




Figure 146. Grooming schedule

2. If you want to start grooming immediately, click **OK**. If you want to start at a later time, set the time and date and then click **OK**.
3. To set the stop time, uncheck **Never or Stop Time**. The grooming schedule of [Figure 146](#) appears. If you don't want to stop grooming, click **OK**. To set a stop time, set the time and date for grooming to stop and click **OK**.
4. Click **OK** to apply the mapping to the program.

Program Redundancy

The BNP supports program level redundancy on all the output services. Program level standby is configurable using the *Element Manager*. The BNP allows the user to designate any input service as a “standby program” with the exception of the same service. The BNP returns back to the primary program from the standby program when the primary program recovers from the interruption.

The health of the standby program will be checked before failover, and the BNP will not perform the switch if the standby is degraded.

Modes of Program Redundancy Operation

The BNP supports two modes of Program Redundancy operation—one offering automatic recovery from the backup program to the primary program while the other allows the user to manually select when the recovery process should occur.

Table 43 describes the various modes of operation for program redundancy.

Table 43. Program Redundancy Modes of Operation

Category	Primary to Backup	Backup to Primary
Automatic Failover to Backup Program / Automatic Recovery to Primary Program	Automatic failover operation is based on two conditions detected, either one will trigger a failover to the designated backup program: <ul style="list-style-type: none"> • Video ES failure detection or <ul style="list-style-type: none"> • Missing PAT/PMT detection. 	Automatic recovery operation is based on two conditions detected, both are required to trigger a recovery to the primary program: <ul style="list-style-type: none"> • Video ES recovery detection and <ul style="list-style-type: none"> • PAT/PMT detection.
Automatic Failover to Backup Program / Manual Recovery to Primary Program	Automatic failover operation is based on two conditions detected, either one will trigger a failover to the designated backup program: <ul style="list-style-type: none"> • Video ES failure detection, or <ul style="list-style-type: none"> • Missing PAT/PMT detection. 	Manual recovery operation is based on the user selecting when a single program or all programs should be recovered to their respective primary programs.

Figure 147. Program Redundancy

To Configure Program Redundancy

1. From the **Grooming** -> **Mapping** window, drag and drop an input program to either an output transport stream or an output program.
The **Configure Program Mapping** window will open.
2. Click the **Program Redundancy** tab.
3. Check the **Specified Program Backup** box at the top of the screen.
4. Drill down in the input grooming window and select the program which is to be the backup for the output program.
5. Under the **Selected Program Redundancy Mode** section, select whether or not this program is to act as **Automatic Failover** / **Automatic Recovery** or **Automatic Failover** / **Manual Recovery**.

Figure 147 shows an example of program redundancy in which the backup is selected as GigE 2, Transport Stream ID 0x5c, and Program Number 1.




Figure 148. Configure Program Mapping - Program Redundancy

Manual Recovery Procedures

The BNP supports the ability to manually switch between the Primary and Backup program. Follow this procedure for manual recovery:

1. From the **Outputs** side of the **Grooming -> Mapping** window, right-click the desired program and select **Display Grooming** from the pop-up menu.

The **Current Program Mapping and Schedule** window opens (Figure 149).




Figure 149. Program Redundancy - Manual Recovery

2. Select the scheduled program and right-click.
3. From the pop-up menu, select **Switch to Backup**.

The **Switch to Backup** option is available when the selected program is already in the *Manual Recovery to Primary Program* operation mode. (The *Automatic Recovery to Primary Program* mode does not allow staying in the Backup Program.)

Figure 149 above illustrates the *Manual Recovery* selection for program redundancy operation on individual programs. This can be used for the *Manual Recovery Primary Program* procedure following an *Automatic Failure to Backup Program*, or for toggling between primary and backup programs for test purposes.

To recover all programs, from the main *Element Manager* window, select **Maintenance -> Regroom**. See "Regrooming" on page 114 for additional information.

Elementary Streams

Creating an Elementary Stream

To add a new elementary stream to an output program:

1. From the **Outputs** side of the **Grooming** -> **Mapping** subtab, select the program to which you want to add an elementary stream.
2. Right-click and select **Manage Elementary Streams** from the pop-up window. The window of Figure 150 appears (The stream entries will vary per program).




Figure 150. Manage Elementary Streams

3. Click **Add ES**.
4. A new elementary stream entry will appear below the last stream.

By default, the new stream is an AC-3 Audio stream. See Figure 151 for an example.

Note: *An **ES Type**, **Stream Type**, **PID** number, **Dummy** value, and **Preconfigured for PMT** value can only be modified when the word “New” appears next to it in the **Stream Order** column. Once you click **OK** to save changes, you will not be able to modify any of these parameters for this particular stream without deleting the stream and adding it again.*




Figure 151. Manage Elementary Streams - New

5. Modify the **ES Type**, **Stream Type**, **PID**, and **Dummy** status (if applicable) by clicking or double-clicking on each field under the respective column. (See Table 44 for details.)

For **ES Type**, a drop down box will be displayed with applicable choices:




Figure 152. Manage Elementary Streams - ES Type choices

For **Stream Type**, if the **ES Type** is **Video**, a drop down box will appear with applicable choices:




Figure 153. Manage Elementary Streams - Stream Type, drop down

If the **ES Type** is **Audio**, the following selection window will appear:




Figure 154. Manage Elementary Streams - Audio Selection

If the **ES Type** is **Data**, the following selection window will appear:




Figure 155. Manage Elementary Streams - Data Selection

Note: When Stream Type is EBIF, EISS or EBIF and EISS, two new descriptor rules will be automatically added for each new EBIF or EISS stream. See “Managing PMT and ES Descriptors” on page 203 for additional information.

For **PID**, double-clicking the field will render it editable and you can type in the new PID:




Figure 156. Manage Elementary Streams - PID

Note: When entering a PID you must enter its decimal conversion from its hex listing in the **Outputs** side of the **Grooming -> Mapping** window. For example, if you are creating a Dummy PID based on an input data stream that has been groomed to a program on an output TS whose PID is 0xf05 (note, the “0x” portion of the PID is for internal reference only), the decimal conversion would be as follows:

hex: F05 converts to decimal: 3845.

If the **ES Type** field is **Data**, clicking on the **Dummy** field will produce a drop down box with the choice of **Yes** or **No**.




Figure 157. Manage Elementary Streams - Dummy

Clicking on the **Preconfigured for PMT** field will produce a drop down box with the choice of **Yes** or **No**.




Figure 158. Manage Elementary Streams - Preconfigured for PMT

6. Click **OK** when you are done modifying the elementary stream to save all changes. The new stream will be displayed in the **Outputs** side of the **Grooming -> Mapping** window.

Table 44 provides a description of the fields from the **Manage Elementary Streams** menu.

Table 44. Manage Elementary Streams menu

Field	Description
Stream Order	Read-only. Displays the order of the stream in the program mapping table (PMT).
Grooming Status	Read-only. Displays whether or not the stream is currently groomed.
ES Type	Read-only if changes have been saved (i.e., <i>OK</i> has been clicked). If the changes to the stream have not yet been applied, clicking this field will open a drop down menu with the following options from which to choose: Audio, Data, or Video.
Stream Type	Read-only if changes have been saved (i.e., <i>OK</i> has been clicked). If the changes to the stream have not yet been applied, and depending on the selection from <i>ES Type</i> , clicking this field will open variable options: <ul style="list-style-type: none"> If <i>Stream Type</i> is <i>Audio</i>, a new window will open allowing you to choose <i>Audio Type</i> and <i>Language Selection</i>. If <i>Stream Type</i> is <i>Data</i>^a, a new window will open with two drop down boxes as follows: Stream Type: choice of decimal values from 5 to 255^b. Stream Sub Type: choice of <i>Data</i>, <i>EISS</i>, <i>EBIF</i>, and <i>EBIF and EISS</i> If <i>Stream Type</i> is <i>Video</i>, a drop down box will appear with choice of <i>MPEG2 Video</i>, <i>H.264 Video</i>, or <i>SCTE Video</i>.
PID	Read-only if changes have been saved (i.e., <i>OK</i> has been clicked). If the changes to the stream have not yet been applied, double-clicking this field allow you to modify the PID associated with the new elementary stream. <ul style="list-style-type: none"> You must enter this value as a decimal conversion of the hex format which appears in the <i>Grooming -> Mapping</i> window.
Dummy	Read-only if stream is groomed; only applicable for data stream. Clicking this field will bring up a drop down box with the following options: <ul style="list-style-type: none"> Yes: Select this if the elementary stream is a dummy stream and the associated data stream with the same PID is carried by another program in the same transport stream. No: This is a read-only value which will appear if the PID is "non-dummy" and therefore treated as a regular stream. <p>Note: The <i>Preconfigured for PMT</i> and <i>Dummy</i> fields are mutually exclusive; therefore, when one is set to <i>Yes</i>, the other will be automatically set to <i>No</i></p>

Table 44. Manage Elementary Streams menu

Field	Description
Preconfigured for PMT	<p>Read-only if stream is groomed; applies to all stream types, but most useful for EBIF / EISS streams.</p> <ul style="list-style-type: none"> Provides the ability to preconfigure the ES by creating associated descriptor rules, regardless of whether or not the data for the corresponding ES is present in the MPEG stream. When the <i>Preconfigured for PMT</i> option is set to Yes, the BNP will not update the PMT, as the assumption is the data is already included in the PMT. <p>Note: The <i>Preconfigured for PMT</i> and <i>Dummy</i> fields are mutually exclusive; therefore, when one is set to Yes, the other will be automatically set to No.</p>
Reserved	Read-only. If the stream is a reserved PID, Yes will appear; if the stream is not a reserved PID, the field will be empty.

- When Stream Type is EBIF, EISS or EBIF and EISS, two new descriptor rules will be automatically added for each new EBIF or EISS stream. See "Managing PMT and ES Descriptors" on page 203 for additional information.
- This number appears as hex in the *Grooming -> Mapping* window; you will need to perform hex to decimal conversion when selecting this value

Reordering an Elementary Stream

You can reorder an elementary stream to change the order of the stream in the PMT. (If, for example, you wish to change the order a stream is placed in the PMT when sent to the end-user's STB.)

- Highlight the stream you want to reorder (Figure 159).




Figure 159. Reordering an Elementary Stream

- Click **Up** or **Down** as required to put the stream in its proper place.




Figure 160. ES Reordered

- When you are done, click **OK**.

Elementary Stream Remapping

You can create a reserved PID or select any specific PID from existing output PIDs, while doing grooming in the **Configure Program Mapping** screen, as an outgoing PID.

You have the flexibility of selecting any PID value for an outgoing PID. When you select from an existing PID then it should be of the same ES Type and language (for audio) as the corresponding Input ES. If there is no exact match then you cannot select that existing output PID.

You can't create a Reserved PID for Video if there is an existing video PID in the output program on which you are grooming.

Reserved PIDs

Reserved PIDs allow you to create PIDs under output programs which will maintain PID values and ES Type and Subtype across reboots and regrooming even when the PID is not groomed. These types of output elementary streams are called Reserved PIDs.

The **Manage Elementary Streams** screen can be used to add the ES and to specify its PID and subtype, as well as the language for the audio ES. The subtype of the reserved video stream will be overwritten by the input Video Subtype but the PID value will be maintained. You can delete any reserved ES if it is not groomed from the main screen by right-clicking the ES, and choosing **Delete**.

See “Unreferenced PID Mapping” on page 196 for steps on creating reserved PID mapping.


Dummy PIDs

To configure a Dummy PID:

1. Groom the actual data stream which you wish to create a dummy PID for from an input program to a desired output program.

In this example, we wish to create a dummy data PID that is associated to the real data stream:

Data [PID: 0x21 Data 0xc2] in Program 6975 BBC HD



Dummy PID will be associated to this Data stream.

Figure 161. Dummy PID: Real data stream groomed

2. Select the program under which you wish to create a Dummy PID, right-click, and select **Manage Elementary Streams** from the pop-up menu.

In this example, we will use Program 6904 BBC 1 C1.

- From the **Manage Elementary Streams** window, click the **Add ES** button.

A new audio ES will appear as the last entry to the list of streams.




Figure 162. Manage ES - New ES for Dummy PID

- From the **ES Type** column, change the ES Type from **Audio** to **Data** from the drop-down window.



Note: See the section, “*Creating an Elementary Stream*” on page 179 for complete details on manipulating the fields in the *Manage Elementary Streams* window.

- From the **Data Selection** window, select the decimal number that matches the actual data stream’s hex ID (this is NOT the PID).

In this case, we will choose the number “194” as it matches the hex number “c2” from the data stream:

Data [PID: 0x21 Data 0xc2] in Program 6975 BBC HD.

- Double click in the **PID** column and enter the decimal value that corresponds to the hex value from the actual data stream.

In this case, we will enter the number “33” as it corresponds to the hex value of “21” in the data stream:

Data [PID: 0x21 Data 0xc2] in Program 6975 BBC HD.

7. From the **Dummy** column, select **Yes** from the drop down box to indicate this is a dummy PID.
The **Manage Elementary Streams** window should now look like this:




Figure 163. Manage Elementary Streams - Dummy PID fields completed

8. Click **OK** to save changes and add this stream to the **Outputs** side of the **Grooming -> Mapping** window.

The data stream (grayed out to indicate dummy PID reference) with associated dummy PID will show up under the appropriate program as seen in [Figure 164](#) below.




Figure 164. Dummy Data PID in Grooming -> Mapping window

9. Repeat [Step 2-Step 8](#) for each additional program (within the same transport stream) under which you wish to create a dummy PID reference.

Dummy PID Configuration Guidelines

The following guidelines should be taken into account when configuring data streams that use dummy PIDs:

1. You cannot configure a Dummy PID data stream unless an actual data stream has been groomed to a program in the relevant transport stream.
2. You cannot delete a program with a data stream to which other dummy PID streams point.
3. If you are creating multiple dummy PIDs under one program, they must all point to the original data streams from a single program. You cannot create multiple dummy PIDs in one program that point to data streams from multiple programs.
4. You can only reference a dummy PID data stream to a data stream in a program that is within the same transport stream.
5. A dummy data PID referenced in a output program will be used regardless of the input source, such as the originally groomed network program source, during program redundancy or program substitution service, or during a DPI ad insertion.
6. You cannot configure the value in an ES as “Yes” for the **Dummy** field and “Yes” for the **Preconfigure in PMT** field at the same time.

Deleting Dummy PIDs

To delete a dummy PID:

1. From the **Grooming -> Mapping** window, select the dummy PID data stream.
2. Right-click and select **Delete**.

Adding an Unreferenced PID as an Elementary Stream

You can add an unreferenced PID to an input transport stream. This allows you to manage unreferenced PID inputs for various applications in the BNP output. Unreferenced PID streams are those MPEG-2 elementary streams encapsulated in the MPEG-2 SPTS or MPTS, whose PIDs are not referenced in any PSI (PAT and PMT) tables. These unreferenced PID streams may be purposely inserted for some special control and applications; they could also result from the stream originator's error.

Unreferenced PIDs can come from the program inputs from GigE interfaces or from ASI inputs. In some applications, these unreferenced PIDs need to be routed to the appropriate output GigE ports or ASI ports as pass-through or with or without the PIDs being remapped. In other cases, these unreferenced PIDs need to be dropped, either because such unreferenced PIDs are not needed or the streams are corrupted.

To add unreferenced PIDs as Elementary Streams:

1. From the **Inputs** side of the **Grooming -> Mapping** subtab, select the transport stream to which you want to add one or more unreferenced PIDs.

2. Right click the transport stream and choose **Create Ghost Program** from the pop-up window (Figure 165).




Figure 165. Choosing a Ghost Program

3. The **Create Ghost Program** screen of Figure 166 appears.




Figure 166. Create Ghost Program

4. Enter the **Ghost Program Name**. Click **OK**. A new program stream appears (Figure 167).




Figure 167. New Program Stream




Figure 168. Adding an Elementary Stream

5. Right click the new Ghost Program you have created, and choose **Add Elementary Stream** (Figure 169).




Figure 169. Adding Elementary Stream: Single ES left, Multiple ES right

6. From the pull-down menus, select the **Stream Category**, **Stream Type**, and **PID**.
If you check **Multiple ES**, you can simultaneously define sequential unreferenced PIDs by entering the number of Elementary Streams (**Number of ES**) and the **Start PID**.

7. Click **OK**. The new PID appears (Figure 170).




Figure 170. New Unreferenced PID

Elementary Stream Ghost PID Management

Ghost programs and PIDs are extra input and output streams not referenced in a Program Association Table (PAT). The BNP allows you to manage elementary stream (ES) Ghost PIDs in three ways:

- **Unreferenced PID Pass Through.** The PID output is unreferenced in the Program Mapping Table (PMT) nor is there any mapping to any other program or transport stream table. Typical applications are Data PID transport and grooming.
- **Unreferenced PID Mapping.** This has no reference in the PMT, but is mapped as a table entry in the PAT at the transport stream level. This is used in various electronic program guide (EPG) applications.
- **Referenced PID Mapping.** The PID output is referenced as a PMT entry. A typical application might be to associate EPG data with one or more programs.

Unreferenced PIDs streams are those MPEG-2 streams encapsulated in the MPEG-2 SPTS or MPTS but their PIDs are not referenced in any PSI (PAT and PMT) tables. These unreferenced PID streams may be purposely inserted for some special control and applications; they could also result from the stream originator's error.

Unreferenced PIDs can come from the program inputs from GigE interfaces or from ASI inputs. In some applications, these unreferenced PIDs need to be routed to the appropriate output GigE ports or ASI ports as pass-through without or with PIDs remapping. In other cases, these unreferenced PIDs need to be dropped, either because such unreferenced PIDs are not needed or the streams are corrupted.

The BNP allows you to add and drop the unreferenced PIDs in its inputs from both GigE and ASI ports.

The BNP can groom the unreferenced PIDs from the inputs to the appropriate output transport stream (SPTS or MPTS) with or without PID remapping using the GUI configuration for the unreferenced PIDs.

Unreferenced PIDs associated with program inputs are usually known in advance, so they can be configured through the GUI for pass-through or drop. The GUI enables the user-configurable

remapping as an output PID for the input unreferenced PID; the output PID can also be referenced in the output TS when necessary through GUI configuration.

For input ASI ports, the TS is automatically created for the input ASI port. User-configured unreferenced PID streams are routed based on grooming rules.

The BNP guarantees there is no conflict between the unreferenced PIDs and the referenced PIDs in its output MPTS or SPTS. If there are unreferenced PIDs causing conflict in the output MPTS or SPTS, then the groomed unreferenced PID causing the conflict is dropped. This could happen when an unreferenced PID is not allowed to be remapped for output.

Unreferenced PID Pass Through

To add an unreferenced PID:

1. Start by creating a ghost program with a data ES, and mapping the unreferenced PID from a program input such as that shown in Figure 171.




Figure 171. Ghost Program With Unreferenced PID.

2. Drag and drop the ghost program from the **Inputs** side of the **Grooming -> Mapping** window to the desired output transport stream.

The **Configure Mapping Window** appears (Figure 172).




Figure 172. Ghost Program Dragged and Dropped to Output TS

3. Note the PID number of the component PID, in this case 115. You will need this when you want to create a referenced PID mapping.
4. Be sure that the **Stay Unreferenced** box is checked, and click **OK**.

The Ghost Program and its Data Transport stream with PID of 0x73 (hex conversion from decimal) appears on both the input and output (Figure 173) showing the stream has been passed through.




Figure 173. Ghost Program Passed Through

Unreferenced PID Mapping

We start with a window as shown in Figure 174.




Figure 174. Starting Unreferenced PID Mapping

1. Highlight the appropriate output port and choose **Create Output Transport Stream** (Figure 175).

Create Output Transport Stream

Port: GigE 6 ☐ SPTS ☐ Non-DPI

☒ Multicast Bitrate (Mbps): 38.0

Destination IP: Reserved B/W (Mbps): 0.0

UDP Port: TS Name:

Subnet Mask: ☐ Unique TS ID: 1

Mac Address: Network PID: 16

TS Type: DVB

☐ Enable Messaging System

Network ID: 160 Modulation Mode: SCTE 256 QAM

Original Network ID: 160

NIT Source: N/A

TDT/TOT Source: N/A

SDT Source: LocalSDT EIT Source: Groomed Input

Figure 175. Create Output Transport Stream

2. Enter the **Destination IP** address and the **UDP Port** number, choose **DVB** as the **TS Type** and click **OK**.

3. Drag the Ghost Program from the input of Figure 174 and drop it on the DVB transport stream you just created. The **Configure Program Mapping** window (Figure 176) appears.

Configure Program Mapping

Grooming **Program Redundancy**

Source
 Port: GigE 2
 TS ID: 0x5c
 Ghost Program: Ghost-Program-1
☐ Synchronize input and output program names
☐ Forward SCTE-35 Cue

Destination
 Port: GigE 4
 TS ID: 0x1
 Program Number: 1
 Program Name: G4-t4-1
☐ PMT PID
☐ SCTE 30 to 35 Conversion

ETV Configuration
 PIDs Priority: Ad

Grooming Schedule
☒ Now or Start Time:
☒ Never or Stop Time:
 (MM/DD/YY HH:MM:SS)

Quality of Service
 Service Level: 0
 Max Video Bitrate(Mbps):

Component PIDs

Input Type	PID	Output Type	PID
<input checked="" type="checkbox"/> Data	115		

☒ Stay Unreferenced ☐ Treat As Async Data
 Placeholder ETV ES: None

TS Type DVB
 Major Channel Number:
 Minor Channel Number:

OK Cancel

Figure 176. Configure Program Mapping Window

4. Be sure that the **Stay Unreferenced** box is checked.
5. Click the empty space to the right of the Component PIDs. The **Select Elementary Stream** window of Figure 177 appears.

Select Elementary Stream

Input ES: Data 115

☒ New Reserved PID 137
☐ Exist Elementary Stream

Stream Order	Groomin Status	ES Type	Stream Type	PID	Dummy	Preconfigured for PMT	Reserved
--------------	----------------	---------	-------------	-----	-------	-----------------------	----------

OK Cancel

Figure 177. Select Elementary Stream Window

6. Enter the new reserved PID number and click **OK**.
7. Click **OK** in the **Configure Program Mapping** window. The unreferenced PID is mapped.

Referenced PID Mapping

Input Ghost ES PIDs can be groomed by the BNP and referenced as ES PIDs in one or more program in the output TS. To add a referenced PID to two programs:

Figure 178 shows the starting window with the unreferenced data PID ES created under a Ghost Program on the input.




Figure 178. Starting Window for Referenced PID Mapping

1. Drag and drop the input ghost program (in this case: Ghost-Program-1) to the output transport stream. Be sure the **Stay Unreferenced** box is checked (Figure 179).



Note: The ghost program must be groomed to the output TS first (Step 1) before creating a dummy PID as described in Step 4.

Configure Program Mapping

Grooming | Program Redundancy

Source
 Port: GigE 2
 TS ID: 0x5c
 Ghost Program: Ghost-Program-1
☐ Synchronize input and output program names
☐ Forward SCTE-35 Cue

Destination
 Port: GigE 4
 TS ID: 0x1
 Program Number: 2
 Program Name: G4-t4-2
☐ PMT PID:
☐ SCTE 30 to 35 Conversion

Component PIDs

Input Type	PID	Output Type	PID
<input checked="" type="checkbox"/> Data	115		

☒ Stay Unreferenced ☐ Treat As Async Data
 Placeholder ETV ES: None

ETV Configuration
 PIDs Priority: Ad

Grooming Schedule
☒ Now or Start Time:
☒ Never or Stop Time:
 (MM/DD/YY HH:MM:SS)

Quality of Service
 Service Level: 0
 Max Video Bitrate(Mbps):


TS Type DVB
 Major Channel Number:
 Minor Channel Number:

OK Cancel

Figure 179. Mapping the Transport Stream

2. Click OK.

The ghost program and its unreferenced PID appear in the **Outputs** side of the **Mapping** window.



- Highlight the output program (from [Figure 178](#)) you wish to reference the data PID to, right click and choose **Manage Elementary Streams**.




Figure 180. Manage Elementary Streams

4. Click **Add ES** and fill in the new row (Figure 181) as described in “Dummy PIDs” on page 187. You will need to know the PID reference, which, in this case, is 115. Be sure to select **Yes** in the **Dummy** column.




Figure 181. New ES filled In

5. Click **OK**.

The new ES will appear under the program. The mapping window shows the same PID in both programs, with the (dummy) PID in Program 1 grayed out.




Figure 182. Dummy data PID in Program grayed out

Clicking on the program of the grayed out data PID and selecting **Manage Elementary Streams** will show the Dummy PID status of **Yes** and a Reserved PID status of **Yes** as well:




Figure 183. Manage ES - Dummy and Reserved status

Managing PMT and ES Descriptors

The *Element Manager* provides the ability to create program descriptor rules that the BNP will apply when it sends out a Program Management Table (PMT) for a specified output program. The rules allow for the appending or removal of output stream descriptors on the PMT level and will remain persistent upon program regrooming.

To manage program descriptor rules, proceed as follows:

1. From the **Outputs** side of the **Grooming** -> **Mapping** window, right-click over the program whose descriptor rules you wish to modify.
2. Select **Manage Descriptor Rules** from the pop-up menu.




Figure 184. Manage Descriptor Rules pop-up

The **Manage Descriptor Rules** window opens.





Figure 185. Manage Descriptor Rules window

To Add a Program Descriptor Rule

1. From the **Manage Descriptor Rules** window, click the **Add Rule** button.



The 'Add Descriptor Rule' window is a dialog box with a blue header and a white body. It contains the following fields:


- TS:** DVB-Stream 0x1(DVB)
- Program:** 1 G4-t4-1
- Action:** A dropdown menu showing 'Append Descriptor'.
- Name:** An empty text field.
- PID:** A text field containing '0' with a green 'DEC' button to its right.
- TAG:** A text field containing '0' with a green 'DEC' button to its right.
- Descriptor Data (Hex Data):** An empty text field.

At the bottom right, there are 'OK' and 'Cancel' buttons.

Figure 186. Add Descriptor Rule window

2. Fill in the fields according to the parameters described in [Table 45 on page 205](#).
3. Click **OK** to create the rule.

A “**New**” status will appear for the descriptor in the Manage Descriptor Rules window. This means that the new rule has not yet been applied to the BNP.



The 'Manage Descriptor Rules' window is a dialog box with a blue header and a white body. It contains the following elements:

- TS:** DVB-Stream 0x1(DVB)
- Program:** 1 G4-t4-1
- Table:** A table with 6 columns: Name, Action, PID, Tag, and Descriptor Data. The table contains 5 rows of data, with the last row marked as 'New'.
- Buttons:** 'Add Rule', 'Edit Rule', and 'Delete Rule' buttons are located to the right of the table.
- Footer:** 'OK' and 'Cancel' buttons are at the bottom right.

	Name	Action	PID	Tag	Descriptor Data
	VideoPMT-Rule	Append Descriptor	4095 (0x0FFF)	192 (0xC0)	0xC2D2
	AudioPMT-Rule	Append Descriptor	2555 (0x09FB)	96 (0x60)	0xC4
		Remove Descriptor	8160 (0x1FE0)	248 (0xF8)	0x0255
		Remove Descriptor	5150 (0x141E)	16 (0x10)	0xD2F2C2
New	DataPMT-Rule	Append Descriptor	1920 (0x0780)	36 (0x24)	0xFFFF

Figure 187. Add Descriptor Rule - New status

4. Click **OK** in the **Manage Descriptor Rules** window to apply the new rule change to the BNP, which will remove the “New” status from the far left of the menu (Figure 188).




Figure 188. Manage Descriptor Rules - Rules Added

5. Click **Cancel** to close the window.

Table 45 describes the fields available in the **Add Descriptor Rule** menu.

Table 45. Manage Descriptor Rules fields

Field	Description
TS	This field is read-only. Displays the Transport Stream ID and type for which the rule will apply.
Program	This field is read-only. Displays the name of the program for which the rule will apply.
Name	For reference use only when appending (or adding) an output program descriptor. Do <i>not</i> enter data in this field when removing a descriptor.
Action	Specify which action is to occur for this rule. Choices are: <ul style="list-style-type: none"> • <i>Append Descriptor</i>: adds the specified descriptor to the PMT of the output stream. The descriptor is appended to the end of the program descriptor loop if the PID is 0, or the ES descriptor loop if the configured PID matches the elementary stream PID. • <i>Remove Descriptor</i>: removes the specified descriptor from the PMT of the output stream. If the BNP doesn't find a match descriptor in the PMT, no action is taken.

Table 45. Manage Descriptor Rules fields (Continued)

Field	Description
PID	<p>Specifies the PID of the stream. Valid range is from 0 to 8190. If the descriptor is a program descriptor, enter a value of 0. Otherwise, enter the elementary stream (ES) PID value; the descriptor rule is applied to this ES.</p> <ul style="list-style-type: none"> Clicking the green DEC button in this field will toggle the field from decimal to hex view. Clicking the green HEX button in this field will toggle the field from hex to decimal view. See Figure 189 for an example of the DEC to HEX toggle view.
TAG	<p>Specifies the TAG of the stream. First 8 bits of the descriptor packet as viewed from an MPEG analyzer.</p> <p>Valid range is from 0 to 255 (decimal) or 0 to FF (hex), up to 8 bits.</p> <ul style="list-style-type: none"> Clicking the green DEC button in this field will toggle the field from decimal to hex view. Clicking the green HEX button in this field will toggle the field from hex to decimal view. See Figure 189 for an example of the DEC to HEX toggle view.
Descriptor Data(Hex Data):	<p>Enter the hex value program descriptor to be appended or removed to or from the PMT of the output stream.</p> <ul style="list-style-type: none"> This value must be an even numbered hex value. This value must be an exact match for the program descriptor as known or discovered through an MPEG analyzer. The BNP will not discover or display the descriptors from the actual TS. When the rule applies to an input stream, the Descriptor Data field is passed through based on information from the input program.

Figure 189 shows an example of the DEC to HEX toggle view in the **Add Descriptor Rule** window.




Figure 189. Add Descriptor Rule - DEC to HEX toggle

To Edit a Program Descriptor Rule

1. From the **Manage Descriptor Rules** window, highlight the descriptor rule you wish to edit.
2. Click the **Edit Rule** button.

The **Add Descriptor Rule** window will open for the highlighted rule.

3. Edit the fields for the descriptor rule, following the guidelines listed in [Table 45 on page 205](#).

If the rule you wish to edit has already been applied to the BNP, you will only be able to edit the **Descriptor Data** field.

4. Click **OK** to save changes.

The status field at the far left of the **Manage Descriptor Rules** window will show a status of “Changed.”




Figure 190. Edit Descriptor Rule - Changed status

5. Click **OK** in the **Manage Descriptor Rules** window apply the new rule change to the BNP, removing the “New” status from the far left of the menu.
6. Click **Cancel** to close the window.

To Delete a Program Descriptor Rule

1. From the **Manage Descriptor Rules** window, highlight the descriptor rule you wish to delete.
2. Click the **Delete Rule** button.

3. You will be asked if you are sure you want to delete the rule.




Figure 191. Manage Descriptor Rules - Rules Deleted

4. Choose **Yes**.
5. The rule is deleted from the **Manage Descriptor Rules** window, as well as removed from the BNP.

Monitoring Bitrates

The second tab on the **Grooming** window is used to monitor input bitrates, and the third tab is used to monitor input-output bit rates. The *BNP Element Manager* shows real-time bit rates.

To change the information displayed for the second tab, use the buttons on the lower left panel. To change the information for the third tab, use the selectors across the top of the window. Select a port and a transport stream.

To select the direction in which to view streaming, move to the upper right of the window. Select Input, Output, or both. A checkmark appears beside the stream direction. The selected direction streams appear in the bar graph beside each other for easy comparison. If only one direction is selected, no comparison is performed.

Input and output bit rates are shown in a bar graph. For the percentage of total output bit rate for each program, use the lower portion of the window. The bar on the lower right shows the total input rate compared to the assumed output rate. You can change the output bitrate by typing a new rate into the Output bitrate field. By default, output bitrate is set to 38.7.

The BNP can simultaneously monitor only 14 programs. If the total selected number of programs exceeds 15, the programs in the earlier monitoring list will be shifted out, and the new selected programs will be added to the bottom of the list. The bit rate monitor window only keeps up to 14 programs.

Each program is shown as a percentage of the total.




Figure 192. Input Monitoring bitrates

Select the port or transport stream from the dropdown menus at the top, and choose input, output, or quantization level (level at which an analog signal is sampled as determined by the resolution of the analog-to-digital converter) to view. You can view any or all simultaneously.

The bar shows the total input rate compared to the assumed output rate. You can change the output rate. If the input rate exceeds the output rate, the total estimated transrating is displayed as shown in Figure 193.




Figure 193. Input bitrate exceeds output

The estimated transrating percentage is computed as follows:

$$\% \text{ Rate Control} = (\text{input rate} - \text{output rate}) / \text{input rate}$$

To stop real-time polling and freeze the bar graph, click **Stop** in the lower right corner. The button changes to **Start** when real-time polling is stopped. To restart the polling, click **Start**.

Each selected counter displays in a separate graph: in the figure below, the top graph shows output quantization levels, while the lower graph shows input and output bitrates.




Figure 194. Input-Output Bit Rate Monitor tab

Digital Program Insertion (DPI)

This chapter describes digital program insertion and how it relates to the BNP3xr.

To implement DPI on the BNP3xr, you need either a GROOMING WITH DPI license key or a PROGRAM WITH DPI license key. See “The License Manager” on page 111 for additional information.

In This Chapter:

- “Digital Program Insertion,” next.
- “Connecting an Ad Server to the BNP” on page 214.
- “Setting SCTE 30 and SCTE 35 Message Handling” on page 215.
- “Setting Postblack Options for DPI” on page 217.

Digital Program Insertion

The BNP supports industry standard digital program insertion (DPI) applications, such as program substitution and ad insertion.

The BNP is fully interoperable with industry compliant ad servers through the SCTE 30 interface. When a successful SCTE 30 initialization has been established with the BNP, the *Element Manager* indicates such with an arrow icon on the Input/Output window of the **Grooming -> Mapping** tab.

The BNP is fully compliant with the SCTE 30 and SCTE 35 standards. A common DPI / ad insertion application deployment using SCTE 30 and 35 (the latter carrying in-band availability cue messages) may be represented by the following regional ad zone insertion illustration:




Figure 195. Regional Ad Zone Insertion Illustration

The BNP receives ads along with SCTE 30 splice messages from an ad server. Receiving these messages triggers the BNP to splice the ad. The ad is then treated the same as other objects in the BNP configuration.

- Note:** *It is highly recommended that you use an NTP server with the BNP. An NTP server is required if you are performing Digital Program Insertion (DPI) and dynamic grooming. You must have the NTP server up and running prior to booting up your BNP.*
- Note:** *When configuring a DPI-enabled program, do not use **Bypass Transrater** or **Handle as Data** Quality of Service levels when grooming a program. See [Table 41 on page 169](#) for additional information.*

Connecting an Ad Server to the BNP

Figure 196 shows how the ad server is connected to the BNP. Other connections may be possible, but this figure shows the general connection.




Figure 196. Ad server - BNP connection

Setting SCTE 30 and SCTE 35 Message Handling

The BNP is capable of receiving SCTE 30 messages from an ad server and converting those messages into SCTE 35 messages.




Figure 197. SCTE 30 to SCTE 35 Conversion

The BNP is also capable of forwarding SCTE 35 messages from input streams to output streams during network time and ad time.

To set SCTE 30 and 35 message handling options:

1. Launch the *Element Manager* and log in as the administrator as described in “[Launching the BNP Element Manager](#)” on page 32.
2. Select the **Grooming -> Mapping** window.
3. Groom an input program to an output transport stream as described in “[Drag and Drop Grooming](#)” on page 163.

The **Configure Program Mapping** window appears.

4. From the **Configure Program Mapping** window, check either the **Forward SCTE 35 Cue** or the **SCTE 30 to 35 Conversion** box.

The **Configure Program Mapping** window has two tabs: **Grooming** and **Program Redundancy**. The **Grooming** tab is active.

Source settings:

- Port: GigE 4
- TS ID: 0x1
- Program Number: 3
- Program Name: (empty)
- ☐ Synchronize input and output program names
- ☒ Forward SCTE 35 Cue

Destination settings:

- Port: GigE 4
- TS ID: 0x1
- Program Number: 7
- Program Name: G4-14-7
- PMT PID: (empty)
- ☐ SCTE 30 to 35 Conversion

ETV Configuration

- PIDs Priority: Ad

Grooming Schedule

- ☒ Now or Start Time: (MM/DD/YY HH:MM:SS)
- ☒ Never or Stop Time: (MM/DD/YY HH:MM:SS)

Quality of Service

- Service Level: 0
- Max Video Bitrate(Mbps): (empty)

Component PIDs

Input Type	PID	Output Type	PID
<input checked="" type="checkbox"/> H.264 Video	49		
<input checked="" type="checkbox"/> AC-3 Audio ...	50		
<input checked="" type="checkbox"/> AC-3 Audio ...	51		

Placeholder ETV ES: None

TS Type ATSC

Major Channel Number: (empty)

Minor Channel Number: (empty)

Buttons: **OK** **Cancel**

Figure 198. Configure Program Mapping window

5. Click **OK**.

- Note:** You can either forward SCTE 35 cues from the input stream or convert SCTE 30 messages from an ad server, but not both.
- Note:** Once SCTE 30 to 35 Conversion is enabled, the BNP only performs conversion; no splicing is performed.

When you choose **Forward SCTE 35 Cue** or **SCTE 30 to 35 Conversion** on an output program, the BNP automatically allocates a PID for the cue (splice information) table, even if the input program contains no cue table. Figure 199 shows an example of an input program with no cue table groomed to an output program selected to forward SCTE 35 cues. Notice the allocation for the cue table in the output program.




Figure 199. Allocated PID for Cue Table

Setting Postblack Options for DPI

Postblack refers to insertion of black video and muted audio at the end of a spliced ad. Postblack might be necessary if the ad is shorter than the specified duration or if there are transmission errors. The BNP offers the following configuration options for postblack.

- **Postblack in ad server requests** — Determine whether to accept or ignore postblack settings in SCTE 30 Splice Request messages from ad servers.
- **Postblack for ad underflows** — Determine whether to insert postblack after ads that are shorter than the time specified in the SCTE 30 Splice Request message. If enabled, postblack is inserted at the end of the ad for the remaining time.

Postblack handling is a global setting on the BNP. To view and configure postblack settings:

1. From the *Element Manager*, select **Configuration -> Global**.

The **Global** chassis configuration window appears.

The screenshot shows the 'Global' configuration window for the Broadcast Network Processor (BNP). The window has a menu bar (File, View, Maintenance, Help) and a title bar (BROADCAST NETWORK PROCESSOR). Below the title bar are tabs for Grooming, Alarms & Events, Configuration, and Chassis. The 'Configuration' tab is selected, and within it, the 'Global' sub-tab is active. The main configuration area is divided into several sections:

- System Time Source:** NTP. A 'Force Sync' button is present.
- Time Zone:** GMT-08 Pacific Time(Tijuana, Baja California).
- System Name:** TEST5.
- System Log Address:** 192.168.41.82.
- Advanced System Parameters:**
 - ☒ Support SCTE 27 Subtitle (Stream Type 0x82)
 - ☐ Enable SCTE-21 to SCTE-20 Conversion
 - ☒ Enable PSIP processing
 - ☒ PAL Mode
 - ☐ Optimize Messaging for HD
 - ☐ Enable Transparency for Messaging System (Enabling this feature will significantly reduce BNP capacity)
- Chassis Redundancy:**
 - Chassis Active Status:** Primary.
 - Redundant Chassis Configuration:**
 - IP Address for 10/100: [Field]
 - Virtual IP Address Configuration:
 - IP Address for 10/100: [Field]
 - IP Address for ETH 2: [Field]
 - IP Address for GigE 1: [Field]
 - IP Address for GigE 2: [Field]
 - IP Address for GigE 3: [Field]
 - IP Address for GigE 4: [Field]
 - Redundancy Switch:**
 - IP Address for GigE 8 (Optional): [Field]
 - Gateway for 10/100: [Field]
 - Gateway for ETH 2: [Field]
 - IP Address for GigE 5: [Field]
 - IP Address for GigE 6: [Field]
 - IP Address for GigE 7: [Field]
 - IP Address for GigE 8: [Field]
- Postblack Enable Options:**
 - ☐ AD Server Request
 - ☐ AD Underflows

At the bottom right, there are 'Apply Configuration' and 'Cancel' buttons. The status bar at the bottom shows 'Connected 10.32.97.249' and the time '15:38:01'.

Figure 200. Global chassis configuration

2. Set your postblack options according to the following table:

Table 46. Postblack Enable Options

Category	Field	Description/Values
Postblack Enable Options	AD Server Request	Check this to play postblack that an ad server specifies be played at the end of an ad. Left unchecked, the BNP will ignore any postblack requests from ad servers.
	AD Underflows	Check this to insert postblack at the end of an ad that is shorter than the duration specified by the ad server.

3. Click **Apply Configuration**.

ETV Binary Interchange Format (EBIF)

This chapter describes how the BNP can be configured to process Enhanced Television (ETV) Binary Interchange Format (EBIF) content for delivery of interactive data in the video processing network.

In This Chapter:

- “Overview,” next.
- “Functionality” on page 219.
- “Prerequisite Reading” on page 219.
- “Use Case Configuration Examples” on page 220.

Overview

The CableLabs EBIF standard provides a solution for the delivery of interactive data to existing set-top boxes (STBs), including older models of STBs. EBIF condenses interactive applications in order to use the minimal STB resources available for interactive data delivery. Since ETV can make use of scant resources, the MSO has the ability to deliver interactive broadcasts and advertisements to the widest possible audience, including the STB user who still relies on legacy hardware. Because ETV applications are very compact and can be downloaded to the STB rapidly, the ETV format is particularly suitable for authoring interactive commercials.

Prerequisite Reading

In order to better understand the *Use Cases* described in this chapter, you should familiarize yourself with the concepts and steps described in [Chapter 5, “Grooming and PSIP.”](#) In particular, the following sections will be useful:

- “Viewing ES-Level Input Source” on page 123.
- “Interpreting Elementary Stream Status Icons” on page 125.
- “Creating Programs” on page 151.
- “Drag and Drop Grooming” on page 163.
- “Elementary Streams” on page 179.
- “Managing PMT and ES Descriptors” on page 203.

Functionality

ETV is interpreted by a **User Agent**: a software application that runs on the set-top box that is installed remotely by the MSO.

When ETV is downloaded to the STB, it uses a pairing of data elementary streams, which consist of the following:

- ETV Binary Interchange Format (EBIF) data ES — carries the application data.
- ETV Integrated Signaling Stream (EISS) data ES — carries timing signals that trigger events associated with the application.

ETV applications are typically "bound" (or **Pre-bound**) to particular pieces of content, and packaged in a program together with video and audio while being broadcast to the STB. This content can be a 30-second ad or a network stream (a dedicated channel or program with EBIF content coded into it). Another possible source of ETV data is a local EBIF streamer: a server that provides pre-packaged EBIF content, allowing the BNP to enhance a video or audio program (network stream or ad) with additional ETV data. The process of adding EBIF enhancement to an existing network stream or ad is referred to as **Late-binding**.

Figure 201 shows the basic ETV data source flow.




Figure 201. ETV EBIF Data Source flow

Use Case Configuration Examples

The BNP can groom, splice or filter ETV data streams, including, but not limited to, the *Use Case* examples listed below:

1. Pre-Bound Ad Splice.
2. Pre-Bound EBIF Passthrough (no DPI).
3. Pre-Bound EBIF Drop.
4. Pre-Bound EBIF Passthrough and Keep During Ad Splice.
5. Pre-Bound Network EBIF; Late-Bind EBIF During Ad.



Note: In all of the following *Use Cases* (except as specified as “Non-DPI”) it is assumed that the BNP is configured for DPI. See [Chapter 6, “Digital Program Insertion \(DPI\)”](#) for details on configuring DPI.

Pre-Bound Ad Splice

In pre-bound ad splicing, the input network (or program) stream does not contain ETV data; rather, an ad containing ETV data ESs is spliced in later. In this case, the BNP would be configured to play the ad's ETV streams on the output during the ad splice.

Figure 202 shows an example of pre-bound ad splice.




Figure 202. Pre-bound Ad Splice flow

Configuration Steps:

To configure pre-bound ad splice, proceed as follows:

1. From the *BNP Element Manager*, click on the **Grooming -> Mapping** tab.
2. Create an output transport stream, if necessary. (See the section that begins with, “[Creating MPEG-2 Output Transport Streams](#)” on page 131 for additional information.)
3. Use the **Drag and Drop Grooming** feature to groom a desired input program to the desired output transport stream (oTS), as seen in [Figure 203](#), for example.



Note: *In this use case, the input program does not contain any ETV elementary streams.*




Figure 203. Input program (without ETV data) groomed to oTS

The **Configure Program Mapping** window will open.

4. In the **ETV Configuration** section, the **PIDs Priority** setting should remain at the default of **Ad**.
5. In the **Component PIDs** section under **Placeholder ETV ESs**, select the appropriate type of EBIF and EISS elementary stream placeholders from the drop down box. The type of ESs selected here should match those of the ETV ESs in the ad.
6. If necessary, change the PID values of the EISS and EBIF ESs by clicking the blue space under the **Output Type** or **PID** columns next to the appropriate input ES.

Figure 204 shows the **Configure Program Mapping** window with the above options filled in.




Figure 204. Configure Program Mapping window - EBIF/EISS Placeholder

7. Click OK.

The **Grooming -> Mapping** window will now show the groomed program with two Data EBIF/EISS ESs grayed out.




Figure 205. Program with placeholders groomed - ESs grayed out



Note: When creating Placeholder ETV ESs, two new descriptor rules with default values will be created for each ES used as a placeholder. The Descriptor Data information in these rules may be edited, if necessary. In this case, there will be 4 new descriptor rules (2 for EISS and 2 for EBIF) that are created in the **Manage Descriptor Rules** window.

To view the descriptor rules created with the placeholder ESs, proceed as follows:

1. From the **Outputs** side of the **Grooming -> Mapping** window, right-click on the program you just groomed and select **Manage Descriptor Rules** from the pop-up menu.

The **Manage Descriptor Rules** window will open, showing two descriptor rules for each ES placeholder:




Figure 206. Manage Descriptor Rules - EISS & EBIF additions

2. Click **Cancel** to close the **Manage Descriptor Rules** window.

Pre-Bound EBIF Passthrough (no DPI)

In pre-bound EBIF passthrough on a non-DPI program, the network stream contains the pre-bound ETV data streams, and the BNP is configured to play the input ETV streams on the output.

Figure 207 shows an example of pre-bound EBIF passthrough.




Figure 207. Broadcast EBIF enabled

Configuration Steps:

To configure pre-bound EBIF passthrough, proceed as follows:

1. From the BNP *Element Manager*, click on the **Grooming -> Mapping** tab.
2. Create an output transport stream, if necessary. (See the section that begins with, “[Creating MPEG-2 Output Transport Streams](#)” on page 131 for additional information.)
3. Use the **Drag and Drop Grooming** feature to groom a desired input program to the desired output transport stream (oTS), as seen in [Figure 208](#), for example.



Note: *In this use case, the input program **does** contain two ETV elementary streams.*




Figure 208. Input program (with ETV data) groomed to oTS

The **Configure Program Mapping** window will open.

The screenshot shows the 'Configure Program Mapping' window with the 'Program Redundancy' tab selected. The window is divided into several sections:

- Source:** Port: GigE 1, TS ID: 0x1, Program Number: 1, Program Name: (empty). Checkboxes for 'Synchronize input and output program names' and 'Forward SCTE-35 Cue' are present.
- Destination:** Port: GigE 7, TS ID: 0x1, Program Number: 2, Program Name: G7-t5-2. Checkboxes for 'PMT PID' and 'SCTE 30 to 35 Conversion' are present.
- ETV Configuration:** PIDs Priority: Ad (dropdown).
- Grooming Schedule:** Checkboxes for 'Now or Start Time' and 'Never or Stop Time' are present.
- Quality of Service:** Service Level: 0 (dropdown), Max Video Bitrate(Mbps): (empty).
- Component PIDs:** A table with columns: Input Type, PID, Output Type, PID.

Input Type	PID	Output Type	PID
<input checked="" type="checkbox"/> MPEG-2 Video	481		
<input checked="" type="checkbox"/> AC-3 Audio eng	482		
<input checked="" type="checkbox"/> EISS	1155		
<input checked="" type="checkbox"/> EBIF	1156		
- Placeholder ETV ES:** None (dropdown).
- TS Type:** MPEG-2, Major Channel Number: (empty), Minor Channel Number: (empty).

Buttons for 'OK' and 'Cancel' are at the bottom right.

Figure 209. Configure Program Mapping - EBIF/EISS defaults

4. In the **ETV Configuration** section, leave the **PIDs Priority** set to the *default* of **Ad**.
5. In the **Component PIDs** section, leave the *EISS* and *EBIF* ESs checked. You may change the PID values or leave them at their defaults.
6. Click **OK**.

The **Grooming -> Mapping** window will now show the groomed program with the data EBIF/EISS ESs passed through to the output.




Figure 210. Program with ETV ESs passed through

Pre-Bound EBIF Drop

In pre-bound EBIF drop, the network stream contains pre-bound ETV data streams and the BNP is configured to not play (*to drop*) the network ETV streams on the output.

Figure 211 shows an example of pre-bound EBIF where the ETV streams are dropped.




Figure 211. Broadcast EBIF disabled

Configuration Steps:

To configure pre-bound EBIF to be dropped, proceed as follows:

1. From the BNP *Element Manager*, click on the **Grooming -> Mapping** tab.
2. Create an output transport stream, if necessary. (See the section that begins with, “[Creating MPEG-2 Output Transport Streams](#)” on page 131 for additional information.)
3. Use the [Drag and Drop Grooming](#) feature to groom a desired input program to the desired output transport stream (oTS), as seen in [Figure 208 on page 225](#), for example.



Note: In this use case, the input program *does* contain two ETV elementary streams.

The **Configure Program Mapping** window will open.

4. In the **ETV Configuration** section, leave the **PIDs Priority** set to the *default* of **Ad**.

5. In the **Component PIDs** section, *uncheck* the *EISS* and *EBIF* ESs.

The **Configure Program Mapping** window will look similar to Figure 212.




Figure 212. Configure Program Mapping - EBIF/EISS unchecked

6. Click **OK**.

The **Grooming** -> **Mapping** window will now show the groomed program with the data EBIF/EISS ESs dropped from the output.



Figure 213. Program with ETV ESs dropped

Pre-Bound EBIF Passthrough and Keep During Ad Splice

In this example, the network stream contains pre-bound ETV data streams and the ads are un-enhanced. When the network stream is groomed to the output the BNP is configured to continue playing (*keep*) the network ETV streams during ad splices.

Figure 214 shows an example of broadcast EBIF groomed as Splice/Keep.




Figure 214. Broadcast EBIF groomed as Splice/Keep

Configuration Steps:

To configure pre-bound EBIF to play through and be kept during an ad splice, proceed as follows:

1. From the *BNP Element Manager*, click on the **Grooming -> Mapping** tab.
2. Create an output transport stream, if necessary. (See the section that begins with, “[Creating MPEG-2 Output Transport Streams](#)” on page 131 for additional information.)
3. Use the [Drag and Drop Grooming](#) feature to groom a desired input program to the desired output transport stream (oTS), as seen in [Figure 208 on page 225](#), for example.



Note: In this use case, the input program *does* contain two ETV elementary streams.

The **Configure Program Mapping** window will open.

4. In the **ETV Configuration** section, click on the **PIDs Priority** drop-down box and select **Network**.
When **Network** is selected in **PIDs Priority**, the **Play Preference** drop-down box will be displayed.

5. In the **Play Preference** drop-down box, leave the setting at the default of **Play through ad**.
The **Configure Program Mapping** window will look similar to Figure 215.

Configure Program Mapping

Grooming | **Program Redundancy**

Source

Port: GigE 1
TS ID: 0x1
Program Number: 1
Program Name:
☐ Synchronize input and output program names
☐ Forward SCTE-35 Cue

Destination

Port: GigE 7
TS ID: 0x1
Program Number: 4
Program Name: G7-t5-4
☐ PMT PID:
☐ SCTE 30 to 35 Conversion

ETV Configuration

PIDs Priority: Network
Play Preference: Play through ad

Component PIDs

Input Type	PID	Output Type	PID
<input checked="" type="checkbox"/> MPEG-2 Video	481		
<input checked="" type="checkbox"/> AC-3 Audio	482		
<input checked="" type="checkbox"/> EISS	1155		
<input checked="" type="checkbox"/> EBIF	1156		

Placeholder ETV ES: None

Grooming Schedule

☒ Now or Start Time:
☒ Never or Stop Time:
(MM/DD/YY HH:MM:SS)

Quality of Service

Service Level: 0
Max Video Bitrate(Mbps):

TS Type MPEG-2
Major Channel Number:
Minor Channel Number:

OK Cancel

Figure 215. Configure Program Mapping - Play through ad

6. Click **OK**.

The **Grooming** -> **Mapping** window will now show the groomed program with the data EBIF/EISS ESs passed through to the output.



Figure 216. Program with ETV ESs passed through (Splice/Keep)

To verify that the ETV ESs are configured for **Play through ad**, highlight the program and select **Modify Program** from the pop-up menu.

Pre-Bound Network EBIF; Late-Bind EBIF During Ad

In this example, the network stream contains pre-bound ETV data streams and a local streamer or another source (such as another input program) streams another pair of ETV ESs (late-bind source). The BNP is configured to play the network ETV streams when the network stream is played, then to switch to the late-bind source during the ad.

Figure 217 shows an example of pre-bound network EBIF and late-bind EBIF during an ad.




Figure 217. Pre-bound Network EBIF, late-bind EBIF during ad

Configuration Steps:

To configure a late-bound EBIF ad to play through a pre-bound program, proceed as follows:

1. From the BNP *Element Manager*, click on the **Grooming -> Mapping** tab.
2. Create an output transport stream, if necessary. (See the section that begins with, “[Creating MPEG-2 Output Transport Streams](#)” on page 131 for additional information.)
3. Use the **Drag and Drop Grooming** feature to groom a desired input program to the desired output transport stream (oTS), as seen in [Figure 218](#), for example.



Note: The input program *should* contain at least two ETV elementary streams and there should be an additional two ETV ESs available for the late-bound streams.




Figure 218. Input program (with ETV data) groomed to oTS; Late-bound

The **Configure Program Mapping** window will open.

4. In the **ETV Configuration** section, click on the **PIDs Priority** drop-down box and select **Network**.

When **Network** is selected in **PIDs Priority**, the **Play Preference** drop-down box will be displayed.

5. In the **Play Preference** drop-down box and select the **Play during ad only** option.

The **Configure Program Mapping** window will look similar to Figure 219.

Configure Program Mapping

Grooming | **Program Redundancy**

Source
 Port: GigE 4
 TS ID: 0x1
 Program Number: 1
 Program Name:
☐ Synchronize input and output program names
☐ Forward SCTE-35 Cue

Destination
 Port: GigE 4
 TS ID: 0x1
 Program Number: 2
 Program Name: G445-2
☐ PMT PID:
☐ SCTE 30 to 35 Conversion

ETV Configuration
 PIDs Priority: Network
 Play Preference: Play during ad only
 Late-Bind Source: ...

Grooming Schedule
☒ Now or Start Time:
☒ Never or Stop Time:
 (MM/DD/YY HH:MM:SS)

Quality of Service
 Service Level: 0
 Max Video Bitrate(Mbps):

Component PIDs

Input Type	PID	Output Type	PID
<input checked="" type="checkbox"/> MPEG-2 Video	2063		
<input checked="" type="checkbox"/> AC-3 Audio eng	2062		
<input checked="" type="checkbox"/> EISS	1768		
<input checked="" type="checkbox"/> EBIF	1770		

Placeholder ETV ES: None

TS Type MPEG-2
 Major Channel Number:
 Minor Channel Number:

OK Cancel

Click the "... " to select a late-bind source

Figure 219. Configure Program Mapping - Play during ad only

When the **Play during ad only** option is selected, the **Late Bind Source** field will be displayed.

6. Click on the ellipses (. . .) on the right-hand side of the **Late Bind Source** field to open the **Late-Bind Source Dialog** window.



Note: This window displays the *Inputs* side of the Element Manager's *Grooming -> Mapping* window.




Figure 220. Late-Bind Source Dialog window

7. In the **Late-Bind Source Dialog** window, drill down to the program level.

8. Select the desired program with ETV ESs that will be used to play during the ad; this is also called the *late-bound ETV source*.




Figure 221. Late-Bind Source selected

9. Click **OK** to return to the **Configure Program Mapping** window, which will look similar to Figure 222:




Figure 222. Configure Program Mapping window - Late-bound selected

10. Click **OK** to complete the grooming process.

The **Grooming** -> **Mapping** window will now show the groomed program with the late-bound data EBIF/EISS ESs in the output.



Figure 223. Program with late-bound ETV ESs

To view which late-bound ETV source is configured for **Play during ad only**, highlight the program and select **Modify Program** from the pop-up menu.




Figure 224. View Late-Bind Source in output program

DVB Conditional Access

This chapter describes the functionality and configuration parameters for the BNP3xr DVB Conditional Access (DVB-CA) feature.

In This Chapter:

- “Overview,” next.
- “DVB-CA Required Components” on page 238.
- “DVB-CA Configuration” on page 238.
- “DVB-CA Best Practices and Considerations” on page 274.

Overview

The BNP3xr supports the DVB-CA Common Scrambling Algorithm (CSA) and DVB SimulCrypt protocols (ETSI TS 103 197 V1.5.1) for Conditional Access System (CAS) which interfaces with DVB systems. This allows for encryption of MPEG-2 and H.264 programs in both SD and HD resolutions. The embedded SimulCrypt Engine is a low cost, high density, scalable encryption and management control implementation that is fully DVB-CA compliant. The BNP3xr provides two 10/100 Ethernet management ports, allowing one of these port to be dedicated to the DVB-CA network.

The DVB-CA encryption feature includes the following functionalities:

- SimulCrypt Synchronizer (SCS).
- Control Word Generation (CWG).
- Common Scrambling Algorithm (CSA).
- ECM / EMM insertion.
- CA-related PSI / SI generation and insertion.

RGB’s SimulCrypt engine interfaces with the following devices:

- Entitlement Control Message Generator (ECMG).
- Entitlement Management Message Generator (EMMG).
- Optional external Event Information Scheduler (EIS)¹.

1. The BNP may be configured to use an external EIS server or the internal EIS server provided by the BNP software.

Figure 225 shows the BNP3xr in a deployed DVB-CA network.




Figure 225. BNP3xr in a DVB-CA network

DVB-CA Required Components

The following components are necessary for a fully functioning DVB-CA system for the BNP3xr:

1. BNP3xr running software version 3.0 or higher.
2. DVB Transport Streams (TSs) configured on the output of the BNP3xr.
3. Conditional Access System (CAS) with the following components:
 - Entitlement Control Message Generator (ECMG);
 - Entitlement Management Message Generator (EMMG);
 - Optional external Event Information Scheduler (EIS);
 - Valid NTP server.
4. Determination of whether or not External EIS mode or Internal EIS mode will be used.

DVB-CA Configuration

This section describes the required configuration steps necessary for the DVB-CA feature. These steps require an **Admin** login level from the *Element Manager*. The steps are as follows:

1. Verify DVB-CA License.
2. Set Up an NTP Server.
3. Configure Ethernet Control Port for DVB-CA.
4. Configure GigE or ASI Port(s) for DVB-CA System.
5. Create Input TS(s) for DVB-CA System.
6. Create Output DVB TS(s) for DVB-CA System.
7. Groom Input Program(s) to Output DVB TS.
8. Create Input PSI/SI Table Grooming.

9. Groom the Ghost Program to Output DVB TS.
10. Configure DVB-CA Global Parameters.
11. Configure DVB-CA Tab: External and Internal EIS Mode.
12. Complete DVB-CA Tab Configuration for Internal EIS Mode.

Verify DVB-CA License

In order to view or configure any DVB-CA parameters in the *Element Manager*, you must first have a valid DVB-CA license. See “The License Manager” on page 111 for details on obtaining or verifying a DVB-CA license. When a valid DVB-CA license is present, an additional DVB-CA menu option will appear on the main *Element Manager* menu as well as an additional DVB-CA tab (Figure 226).




Figure 226. DVB-CA Element Manager additions

Set Up an NTP Server

In order for the DVB-CA feature to properly interact with the CAS, a network time protocol (NTP) server must be set up in the *Element Manager* such that the IP Address of the NTP server is from the same source as that used by the CAS.

1. From the **Global Chassis Configuration** menu (**Configuration -> Global**), enter one IP address that will be used for NTP by the DVB-CA system.




Figure 227. DVB-CA - NTP server setup

2. Click the **Apply Configuration** button at the bottom right of the window to save the changes.

Configure Ethernet Control Port for DVB-CA

There are two 10/100 Base T Ethernet management ports for the BNP3xr.

Only **Ethernet Port 2** is available for management access to the CAS. You must configure an IP address for both Ethernet Port 1 and Ethernet Port 2 for proper DVB-CA functionality.

To configure IP parameters for Ethernet Port 2, proceed as follows:

1. From the **Ethernet Control Port Configuration** menu (**Configuration -> Ethernet Control Port**) under the **Ethernet Port 2** section, enter the **IP Address**, **Subnet Mask**, **Gateway**, and **DNS Server** (optional) to which the CAS will connect.

Note: *If you have configured the BNP3xr in a 1:1 redundancy environment, the Gateway IP Address for Ethernet Port 2 must be configured.*

2. Click the **Apply Configuration** button to save the changes.
3. The BNP will prompt for a reboot.

Ethernet Port: GUI Display to Chassis Mapping

In the BNP3xr the naming scheme and physical layout of the two management Ethernet ports differs from the **Ethernet Control Port** menu in the *Element Manager* to the labels and layout on the actual chassis. Figure 228 below provides a mapping of the port layout.




Figure 228. DVB-CA - Ethernet Control Port mapping

Configure GigE or ASI Port(s) for DVB-CA System

GigE Port Input and Output Interface Configuration

1. From the [GigE Port Configuration](#) menu (**Configuration -> GigE Ports**) enter the **IP Address**, **Subnet Mask**, **Gateway**, and **Auto-negotiation** information for the input and output GigE port(s) that are to be used for encryption.



Note: A GigE port may be used for simultaneous input and output.




Figure 229. Configure GigE - DVB-CA

2. Click **Apply Configuration** to save changes.

And / Or:

ASI Port Input and Output Configuration

1. From the [Configuring ASI Ports](#) menu (**Configuration** -> **ASI Ports**) select which ports will be used for input and which ports are to be used for output.



Note: An ASI port may not be used for simultaneous input and output; only one direction per port may be selected.




Figure 230. Configure ASI - DVB-CA

2. Click **Apply Configuration** to save changes.

Create Input TS(s) for DVB-CA System

If you have not yet done so, create an input transport stream for which programs are to be encrypted.

1. From the [Creating Input Transport Streams](#) menu (from **Grooming** -> **Mapping** window, right click on the Input GigE or ASI port and select **Create Transport Stream**), enter the **TS Name**, **IP Address**, and **UDP Port** of the Input TS for the programs to be encrypted.




Figure 231. Create Input TS - DVB-CA

2. Click **OK** to create the TS.

Create Output DVB TS(s) for DVB-CA System

1. Follow the steps in the section titled, “Creating DVB Output Transport Streams” on page 142 to create a new DVB Transport Stream for either a GigE or an ASI port.

Figure 232. Create Output TS - DVB-CA: GigE port (left); ASI port (right)

2. Ensure that the following parameters are configured as specified below in Table 47 for proper encryption functionality:

Table 47. Output DVB TS parameters for DVB-CA configuration

Output TS Parameter	Description	Required DVB-CA Value
Unique TS ID ^a	Allows you to assign a unique numeric ID to this transport stream. <ul style="list-style-type: none"> • When this option is <i>checked</i>, the TS ID value placed in this field will be reserved as unique for the entire chassis. • When this option is <i>unchecked</i>, a TS ID value may still be entered, however the value may be the same as another TS ID, as long as that TS ID's value has not been reserved as a Unique TS ID. 	This field <i>must</i> be checked. The value in this field <i>must</i> match that of the CAS.
TS Type	The type of stream. The type of stream you choose determines what other information is required. Choices are: <i>MPEG-2, ATSC, SCTE, or DVB.</i>	This field <i>must</i> be set to <i>DVB</i> .
Network ID	The Network ID of the current transport stream.	The value in this field <i>must</i> match that of the CAS.
Original Network ID	The Network ID from which this stream has originated.	The value in this field <i>must</i> match that of the CAS.

Table 47. Output DVB TS parameters for DVB-CA configuration (Continued)

Output TS Parameter	Description	Required DVB-CA Value
Modulation Mode	Use the pull-down menu to select the modulation mode used for the TS. <ul style="list-style-type: none"> The Modulation Mode information is carried in the Network Information Table (NIT) of the input from the CAS vendor. Choice between <i>SCTE 64 QAM</i> and <i>SCTE 256 QAM</i>. 	The selection in this field <i>must</i> match that of the CAS, unless NIT is passed through.
SDT Source	Source of the service description table for this transport stream. If you select N/A then SDT is not generated for this output TS.	This field <i>must</i> be set to N/A if SDT is originating from an external source.
EIT Source	Source of the Event Information Table (EIT) for the programs in this transport stream. If you select N/A then EIT will not be generated.	This field <i>must</i> be set to N/A if EIT is originating from an external source.

a. The DVB-CA standard requires a unique pair value of the TS ID and Network ID fields.

3. Click **OK** to create the output transport stream.

Groom Input Program(s) to Output DVB TS

1. From the **Grooming** -> **Mapping** window, drag the desired input program(s) to the output DVB TS you just created. See the section titled, “[Drag and Drop Grooming](#)” on page 163 for details on program dragging and dropping.

After grooming the input program to the DVB output TS, the **Configure Program Mapping** window opens:




Figure 233. Configure Program Mapping - DVB-CA

2. In the **Destination** section, change the **Program Number** to the number *assigned and provided by the CAS*.
3. If you are using an external EIS server, you may need to reserve the elementary stream PIDs *per the CAS configuration to match those from the external EIS server*.

If you are using an internal EIS server, reserving a PID is optional and you may proceed to [Step 6](#) below.

In the **Component PIDs** section, double click on the **Output Type** or **PID** fields for each elementary stream to assign a new reserved PID

4. The **Select Elementary Stream** window open.

In the example above and below in [Figure 233](#) and [Figure 234](#), the Input SCTE Video PID of 16 will be changed to 3011 and the AC-3 Audio PID of 17 will be changed to 3012:




Figure 234. Reserve ES PIDs - DVB-CA

Note: When entering elementary stream PID values in the BNP Element Manager, the values must be entered in decimal format, however in the **Grooming -> Mapping** window, these values will always appear in hexadecimal format. It will be necessary to perform hex to decimal and vice versa conversion during the DVB-CA configuration.

5. Select the **New Reserved PID** radio button and enter the PID which the CAS vendor has provided for the appropriate elementary stream.
6. Click **OK** to save changes and return to the **Configure Program Mapping** window. ([Figure 235](#))




Figure 235. Configure Program Mapping - PIDs & Program changed - DVB-CA

7. Repeat [Step 3](#) through [Step 6](#) for every elementary stream in the **Configure Program Mapping** window.

- Click **OK** in the **Configure Program Mapping** window to complete the grooming process.

The program with the new reserved PIDs (in hexadecimal format: $b c 3 = 3 0 1 1$; $b c 4 = 3 0 1 2$) will appear in the **Grooming -> Mapping** window as seen in Figure 236 below:




Figure 236. Reserved PIDs to Output (in hex) - DVB-CA

Create Input PSI/SI Table Grooming

- From the **Creating Input Transport Streams** menu (from **Grooming -> Mapping** window, right-click on the Input GigE or ASI port where PSI/SI table information may be found and select **Create Transport Stream**).
- Enter the **IP Address**, and **UDP Port** for the PSI/SI table information.




Figure 237. Create Input TS for PSI/TS - DVB-CA

- Click **OK** to create the transport stream.
- Right click the TS that you just created and select the **Create Ghost Program** option from the popup menu as described in the section titled, “Adding an Unreferenced PID as an Elementary Stream” on page 190.

5. The **Create Ghost Program** screen of Figure 238 appears.




Figure 238. Create Ghost Program - DVB-CA

6. Enter the **Ghost Program Name**. Click **OK**. A new program stream appears under the TS.




Figure 239. Ghost Program in GigE - DVB-CA

7. Right-click the new ghost program and select the **Add Elementary Stream** option from the popup menu.
8. In the **Add Element Stream** window, change the **Stream Category** to *Data*, match the **Stream Type** and **PID** number provided by the CAS.




Figure 240. Add Elementary Stream PIDs - DVB-CA

9. Click **OK** to add the elementary stream to the Ghost program

- Repeat [Step 7](#) and [Step 9](#) for every elementary stream provided by the CAS vendor for which a PSI/SI table must be generated.

When finished, the elementary streams in the ghost program will look similar to [Figure 241](#).




Figure 241. Ghost Program Elementary Streams - DVB-CA

Groom the Ghost Program to Output DVB TS

- Groom the Ghost Program you just created above by dragging the program from the Inputs side of the **Grooming** -> **Mapping** window to the output DVB TS from “Create Output DVB TS(s) for DVB-CA System” on page 244.
- In the **Configure Program Mapping** window that opens, check the **Stay Unreferenced** box.




Figure 242. Configure Program Mapping - Ghost Program - DVB-CA

3. Click **OK** to complete the grooming process.

The **Grooming** -> **Mapping** window will look similar to [Figure 243](#) below:




Figure 243. Output grooming window with ghost program added - DVB-CA


Configure DVB-CA Global Parameters

Before configuring the DVB-CA global parameters, determine if you will be using an external EIS server or the BNP's internal EIS server. External EIS mode requires different setup and menus that are determined in the **DVB-CA Global Configuration** menu. Changing from an external EIS to an internal EIS or vice versa will require a reboot of the BNP and will remove all previously configured DVB-CA encryption streams.

To configure the DVB-CA global parameters, proceed as follows:

1. From the main *Element Manager* window, select **DVB-CA -> Global Configuration**.

The **DVB-CA Global Configuration** window of Figure 244 opens:



The image shows a software window titled "DVB-CA Global Configuration". It has a blue header bar with the title and standard window controls (minimize, maximize, close). The main area has a blue background and contains several configuration fields. On the left, labels are aligned to the right. On the right, there are input fields, some of which are dropdown menus. At the bottom right, there are "Apply" and "Cancel" buttons. The "External EIS Port Number" field has an "Enable" checkbox to its right.

Field Name	Value
Scramble Level:	TS
Crypto Period Duration (100ms):	200
CW Mode:	Conformance 64-bits
CAS Mode:	Broadcast
External EIS Port Number:	<input type="checkbox"/> Enable
EIS Test Timeout:	
EIS Test Interval:	
ECM Test Timeout:	5
ECM Test Interval:	20
EMM Test Timeout:	5
EMM Test Interval:	20
EMMG TCP Control Port Number:	0
EMMG Data Port Number:	0
EMM Multicast IP:	0.0.0.0
Update Timer (secs):	30

Figure 244. DVB-CA Global Configuration - Internal EIS mode default

If an external EIS server is being used (i.e., the **Enable** button in this window checked), the **DVB-CA Global Configuration** window of Figure 245 will appear as follows:

Figure 245. DVB-CA Global Configuration - External EIS mode default

2. Fill out the fields of this window according to the descriptions listed in Table 48.
3. Click **Apply** to save any changes.
4. If the **Enable** button next to the **External EIS Port Number** field has been checked or unchecked, the system will prompt for a reboot. Click **Yes** to accept the reboot.

Table 48 describes the fields available in the **DVB-CA Global Configuration** window.

Table 48. DVB-CA Global Configuration fields

Field	Description	Internal EIS mode or External EIS mode
Scramble Level	Specifies the default scramble level for the BNP chassis. The default is set to TS (transport stream). This field is read-only.	Common to both
Crypto Period Duration (100ms)	Specifies the default crypto period for the BNP chassis in 100 millisecond increments. <ul style="list-style-type: none"> The default is set to 200 (which is 20,000 msecs, or 20 seconds). 	Common to both

Table 48. DVB-CA Global Configuration fields (Continued)

Field	Description	Internal EIS mode or External EIS mode
CW Mode	Specifies the Control Word mode to be used for the BNP chassis. Choose one of the following options from the pull-down menu: <ul style="list-style-type: none"> • <i>Conformance 64-bits, Non-conformance 64-bits, Fixed 0, or Fixed 1.</i> • Default is <i>Conformance 64-bits.</i> 	Common to both
CAS Mode	Specifies the CAS mode for the BNP chassis. Default is <i>Broadcast</i> mode; this field is read-only.	Common to both
External EIS Port Number	Specifies the TCP port number that the BNP will use to connect to the external Event Information System (EIS) server. <ul style="list-style-type: none"> • This field is for an External EIS server to communicate with the BNP. • Default value is 1; valid range is from 1 to 65535. 	External EIS mode only
Enable button	Checking this button will do the following: <ul style="list-style-type: none"> • Switch the DVB-CA system from an internal CAS to an external CAS. • Allow editing of the External EIS Port Number, EIS Test Timeout, and EIS Test Interval fields. Unchecking this button will do the opposite of the above.	Determines if system uses External EIS mode or Internal EIS mode
EIS Test Timeout	Specifies the testing timeout (in seconds) for the external EIS server. Default is 5 seconds.	External EIS mode only
EIS Test Interval	Specifies the interval (in seconds) in which the EIS test timeout will occur. Default is 20 seconds.	External EIS mode only
ECM Test Timeout	Specifies the testing timeout (in seconds) for the Entitlement Control Message Generator (ECMG). Default is 5 seconds.	Common to both
ECM Test Interval	Specifies the interval (in seconds) in which the ECMG test timeout will occur. Default is 20 seconds.	Common to both
EMM Test Timeout	Specifies the testing timeout (in seconds) for the Entitlement Management Message Generator (EMMG). Default is 5 seconds.	Common to both
EMM Test Interval	Specifies the interval (in seconds) in which the EMMG test timeout will occur. Default is 20 seconds.	Common to both
EMMG TCP Control Port Number	Specifies the TCP control port number for the EMMG. Default is 0; valid range is 1 to 65535.	Common to both

Table 48. DVB-CA Global Configuration fields (Continued)

Field	Description	Internal EIS mode or External EIS mode
EMMG Data Port Number	Specifies the UDP number for the EMMG. Default is 0; valid range is 1 to 65535.	Common to both
EMM Multicast IP	Specifies the multicast IP address on which Ethernet Port 2 will receive EMM packets. <ul style="list-style-type: none"> Enter a valid multicast IP address in this field to enable Ethernet Port 2 for receiving EMM packets. Enter all 0's (or leave field at the default of all 0's) to not send EMM traffic via Ethernet Port 2. 	Common to both
Update Timer (secs)	Specifies the amount of time (in seconds) before the BNP should begin to transmit video services in order to allow for encryption processing. <ul style="list-style-type: none"> Default is 30. The higher the number, the longer it will take the end user to receive a video signal. If the number is too low, programming will be transmitted in the clear until the encryption engine takes over. The recommendation is to choose a number that will be an acceptable level of delay for the end user while still providing the minimum amount of clear data transmission. 	Common to both

Configure DVB-CA Tab: External and Internal EIS Mode

Depending on whether or not you have set up your DVB-CA system to use an external EIS server or the BNP's internal server, the menus in the DVB-CA tab are slightly different. The following section provides instructions that are common to both external and internal EIS modes; the end of this section provides instructions on configuration that only applies to internal EIS mode.

1 Create CA System

1. From the main *Element Manager* menu tabs, click on the **DVB-CA** tab to view the **CA System** and **SCG** subtabs.




Figure 246. DVB-CA tab

2. Click the **CA System** subtab.

If no **CA System** has been configured, there will be no “+” expansion icon to the left of the folder icon, as seen in Figure 246.

3. Right-click the **CA Systems** folder and select **Create CA System** from the pop-up menu.




Figure 247. Create CA System popup

4. The **Create CA System** dialog opens:




Figure 248. Create CA System dialog

5. In the **CAS Name** field, enter the desired name for this CAS. This name should be unique across the chassis.
6. In the **CAS ID** field, enter the ID number provided by the CAS.
7. Click **Apply** to save changes.

The new CAS is added to the CA Systems list.




Figure 249. New CAS Added

2 Create ECMG

1. Click the “+” icon next to the name of the CAS you just created (or double-click the name of the CAS) to expand the list:




Figure 250. Expand CAS Name

2. Right-click on the **ECMG List** folder and select the **Create ECMG** option from the pop-up menu:




Figure 251. Create ECMG pop-up

The **Create ECMG** dialog opens:




Figure 252. Create ECMG

3. Fill out the fields according to the descriptions in [Table 49](#).
4. Click **Apply** to save changes and create the ECMG.

5. The new ECMG is added to the ECMG List:




Figure 253. ECMG Added to ECMG List

Table 49 describes the fields available in the **Create ECMG** dialog:

Table 49. Create ECMG dialog fields

Field	Description	Info Provided by:
CAS Name	Specifies the name of the CAS created in the CA Systems subtab. This field is read-only.	CAS
CAS ID	Specifies the CAS ID number created in the CA Systems subtab. This field is read-only.	CAS
Sub CAS ID	Enter the Sub CAS ID for this ECMG. <ul style="list-style-type: none"> Valid range is 0 to 65535; enter 0 if this field is to be ignored. This field is optional. 	CAS
ECMG IP Address	Enter the IP address of the ECMG	CAS
ECMG Port	Enter the UDP number of the ECMG	CAS
Channel Start Offset	Specifies the first channel for the ECMG. <ul style="list-style-type: none"> This field is optional. Valid range is any integer. Default is 0. 	CAS
Channel Count	Specifies the total number of channels this ECMG is currently maintaining. <ul style="list-style-type: none"> This field is optional. Valid range is any integer. Default is 10. 	CAS
Second CAS ID	Enter the second CAS ID (if provided with one) from the CAS. Range is 0 to 65535; enter 0 if not using a second CAS ID. <ul style="list-style-type: none"> This field is optional. 	CAS

3 Create EMMG

1. Under the **CAS Name** folder, Right-click on the **EMMG List** folder and select the **Create EMMG** option from the pop-up menu:




Figure 254. Create EMMG pop-pop

The **Create EMMG** dialog opens:




Figure 255. Create EMMG

2. Enter the **Client ID** number in *decimal format*.

Note: *If this value is being provided by the CAS, you will most likely receive this number in hexadecimal format. You will need to convert the format from hex to decimal in order for this value to properly populate the field.*

3. Click **Apply** to save changes and create the EMMG.

The new EMMG will appear under the **CAS Name** folder:




Figure 256. EMMG Created

i **Note:** A maximum of 4 EMMGs may be created per CAS.

4 Create EMM

1. Under the **CAS Name** folder, Right-click on the **Client ID** folder and select the **Create EMM** option from the pop-up menu:




Figure 257. Create EMM pop-up

The **Create EMM** dialog opens:




Figure 258. Create EMM dialog

2. Fill out the fields according the descriptions listed in [Table 50](#).
3. Click **Apply** to save changes and create the EMM.

The new EMM is added under the Client ID folder:




Figure 259. EMM Created

Table 50 describes the fields available in the **Create EMM** dialog:

Table 50. Create EMM dialog descriptions

Field	Description	Provided by:
Client ID	Displays the value created in the Create EMMG dialog. This value is read-only.	CAS
Data ID	Specifies the unique identification of an EMM / private data stream of a Client ID. Range is 0 to 65535	CAS
Private Data	Enter additional data into the CA descriptor in the PMT. <ul style="list-style-type: none"> For a service, add private data into the program level's CA descriptor. For an ES, add private data into the ES level's CA descriptor. Default is blank. Format must be hex. 	CAS
Second CAS ID	Enter the second CAS ID (if provided with one) from the CAS vendor. Range is 0 to 65535; enter 0 if not using a second CAS ID.	CAS (optionally)
Max Bandwidth (kbps)	Enter the maximum bandwidth that will be allocated by the MUX.	CAS

5 Join TS to EMM

- In the **CA Systems** subtab, drill down to:
CAS Name -> EMMG List -> Client ID.

2. Right-click the desired EMM (preceded by the label, “**Client ID**” and select the **Join/Disjoin TS** option from the pop-up menu:




Figure 260. Join/Disjoin TS - external

The **Join/Disjoin TS to EMM** window opens:




Figure 261. Join/Disjoin TS to EMM window

3. From the right side of the window, expand the GigE or ASI port (by clicking on the + icon or double-clicking the port) in which you created the original DVB TS (See “[Create Output DVB TS\(s\) for DVB-CA System](#)” on page 244.)
4. Highlight the TS and click the left arrow button (<<) next to the port list.




Figure 262. Join/Disjoin TS - port expanded

- The TS is added to the left side of the window with a PID value of 0, which you will need to change.




Figure 263. Join/Disjoin TS - TS added to EMM - No PID

- Click on the TS just added on the left side of the window.
The **PID** field at the bottom of the screen becomes editable.
- Type in a PID value for this TS. The PID value may be any valid PID.
Leaving the **PID** value as 0 will automatically generate a default PID for the entry.




Figure 264. Join/Disjoin TS - PID entry

- After typing in the value, you *must* tap the **<Enter>** key in order to apply the PID change to the TS entry above.

9. The new PID is then reflected in the **Pid** column at the top of the window.




Figure 265. Join/Disjoin TS - PID modified

10. Click **Apply** to complete the process of joining the TS to the EMM.
11. A new EMM program will appear under the TS to which the EMM was joined in the **Grooming** -> **Mapping** window:




Figure 266. EMM Program joined to TS

This completes the process for configuring a DVB-CA system when using an external EIS server. If you are using an internal EIS server, see the section “[Complete DVB-CA Tab Configuration for Internal EIS Mode](#)” on page 265 for additional steps necessary for program scrambling.

6 Verify Scrambling

The best way to verify scrambling is to confirm encrypted streams through the use of an analyzer, however, other methods from the *Element Manager* may be useful.

For example, You can view the channel information being received on the BNP by selecting the following menu path from the DVB-CA tab:

CA System -> CAS Name -> ECMG List -> Sub CAS ID -> Channel.

If scrambling is taking place, you may see stream IDs for each program showing a “*connected*” status (Figure 267).




Figure 267. Stream IDs connected

Depending on the configuration of the DVB-CA system, you may be able to view the elementary stream(s) joined to the SCG in the Service List folder under the SCG tab. Select the following menu path (as seen in [Figure 268](#)) from DVB-CA tab:

SCG -> SCG Group -> SCG -> Service List -> ES Type




Figure 268. SCG List - ESs Scrambled

This completes the DVB-CA configuration process in external EIS mode. See the next section, “[Complete DVB-CA Tab Configuration for Internal EIS Mode](#)” for additional steps required in configuring an internal CAS.

Complete DVB-CA Tab Configuration for Internal EIS Mode

The following steps are additional configuration requirements necessary when setting up a DVB-CA system that uses the BNP’s internal EIS.

1 Create Access Criteria List

Note: *An Access Criteria List is CA system-specific information needed by the ECMG to build an ECM. This is only required for configuration when in internal EIS mode.*

1. From the **CA System** tab, drill down to **CAS Name -> Access Criteria List**.

2. Right-click over the **Access Criteria List** folder and select **Create Access Criteria** from the pop-up menu (Figure 269).




Figure 269. Create Access Criteria pop-up

3. The **Create Access Criteria** dialog of Figure 270 opens.




Figure 270. Create Access Criteria dialog

The **CAS Name** and **CAS ID** fields are read-only and based on the information already entered in the [Create CA System](#) section on page 254.

4. In the **AC Name** field, enter a desired name that is unique to the chassis.
5. In the **AC Data** field, enter the hexadecimal number provided by the CAS.

The AC Data field is a hex number; the following format is an example of the type of number you may receive from the CAS.

[vendor #] [Unique TS ID] [ECM PID]

For example:

0b04 0003 0bc6

6. Click **Apply** to create the **Access Criteria** List.

To view the total count of Conditional Access systems:

1. From the **DVB-CA** menu click on the **CA Systems** tab.
2. Expand the **CA Systems** folder to display a list of CA Systems.

3. Highlight the **Access Criteria List** folder. The **TOTAL ACs** pop-up will give a count of the total number of ACs, as in the example in Figure 271:




Figure 271. Access Criteria List - Total ACs

2 Create SCG

- i Note:** When the DVB-CA system is configured to use an external EIS server, an SCG is automatically created for every program to be encrypted; you can only display the SCG for external EIS mode, not create one.
- i Note:** When the DVB-CA system is configured to use an internal EIS server, an SCG must be manually created. One SCG must be created for every program to be encrypted.

1. From the **SCG** tab, right-click on the **SCG Group** folder and select **Create SCG** from the pop-up menu.




Figure 272. Create SCG pop-up

2. The **Create SCG** dialog of Figure 273 opens:




Figure 273. Create SCG dialog

3. Fill out the information according to the descriptions provided in Table 51.
4. Click **Apply** to create the SCG.
5. Repeat Step 1 through Step 4 for every program to be encrypted.

Table 51 describes the fields available in the **Create SCG** dialog.

Table 51. Create SCG dialog - Internal EIS mode

Field	Description
SCG ID	Specify a unique number that will identify an SCG within the system. Range is 1 to 65534; default is blank.
Transport Stream	Use the Select TS button to select the TS under which the desired programs are to be encrypted. This TS <i>must</i> be a DVB TS. See “Create Output DVB TS(s) for DVB-CA System” on page 244.
CP Duration (100ms)	Specify the Crypto Period for this SCG. Specifies the default crypto period for the BNP chassis in 100 millisecond increments. <ul style="list-style-type: none"> • Check the <i>Use global config</i> box to follow the default parameter as specified in the DVB-CA Global Configuration fields table. • Uncheck the <i>Use global config</i> box to specify a different Crypto Period for the SCG. • Default is set to <i>Use global config</i>.

Table 51. Create SCG dialog - Internal EIS mode

Field	Description
Scramble Level	<p>Specifies the default scramble level used to configure the scrambler for this SCG.</p> <ul style="list-style-type: none"> • TS is currently the only option. • This field is read-only. • <i>Use global config</i> box is read-only and defaulted to checked.
Disable	<p>Checking this button will disable all scrambling on the SCG, changing all scrambled programs to clear.</p> <ul style="list-style-type: none"> • Default is unchecked.

Monitor SCG

The CP Counter can display a **Basic** or **Extension** view of CP counters. The **Basic** view displays data between the SCS and the MUX. The **Extension** view additionally displays counters that are collected between the SCS and the ECMG.

To monitor the SCG:

1. From the **DVB-CA** screen click on the **SCG** tab.
2. Right-click on a selected SCG. A popup menu offers the choice to modify, delete, or monitor an SCG. Click on **Monitor SCG**.
3. The Monitor SCG dialog appears. Use the pull-down menu to choose the **Basic** or **Extension** view, as seen in [Figure 274](#):




Figure 274. Monitor SCG dialog

3 Create ECM

- Note:** When the DVB-CA system is configured to use an internal EIS server, the ECM must be manually created.
- Note:** When the DVB-CA system is configured to use an external EIS server, an ECM is automatically created for each SCG.

1. From the **SCG** tab, drill down to **SCG Group** -> **SCG** -> **ECM Groups**.

2. Right-click on the **ECM Groups** folder and select **Create ECM** from the pop-up menu.




Figure 275. Create ECM pop-up

The **Create ECM** dialog of Figure 276 opens:




Figure 276. Create ECM dialog

3. Fill out the fields according to the descriptions in Table 52.
4. Click **Apply** to create the ECM.

Table 52 describes the fields available in the **Create ECM** dialog.


Table 52. Create ECM dialog


Field	Description
ECM ID	Enter a unique PID (allocated by the MSO) to identify the ECM stream for a Super CAS ID. The combination of the Super CAS ID and the ECM ID uniquely identifies the ECM stream in the system as a whole. <ul style="list-style-type: none"> • Default is blank • Valid range is up to a 10-digit number and must be equal to or greater than 0.
CAS ID	Select the CAS ID from the drop-down box. This value should have been provided by the CAS and configured in the CA System tab.
Sub CAS ID	Select the Sub CAS ID from the drop-down box. This value should have been provided by the CAS and configured in the CA System tab.

Table 52. Create ECM dialog

Field	Description
Private Data	Enter additional data into the CA descriptor in the PMT. <ul style="list-style-type: none"> • For a service, add private data into the program level's CA descriptor. • For an ES, add private data into the ES level's CA descriptor. • Default is blank. • Format must be hex.
Access Criteria	Select the name of the Access Criteria from the drop-down menu created from the Access Criteria List menu.
PID	Enter the PID to use for the ECM. <ul style="list-style-type: none"> • Default is blank. • Valid range is 52 to 8175.

4 Join Program and ES to the SCG

 **Note:** When the DVB-CA system is configured to use an internal EIS server, each elementary stream or program must be joined to the SCG.

 **Note:** When the DVB-CA system is configured to use an external EIS server, the elementary stream(s) or program are automatically joined to an SCG.

1. From the **SCG** tab, drill down to **SCG Group -> SCG -> Service Lists**.

2. Right-click on the **Service Lists** folder and select **Join Program and ES** from the pop-up menu.




Figure 277. Join Program and ES pop-up

The **Select service list and ES list Objects** dialog of Figure 278 opens:




Figure 278. Select service list and ES list Objects dialog

3. Select the program you wish to encrypt from the list of programs available for this TS. Programs unavailable for encryption will be grayed out.

Additionally, you may select an ES to encrypt by drilling down on the program level and selecting the desired ES as seen in [Figure 279](#).




Figure 279. Select service list and ES list Objects - ES level

4. Click **Apply** to join the program or ES to the SCG.

5 Verify Scrambling

To verify programs are being scrambled, follow the steps in the previous section, “[Verify Scrambling](#)” on [page 264](#).

DVB-CA Best Practices and Considerations

The following guidelines should be taken into consideration when setting up a DVB-CA system:

- In a BNP redundancy configuration only the primary BNP is connected to the EIS, ECMG, and EMMG servers.
- During switchover the old primary (now standby) disconnects to CA servers and the new primary reconnects to them.
- The Update Timer is used to avoid sending clear streams during boot up & switchover because the boot up time and CAS reconnection time vary from configuration to configuration.
- It is recommended that Ethernet Port 2 be connected downstream of an IP switch such that multicast traffic does not spill onto the CAS network and flood the EMM and ECM traffic.
- The BNP can optionally be configured to receive EMM traffic via a multicast socket on Ethernet Port 2.
- Virtual IP configuration for Ethernet Port 2 must be configured when using 1:1 chassis redundancy; this virtual IP address must be used by CA servers (external EIS and ECMG configuration).

Monitoring the BNP

This chapter describes information about the system that you can monitor to ensure that the system is always healthy. The **Alarms & Events** tab provides system information and health status.

To view other information about the BNP3xr, use the other BNP *Element Manager* windows. A complete discussion of the BNP *Element Manager* begins in “Using the Element Manager” on page 34.

In This Chapter:

- “Selecting the Elements to View,” next.
- “Viewing Alarms and Events” on page 275.
- “The Status Bar” on page 277.

Selecting the Elements to View

The upper portion of the **Alarms & Events** tab lets you define the information you want to see on the screen. You can select as many options as you choose. The information is cumulative. To sort alarms and events, click the table header. The BNP *Element Manager* re-sorts the information according to your selection.

Once you have selected the events to display, click **Apply Filter** to accept the changes and refresh the window.

Types of alarms and events that can be displayed include:

- **All** shows all alarms and events, regardless of severity
- **Raised** shows all alarms that have been raised, but not cleared
- **Cleared** shows all alarms that have been raised and cleared
- **Critical** shows only critical severity alarms; these are alarms that must be dealt with immediately
- **Major** shows major alarms; these are alarms that may not require immediate intervention but cannot be allowed to continue indefinitely
- **Minor** shows minor alarms that will not disrupt the system

Viewing Alarms and Events

After you have set the types of alarms to display, you can tab to Alarms & Events at any time to see the current state of the system. [Figure 280](#) shows a typical alarms window.

For each alarm, you see a description, status, severity, source, cleared time (if the alarm has been cleared), any comment, and the user who cleared the alarm.

Note: Only those alarms whose levels have been checked (Figure 280) will be displayed. The others will be hidden until checked.

Cleared events remain in the list for historical purposes.

Index	Description	Severity	Status	Source	Date and Time	Cleared Time	Comment	User
1	Input TS is missing.	Major	Raised	Gige2 239.9.9.9 500	01/28/10 15:35:08 PST			System
2	Input TS is missing.	Major	Raised	ASI D5	01/28/10 15:35:08 PST			System
3	Input TS is missing.	Major	Raised	ASI D4	01/28/10 15:35:08 PST			System
4	Input TS is missing.	Major	Raised	ASI D3	01/28/10 15:35:08 PST			System
5	Input TS is missing.	Major	Raised	ASI D2	01/28/10 15:35:08 PST			System
6	Input TS is missing.	Major	Raised	ASI C6	01/28/10 15:35:08 PST			System
7	Input TS is missing.	Major	Raised	ASI C5	01/28/10 15:35:08 PST			System
8	Input TS is missing.	Major	Raised	ASI C3	01/28/10 15:35:08 PST			System
9	Input TS is missing.	Major	Raised	ASI C1	01/28/10 15:35:08 PST			System
10	Power supply is not prese...	Minor	Cleared	Power supply 2 is not present.	01/28/10 15:35:17 PST	01/28/10 15:40:41 PST		System
11	Ethernet port 2 link fault.	Major	Raised	Ethernet port 2 link fault.	01/28/10 15:35:17 PST			System
12	Power supply is in bad sta...	Major	Cleared	Power supply 2 is in bad state	01/28/10 15:40:51 PST	01/28/10 16:20:10 PST		System
13	Power supply is in bad sta...	Major	Cleared	Power supply 1 is in bad state	01/28/10 15:58:58 PST	01/28/10 15:59:43 PST		System
14	Power supply is removed.	Major	Cleared	Power supply 1 is removed.	01/28/10 15:59:43 PST	01/28/10 16:18:14 PST		System
15	Power supply is removed.	Major	Cleared	Power supply 1 is removed.	01/28/10 16:18:22 PST	01/28/10 16:18:36 PST		System
16	Power supply is removed.	Major	Cleared	Power supply 1 is removed.	01/28/10 16:18:48 PST	01/28/10 16:18:54 PST		System
17	Power supply is in bad sta...	Major	Cleared	Power supply 1 is in bad state	01/28/10 16:19:06 PST	01/28/10 16:19:11 PST		System
18	Power supply is removed.	Major	Cleared	Power supply 1 is removed.	01/28/10 16:19:11 PST	01/28/10 16:19:21 PST		System
19	Power supply is removed.	Major	Cleared	Power supply 1 is removed.	01/28/10 16:19:29 PST	01/28/10 16:19:41 PST		System
20	Power supply is removed.	Major	Raised	Power supply 2 is removed.	01/28/10 16:20:10 PST			System
21	Input TS is missing.	Major	Cleared	Gige2 238.8.8.8 8888	01/28/10 18:20:22 PST	01/28/10 18:20:25 PST		System
22	Input TS is missing.	Major	Cleared	Gige2 239.11.11.11 1111	01/28/10 18:20:22 PST	01/28/10 18:20:26 PST		System
23	Input PID is missing,audio...	Major	Raised	Gige7 236.8.8.8:8888 1 output audio pid ...	01/28/10 18:20:24 PST			System
24	Input TS is missing.	Major	Cleared	Gige2 238.8.8.8 8888	01/29/10 14:40:41 PST	01/29/10 14:40:41 PST		System
25	TDT/TOT input Source is n...	Major	Raised	Gige1 224.2.2.2 2222	01/29/10 14:59:25 PST			System
26	NIT source is not configured	Major	Raised	Gige1 224.2.2.2 2222	01/29/10 14:59:25 PST			System
27	Input TS is missing.	Major	Cleared	Gige2 238.8.8.8 8888	01/29/10 17:02:33 PST	01/29/10 17:02:35 PST		System
28	Input TS is missing.	Major	Cleared	Gige2 239.11.11.11 1111	01/29/10 17:02:33 PST	01/29/10 17:02:35 PST		System
29	Input PID is missing,audio...	Major	Raised	Gige1 235.3.3.3:5333 3 output audio pid ...	01/29/10 17:02:34 PST			System
30	Input PID is missing,audio...	Major	Raised	Gige7 236.8.8.8:8888 1 output audio pid ...	01/29/10 17:02:34 PST			System
31	Input PID is missing,audio...	Major	Raised	Gige1 235.3.3.3:5333 2 output audio pid ...	01/29/10 17:02:34 PST			System

Figure 280. Alarms & Events tab

Alarms and Events

The following alarms are available:

- Video underflow
 - PID missing
 - Grooming failed
- Missing input-Missing PAT/PMT, this could be caused by:
 - A disconnected cable
 - A TS packet missing or lost

- Input GigE not operational
- Cooling system failure
- Failure of ad insertion/splicing
- Postblack duration from ad server ignored or greater than four seconds

The four severity levels include **info**, **minor**, **major**, and **critical**.

The Status Bar

The status bar is visible regardless of the tab selected. This ensures that you can see if there are any critical alarms that need attention. The bottom portion of the window displays the IP address to which the BNP *Element Manager* is connected and the highest-priority current alert. The information is color-coded. A green IP address section indicates that the connection is active.

For alarms, the color-coding is one of the following:

- **Green** indicates that the alert or event displayed is informational.
- **Yellow** indicates a situation that might need operator action.
- **Pink** indicates a major alarm requiring operator attention.
- **Red** indicates a critical error has occurred and immediate operator intervention is needed.




Figure 281. The status bar

Troubleshooting

This chapter describes error detection and correction procedures.

In This Chapter:

- “LED Indicators,” next.
- “Event Log Analysis” on page 280.
- “Software Upgrade” on page 280.
- “Contacting RGB Customer Support” on page 280.

LED Indicators

The LED indicators are fully described in “LED Indicators” on page 17. These should be your first line of inquiry if any BNP3xr component is not performing correctly.




Figure 282. LED Indicator Locations

Table 53. LED Indications

Indication	Possible Solution
An LED indicator for one of the GigE ports is off.	Verify that the module is installed correctly and has power.
The LED indicator for the 10/100 BaseT port is off.	Verify that the module is installed correctly and the 10/ 100 BaseT port cable is connected correctly.

Table 53. LED Indications (Continued)

Indication	Possible Solution
The system power LED indicator is off.	Verify that the power cord is correctly installed and that the power is turned on.
The LED indicator for the compact flash is blinking red	Install a compact flash card.
The LED indicator for the compact flash is solid red.	A flash error has occurred or the flash module is corrupted and needs to be reformatted or replaced.

Event Log Analysis

If asked to do so by technical support, access the event log. You will be instructed on this procedure by the technical support engineer.

Software Upgrade

Use the *Element Manager* to upgrade any software image of the BNP3xr. See “Upgrading Software” on page 107 for details about upgrading software.

Contacting RGB Customer Support



Note: For BNP products or software purchased through other distribution partners, please contact their customer service for product support.

Before you contact Customer Support, have the following information handy:

- Serial number of the AC power supply.
- A clear description of the problem.
- Steps to reproduce the problem, if applicable.

Customers who purchased their product directly from RGB Networks, or have purchased extended product support directly from RGB Networks should contact Customer Support via one of the following methods:

Table 54. Contacting Customer Support

Method	Details
Phone	+1 (877) RGB-NETW (877-742- 6389) or +1 (408) 701-2800
Customer Portal	http://support.rgbnetworks.com
Email	support@rgbnetworks.com

Searching the RGB Customer Portal

To search the RGB Customer Portal for a specific document or solution, proceed as follows:

1. Log in to the [RGB Customer Portal](#) site.

RGB Customer Portal

Welcome! You've arrived at the login page for RGB's Support Services. Here you will be able to:

- Create and track your own case reports
- Search our knowledge base for helpful information
- Download useful product documentation

Please note: RGB Customer Portal access is available to direct customers and resellers only. If you purchased your RGB equipment through a channel, please [go here](#).

Secure Customer Login

User Name:

Password:

[Forgot your password?](#)

[Not registered yet? Request login credentials here.](#)

Figure 283. RGB Customer Portal home page

2. From the Customer Portal homepage, click on the **Knowledge Base** tab:




Figure 284. Customer Portal home page - Direct and Reseller

3. From the **Knowledge Base** homepage, enter the desired search term in the **Search** box and tap the [Enter] key:




Figure 285. Knowledge Base search - Direct and Reseller

Field-replaceable Units

This chapter provides instructions on replacing the Field-replaceable Units (FRUs).

In This Chapter:

- “Overview,” next.
- “Replacing a Power Supply” on page 284.
- “Replacing a Fan Tray” on page 287.
- “Replacing a Gigabit Ethernet Processor (GBP3) Module” on page 289.
- “Replacing a Processor Module (PROC3) or an ASI Module” on page 290.

Overview

There are four replaceable units on the BNP3xr, shown in [Figure 286](#). The removal and replacement procedure is provided for each.




Figure 286. Top view of chassis, with FRUs visible

The GBP3 module is located underneath the fan trays; its design is shown below in [Figure 287](#)




Figure 287. Gigabit Processor - 3 Module

Always wear an ESD wristband or use an electrostatic mat when working with electronic components.

The chassis does not need to be removed from the rack to replace a FRU, but the system **must** be powered down before beginning any replacement process.



Warning: *Never replace any FRU while the chassis is still connected to the power source.*

If replaced items need to be configured, see [Chapter 4, “System Configuration.”](#)



Warning: *Do not replace any component (such as fuses) not specifically described here. For replacement beyond the FRU level, contact your technical support representative for instructions on returning the component. (See “[Contacting RGB Customer Support](#)” on [page 280.](#))*

Replacing a Power Supply

The power supplies are located at the rear of the BNP3xr chassis. Any time that the chassis is not receiving adequate power, as indicated by the system LEDs and performance, verify that power is reaching the chassis.

If power is reaching the power supply but not getting to the system, you might need to replace one or both power supplies.



Note: *The BNP3xr operates in normally with just one power supply; the addition of a second power supply allows for redundancy support and is either a field or factory upgrade option.*

Removing a Power Supply

The basic procedure for removing a power supply is similar regardless of whether the power supply is for AC or DC power.

To remove a failed power supply:

1. Ensure that you have a replacement power supply ready to reinsert.
2. If you have installed dual redundant power supplies, skip [Step 3](#) and proceed to [Step 4](#).

3. Ensure that there is no power to the unit:
 - AC power supply units - Shut down the unit by removing the power cable from the power supply connector.
 - DC power supply units - Toggle the circuit breaker to the OFF position. Disconnect the cables from the power connector.
4. Loosen the power supply unit by turning the safety screw *clockwise*.



Note: *Turning the screw counterclockwise tightens the screw. Use a slotted screwdriver to tighten or loosen the screw, then use your fingers to further turn the screw, if necessary.*

5. Firmly grasp the power supply by the handle, shown in Figure 288.




Figure 288. Power supply handle (AC power supply)




Figure 289. Power supply handle (DC power supply)

6. Pull gently but firmly, sliding the power supply out of the bay as shown in [Figure 290](#).




Figure 290. Power supply removal (AC power, left; DC power, right)

Inserting a Power Supply

Once you have removed the failed power supply, install a replacement:

1. Remove the replacement power supply from its packing and carefully inspect it for damage.
Do not install a visibly damaged power supply.

2. Slide the replacement power supply into the slot




Figure 291. Power supply insertion (AC power, left; DC power, right)

3. Turn the screw counterclockwise to tighten it, securing the power supply to the BNP3xr chassis.
4. Connect power to the power supply:
 - For AC power supplies, refer to [“Connecting AC Power to the BNP3xr”](#) on page 26.
 - For DC power supplies, refer to [“Connecting DC Power to the BNP3xr”](#) on page 27.

Replacing a Fan Tray

The two fan trays in the BNP3xr are redundant and hot-swappable; however, normal BNP3xr operation is such that both fan trays should be operational at all times. A fan tray may be safely removed or replaced as long as the BNP3xr remains within the normal operating temperature range (see the section, titled [“Environmental”](#) on page 296 for details on operating temperature).

To replace a fan tray, proceed as follows:



Note: *The front bezel does not need to be removed when replacing a fan tray.*

1. Using a slotted or Phillips screwdriver, loosen the captive screw located above the fan tray handle.




Figure 292. Fan tray removal

2. Use the handle to pull out the fan tray assembly.
3. Insert the new fan tray assembly provided by RGB.
4. Tighten the captive screw using a slotted or Phillips screwdriver.




Figure 293. Fan tray replacement

Replacing a Gigabit Ethernet Processor (GBP3) Module

When you have determined that a GBP3 module must be replaced, follow this procedure to remove and replace the module. You do not need to remove the chassis from its rack mount to replace a module.

Removing a GBP3 Module

1. Ensure that you have a replacement module available, then shut down the unit by removing the power cable from the power supply connector.
2. Remove all cabling from the module.
3. Grasping it firmly with your fingers, gently remove the bezel on the front of the chassis, as shown in Figure 294.




Figure 294. Front bezel removal

4. Using a Phillips screwdriver, loosen—but do not remove—the screws that secure both sides of the GBP3 module to the chassis. They act as handles to assist with the module's removal.




Figure 295. Loosen the GBP3 module release screws

5. Firmly grasping the screws, slide the GBP3 module out of the bay, as shown in Figure 296.




Figure 296. GBP3 module removal

Replacing a GBP3 Module

After you have removed the failed GBP3 module, replace it with the new one:

1. Grasp the module firmly by the edges only and slide it into the chassis, using the plastic guide rails to ensure proper seating.
2. Push until the module is firmly seated.
3. Using a Phillips screwdriver, tighten the insertion/removal screws to secure the GBP3 module to the BNP3xr chassis.
4. Replace the front bezel by snapping it in place.
5. Restore any cabling and power up the unit.

Replacing a Processor Module (PROC3) or an ASI Module

i Note: *The BNP3xr supports both ASI and ASI2 modules.*

Removing and replacing either a PROC3 module or an ASI module uses the same procedure.

- If you are adding a new PROC3 or ASI module to an existing but underpopulated chassis, insert the card into the next designated slot.
- If you are replacing a failed unit, simply replace that unit regardless of the slot it occupies.

Removing a PROC3 or ASI Module

1. Shut down the unit by removing the power cable from the power supply connector.
2. Using a Phillips screwdriver, loosen—but do not remove—the insertion/removal screws, shown in Figure 297.




Figure 297. Loosen the insertion/removal screws

3. Using the handles on either side of the module as a grip, gently but firmly slide the module out of the chassis, as shown in Figure 298.




Figure 298. Remove the module

Replacing a PROC3 or ASI Module

After a PROC3 module has been removed, replace it as soon as possible, or install a blank slot cover to ensure proper air flow.

If you are leaving an empty slot, any empty slot should be fitted with a blank cover.



Caution! *ASI modules should always be replaced; no filler should be used.*

To install a PROC3 or ASI module:

1. Firmly hold the card by the edges or the handles and slide it into the chassis, using the plastic guide rails to ensure proper seating.
2. Press firmly until the module seats in the chassis.




Figure 299. Install the ASI or PROC3 module (ASI shown)

3. Using a Phillips screwdriver, tighten the insertion/removal screws to attach the card to the chassis.
4. Restore any cabling and power up the unit.
5. Reboot the system as described in [“Rebooting the System”](#) on page 116.

Specifications

This chapter provides the system specifications for the BNP3xr.

In This Chapter:

- “Input Interfaces/Output Interfaces,” next.
- “MPEG Processing” on page 293.
- “Video Formats” on page 294.
- “Audio Formats” on page 294.
- “Regulatory Compliance” on page 296.
- “Electrical/Mechanical” on page 296.
- “Environmental” on page 296.

Input Interfaces/Output Interfaces

Table 55. Input/Output Interfaces

Interface	Type
Gigabit Ethernet	8 SFP interfaces (copper or optical) configured
Fast Ethernet	2 10/100BaseT control and management interface
ASI	Up to 18 ASI ports per chassis
	Up to 3 ASI modules with 6 ASI ports each
	Software configurable as input or output
	213 Mbps data rate/port

MPEG Processing

Table 56. MPEG Processing

MPEG	Supported Format
Transrating	SD and HD MPEG-2 video streams
	VBR and CBR support
	QoS - Ability to set priority for the level of transrating desired

Table 56. MPEG Processing (Continued)

MPEG	Supported Format
Multiplexing and Table Processing	MPEG-2 and MPEG-4 H.264/AVC multiplexing and re-multiplexing
	MPTS, SPTS, multicast and unicast support
	CBR and VBR support
	PID filtering and remapping
	PCR restamping and de-jitter
	Generation and pass-through of PSIP tables
	PAT and PMT generation
DPI	Seamless SD and HD splicing
	SCTE 30 (DVS-380, DVS-638) and SCTE 35 (DVS-253) compliant
	SCTE 30 to SCTE 35 conversion
	Text and graphical crawl messages and graphical logo overlays
	SCTE 18 (Emergency Alert Message for cable)
	SCTE 21 to SCTE 20 conversion
Jitter Tolerance	+/- 100 ms

Video Formats

Table 57. Video Formats

Video	Supported Format
MPEG Profile and Level	MPEG-2 MP@ML (SD) and MP@HL (HD) MPEG-4 H.264/AVC (all profiles supported)
All SD and HD resolutions	SD – 720 x 576, 720 x 480, 704 x 480, 544 x 480, 528 x 480, 352 x 480 HD – 1080i x 1920, 1080i x 1440, 1080i x 1280, 720p x 1280, 480p x 720, 480p x 704, 480p x 640
Frame Rates	24, 25, 29.97, 30, 50, 59.94, 60

Audio Formats

Table 58. Audio Formats

Audio	Supported Format
Audio Format	Dolby AC-3, MPEG-1 Layer 2 (Musicam) and MPEG-2, MPEG-2 AAC, MPEG-4 HE-AAC

Elementary Stream Types & Conversions

Table 59. Elementary Stream Types & Conversions

Output Transport Stream (TS) Type	Video ^a	Audio ^b	Data
MPEG2	MPEG2 video (0x2) <i>Converts to 0x2 if input video has type 0x80.</i> H.264 (0x1B)	MPEG1 audio (0x3) MPEG2 audio (0x4) ATSC AC-audio (0x81) DVB AC-3 audio (0x6) AAC (0x0f) HE-AAC (0x11)	0x5 ~ 0xff
ATSC	MPEG2 video (0x2) SCTE video (0x80) H.264 (0x1B)	MPEG1 audio (0x3) MPEG2 audio (0x4) ATSC AC-audio (0x81) <i>Converts to 0x81 if input AC-3 audio has type 0x6.</i> AAC (0x0f) HE-AAC (0x11)	0x5 ~ 0xff
SCTE	SCTE video (0x80) <i>Converts to 0x80 if input video has type 0x2.</i> H.264 (0x1B)	MPEG1 audio (0x3) MPEG2 audio (0x4) ATSC AC-audio (0x81) <i>Converts to 0x81 if input AC-3 audio has type 0x6.</i> AAC (0x0f) HE-AAC (0x11)	0x5 ~ 0xff
DVB	MPEG2 video (0x2) <i>Converts to 0x2 if input video has type 0x80.</i> H.264 (0x1B)	MPEG1 audio (0x3) MPEG2 audio (0x4) DVB AC-3 audio (0x6) <i>Converts to 0x6 if input AC-3 audio has type 0x81.</i> AAC (0x0f) HE-AAC (0x11)	0x5 ~ 0xff

a. For H.264 video, the stream type will be passed through regardless of input or output TS type.

b. For AAC and HE-AAC audio, the stream type will be passed through regardless of input or output TS type.

Digital Broadcast

Table 60. Digital Broadcast

DVB	Supported Format
Digital Broadcast	ATSC PSIP, (A/52B, A/53E, A/58, A/65) DVB (DVB-SI, DVB-SUB, DVB-TXT, CSA and Simulcrypt)

Regulatory Compliance

Table 61. Regulatory Compliance

Regulatory Type	Compliance
Safety	UL 60950-1:2007; CAN/CSA-C22.2 No. 60950-1-07; TUV/GS, cTUVus: IEC 60950-1:2005, EN 60950-1:2006+ A11
Electromagnetics	FCC - Title 47 CFR Part 15 Subpart B; Canada ICES-003, Issue 2, April 1995
Hazardous Substances	RoHS-compliant (Restricted use of Hazardous Substances)

Electrical/Mechanical

Table 62. Electrical and Mechanical

Specification	Limits
Maximum Input Power Limits	AC: 100-240V; 8.8A; 50/60Hz; Class 1 DC: 36-72V; 15.7A; Class 1
Line Frequency	50-60 Hz
Power consumption	400 W maximum, fully loaded chassis at 110 V AC
Dimensions	2RU (3.5" H x 19" W x 23.25" L) (88 H x 444 W x 590.4 L mm)
Weight	38.7 lbs. (17.6 kg)
Cooling	Front to back; BTU: 2900 BTU/hour maximum

Environmental

Table 63. Environmental Ranges

Condition	Value Range
Storage Temperature	-40° C to 70° C
Operating Temperature	0° C to 40° C
Humidity	5% to 95% (non-condensing)
Noise Emissions (In accordance with ISO 9296)	LWAd (iB=10dB) 7.2 B 6.9 B LpAm (TBD) 58.1 dBA 55.3 dBA

Editing the DVB NIT Table

This appendix shows you how to edit, make additions to, and delete items from the NIT table, one of the DVB tables. To understand the meaning and context of the various values in the table, consult one or both of the following documents:

- *Digital broadcasting systems for television, sound and data services; Allocation of Service Information (SI) codes for Digital Video Broadcasting (DVB) systems*, ETSI Technical Report, ETR 162, European Telecommunications Standards Institute, October 1995.
- *Digital Video Broadcasting (DVB); Specification for Service Information (SI) in DVB systems*, ETSI EN 300 468 V1.5.1 (2003-05), European Telecommunications Standards Institute.

In This Appendix:

- “NIT Values Supported,” next.
- “Naming, Viewing, Deleting and Editing NIT Configuration Files” on page 300.
- “Suggestions for Editing the NIT Table” on page 311.

NIT Values Supported

Table 64 shows the NIT values Mandatory values are indicated with an asterisk (*).

Table 64. Values Supported

NIT Section	Value Name	Default	Range
nit_section	network_id	100	
	Version_Number	1	
	*current_next_indicator	1	
Array of network_name:	*name	my network name	Any name
Array of linkage:	*Transport stream ID	1	Any value that fits in 16 bits
	*original_network ID	129	Any value that fits in 16 bits
	*service_id	16642	Any value that fits in 16 bits
	*linkage_type	9	Any value that fits in 16 bits
Array of private_data_byte:	data	private1	Array of bytes of hex integers (if type is 8 or 9). Else it is char string

Table 64. Values Supported (Continued)

NIT Section	Value Name	Default	Range
Array of Frequency List	*coding_type	2	0 (not defined), 1(Satellite), 2 (cable) and 3 (terrestrial)
	*Center_frequency:	3300000	32 bit unsigned integers
	*Private_data:	private_data_1	32 bit unsigned integer (currently defined values are) 1 (SES), 2 (BSKYB1), 3(BSKY2), 4(BSKY3) BE (BetaTechnik), 0x6000 (News DataCom), 0x6001(NDC1), 0x6002(NDC2), 0x6003(NDC3) 0x6004(NDC4), 0x6005(NDC5), 0x6006(NDC6) 0x362275(Irdeto) 0x4E544C(NTL) 0x532D41(SFA) 0x44414E59(NEWS DATACOM), 0x46524549(NEWS DATACOM) 0x53415053 (SFA)
Array of Transport Stream	*transport stream id	769	Any value that fits in 16 bits
	*original network id	1920	Any value that fits in 16 bits
Array of service:	id	16398	Any value that fits in 16 bits
	type	1	1 to 0x10 and 0x80 to FE 1(digital television service)
	*id	16403	Any value that fits in 16 bits
	*type	1	1 to 0x10 and 0x80 to FE 1(digital television service)
Cable delivery system:	*frequency	6312500	Up to 8 digit (decimals) value in MHz
	*FEC_Outer	2	4 bit integer 0,1, 2
	*modulation	4	8 bit integer (00, 01, 02,03, 04 and 05)
	symbol_rate	68750	7 digit (decimals) integer specifying symbols/ second
	*FEC_Inner	5	4 bit integer 0 (not defined),1 (1/2 conv code rate), 2(2/3), 3 (3/4), 4 (5/6), 5 (7/8), 6 (8/9), F (no conv Coding)
Satellite Delivery System	*frequency	1208400	up to 8 digits (decimal) value in GHz
	orbital_position	970	up to 4 digit (decimal) value orbital position. A decimal occurs after the third character
	west_east_flag	0	0 or 1 (0 indicates western, 1 indicates eastern)
	polarization	1	0 (linear horizontal), 1 (linear vertical), 2 (circular left) or 3 (circular right)
	modulation	1	0 (not defined), 1 (QPSK), 2 (8 PSK) or 3 (16 QAM)
	symbol_rate	220000	7 digit value specifying mega symbol/sec (decimal (imaginary) occurs after third digit)
	FEC_Inner	3	4 bit integer 0 (not defined),1 (1/2 conv code rate),2 (2/3), 3 (3/4), 4 (5/6), 5 (7/8), 6 (8/9), F(no conv Coding)

Table 64. Values Supported (Continued)

NIT Section	Value Name	Default	Range
Terrestrial Delivery System	centre_frequency	739000000	32 bit integer (expressed in multiple of 10Hz)
	bandwidth	0	0 (8 MHz), 1 (7 MHz) or 2 (6 MHz) (3 bit field)
	constellation	2	0 (QPSK), 1 (16 QAM), 2 (64 QAM) (2 bit field)
	*hierarchy_information	0	0 (non hierarchical), 1 (alpha = 1), 2 (alpha = 2), 3 (alpha=4) (3 bit field)
	code_rate-HP_stream	0	0 (1/2), 1 (2/3), 2 (3/4), 3 (5/6), 4 (7/8) (3 bit field)
	code_rate-LP_stream	0	0 (1/2), 1 (2/3), 2 (3/4), 3 (5/6), 4 (7/8) (3 bit field)
	*guard_interval	3	0 (1/32), 1 (1/16), 2 (1/8) or 3 (1/4) (2 bit field)
	transmission_mode	1	0 (2k mode) or 1 (8k mode) (2 bit field)
	*other_frequency_flag	1	0 (no other frequency in use) or 1 (more than one frequency in use)
Array of Private Data	data	1	32 bit unsigned integer (currently defined values are) 1 (SES), 2 (BSKYB1), 3 (BSKY2), 4 (BSKY3) BE (BetaTechnik), 0x6000 (News DataCom), 0x6001 (NDC1), 0x6002 (NDC2), 0x6003 (NDC3) 0x6004 (NDC4), 0x6005 (NDC5), 0x6006 (NDC6) 0x362275 (Irdeto) 0x4E544C (NTL) 0x532D41 (SFA) 0x44414E59 (NEWS DATACOM), 0x46524549 (NEWS DATACOM) 0x53415053 (SFA)
Array of Frequency List	coding_type	2	0 (not defined), 1 (Satellite), 2 (cable) and 3 (terrestrial)
	Center_Frequency	1300000	

Naming, Viewing, Deleting and Editing NIT Configuration Files

Naming a Configuration File

An opening window with no files named is shown in [Figure 300](#). The default configuration file is present.




Figure 300. Window With No Arrays

To name a configuration file:

1. Click **Edit**. The default configuration file appears (Figure 301).




Figure 301. Default Array

2. Now enter a name for the file in the **Name** space, in this case *Array2*.
3. Click **Apply**.

The configuration file is named as Array2. (Figure 302).




Figure 302. Array2 Added

Viewing a Configuration File

You can view an configuration file in XML format.

1. In [Figure 302](#), choose View NIT in XML Format. A window similar to [Figure 303](#) appears.

```

?xml version="1.0" encoding="UTF-8" ?>
<nit xmlns="http://www.example.org/nit" xmlns:x0="http://www.w3.org/2001/XMLSchema">
  <nit_section current_next_indicator="1" network_id="100" version_number="1.0" />
  <network_name name="my network name" />
  <linkage linkage_type="5" original_network_id="129" service_id="16642" transport_stream_id="1">
    <private_data_byte data="01" />
    <private_data_byte data="02" />
  </linkage>
  <frequency_list coding_type="2">
    <centre_frequency frequency="3300000" />
    <centre_frequency frequency="3500000" />
  </frequency_list>
  <private_data data="1" />
  <transport_stream original_network_id="1920" transport_stream_id="769">
    <service_list>
      <service id="16398" type="01" />
      <service id="16403" type="01" />
    </service_list>
    <cable_delivery_system FECInner="5" FECOuter="2" frequency="6312500" modulation="04" symbolrate="68750" />
    <private_data data="1" />
  </transport_stream>
  <frequency_list coding_type="2">
    <centre_frequency frequency="1300000" />
    <centre_frequency frequency="1500000" />
  </frequency_list>
</nit>

```

Figure 303. NIT Configuration File Viewed in XML Format

2. Navigate to where the arrays are stored and click **Open**. The window of [Figure 304](#) appears.




Figure 304. Assigning a Name to a Configuration File

3. Assign the name you want to the Array. In this example, we chose *Array2*.

Deleting a Configuration File

1. To delete an array, highlight the array to be deleted in [Figure 302](#).
2. Click **Delete**.
3. The delete confirmation box appears ([Figure 305](#)).




Figure 305. Delete Confirmation

4. Click **Yes** if you want to delete the configuration file

The Array is deleted.

Editing a Configuration File

1. Highlight the configuration file you want to edit (Figure 306).



Figure 306. Setup Network Information Table screen

2. Click **Edit**. The window of Figure 307 appears.




Figure 307. Editing Window

Icon Menu

Figure 308 shows the icons appearing at the top of the window.




Figure 308. Icon Menu

Figure 309 shows the Namespace Qualifiers window, obtained when you click the Namespace Qualifier icon




Figure 309. Namespace Qualifier Window

Figure 310 shows the Search window, obtained when you click the Search icon.




Figure 310. Search Window

Expanding the NIT Edit Window

The vertical bars shown in the window of [Figure 307 on page 304](#) are used to toggle between an expanded and reduced view. through show three layers of expansion. Clicking the large vertical bar compresses the display as shown in [Figure 311](#).




Figure 311. Large Vertical Bar Clicked Fully Compress

[Figure 312](#) shows the first level of expansion from [Figure 307 on page 304](#), obtained by clicking all of the small bars to the right of the large bar.




Figure 312. First Level of Expansion

Clicking all of the smaller bars in Figure 312 creates the second level of expansion shown in Figure 313.

Figure 313. Second Level of Expansion

Clicking the smaller bars in Figure 313 creates the third level of expansion shown in Figure 314.

Figure 314. Third Level of Expansion

Inserting a Node

To insert a node, select the node and click **Insert Node Before** (Figure 315).




Figure 315. Inserting a Node Before

Figure 316 shows the result.




Figure 316. Node Inserted Before

In the node that was added, we attempted to change the value of the transport stream to an alpha value, 'a.' An error message resulted (Figure 317).




Figure 317. Error Message from Wrong Type of Data Character

Using the proper data types we changed the values so they are different from the original (Figure 318).




Figure 318. Data Type Mismatch Corrected

Deleting a Node

You can delete a node. In the example, highlight the linkage to be deleted and click Remove Node. The node is deleted (Figure 319).




Figure 319. Linkage Deleted

Suggestions for Editing the NIT Table

The following are some suggestions that may prove helpful in editing the NIT table:

- In editing fields, go to the next tab to apply.
- When adding new nodes or fields, it is easiest to right click on the node to be added, then choose **Insert**.
- Uncheck optional fields if they are not needed.


Localized Cautions and Warnings

This appendix provides all of this manual's Caution and Warning statements in French and German.



Page number	Statement type	Statement
Page 16	Warning	Whenever computer components are handled (especially during installation), the equipment can be damaged by the buildup of static electricity. Take precautions before touching any internal components or boards by wearing an ESD wrist strap or working on an antistatic mat. Always hold system modules by the edges and avoid touching any electronic circuitry on the cards.
	Avertissement	Lors de la manipulation de composants électroniques ou informatiques (en particulier pendant l'installation) l'équipement peut être endommagé par l'accumulation d'électricité statique. Prenez des précautions avant de toucher tout circuit ou toute carte interne, soit en portant un bracelet antistatique, soit en travaillant sur un tapis de sol antistatique. Tenez toujours les modules du système par leurs bords et évitez de toucher tout circuit électronique sur les cartes.
	Warnung	Bei der Handhabung von Computerbauteilen (insbesondere beim Einbau) können diese durch elektrostatische Aufladung beschädigt werden. Treffen Sie Vorsichtsmaßnahmen, indem Sie ein Erdungsarmband anlegen oder auf einer antistatischen Matte arbeiten, bevor Sie Bauteile oder Leiterplatten im Inneren des Geräts berühren. Halten Sie Systemmodule immer an den Kanten, und berühren Sie die elektronischen Bauteile auf den Leiterplatten nicht.



Page number	Statement type	Statement
Page 21	Caution	
	Attention	EQUIPEMENT SENSIBLE A L'ELECTRICITE STATIQUE PRENEZ DES PRECAUTIONS
	Vorsicht	Elektrostatisch empfindliches Gerät Vorsichtsmaßnahmen beachten



Page number	Statement type	Statement
Page 22	Caution	Please install the BNP3xr so as to be easily accessible and as close to a power socket outlet as possible.
	Attention	Installez le BNP3xr dans un endroit accessible et aussi près que possible d'une prise de courant.
	Vorsicht	Der BNP3xr muss möglichst leicht zugänglich und in der Nähe einer Netzsteckdose aufgestellt werden.



Page number	Statement type	Statement
Page 22	Caution	Be sure that the BNP3xr is mounted in a location that meets the environmental conditions shown in Table 3.
	Attention	Vérifiez que le BNP3xr est installé dans un lieu qui satisfait aux conditions environnementales présentées dans le tableau 3.
	Vorsicht	Vergewissern Sie sich, dass der Aufstellort des BNP3xr den in Tabelle 3 aufgeführten Umgebungsbedingungen entspricht.



Page number	Statement type	Statement
Page 24	Warning	The BNP3xr must be properly grounded to ensure safe operation. Before you connect power or turn on the BNP3xr, ground the chassis. This section provides one method of grounding. There may be others: check your network configuration for details.
	Avertissement	Le BNP3xr doit être correctement relié à la masse pour assurer un fonctionnement sécurisé. Avant de connecter le courant ou de mettre en marche le BNP3xr, reliez le châssis à la masse. Cette section indique une méthode de mise à la masse. Il peut y en avoir d'autres : vérifiez la configuration de votre réseau pour plus de détails.
	Warnung	Für einen sicheren Betrieb muss der BNP3xr vorschriftsmäßig geerdet sein. Erden Sie das Chassis des BNP3xr, bevor Sie das Gerät an die Stromversorgung anschließen oder einschalten. Dieser Abschnitt erläutert eine Erdungsmethode. Eventuell gibt es auch andere Möglichkeiten. Prüfen Sie ihre Netzwerkkonfiguration, um diesbezügliche Einzelheiten festzustellen.



Page number	Statement type	Statement
Page 24	Warning	If you are installing dual redundant power supplies, only ground one of the two power supplies.
	Avertissement	Si vous installez des doubles alimentations redondantes, ne reliez qu'une seule des alimentations à la masse.
	Warnung	Wenn Sie zwei redundante Netzteile einbauen, erden Sie nur eines der beiden Netzteile.



Page number	Statement type	Statement
Page 26	Caution	The power cord is the disconnect device for the BNP3xr. There is no power switch: once connected to the power outlet, the unit powers up immediately.
	Attention	Le cordon d'alimentation constitue le mécanisme de déconnexion du BNP3xr. Il n'y a pas d'interrupteur : une fois connecté à la prise de courant, le système est immédiatement mis sous tension.
	Vorsicht	Der BNP3xr wird mit dem Netzkabel ein- und ausgeschaltet. Es gibt keinen Netzschalter. Beim Einstecken des Netzkabels in die Steckdose wird das Gerät unmittelbar eingeschaltet.



Page number	Statement type	Statement
Page 27	Caution	Only trained personnel should install or replace this equipment.
	Attention	Seul un personnel qualifié devrait installer ou remplacer cet équipement.
	Vorsicht	Dieses Gerät darf nur von qualifiziertem Personal aufgestellt und ausgetauscht werden.



Page number	Statement type	Statement
Page 27	Caution	Make sure that the safety screws are in the locked position (turned counterclockwise) after the power supplies are installed, but before connecting power (Figure 22). Note that the locked position may be different than that of similar units. This ensures that the power supplies cannot be accidentally disconnected, causing possible damage.
	Attention	Assurez-vous que la vis de sécurité est en position bloquée (tournée dans le sens contraire des aiguilles d'une montre) après avoir installé l'alimentation, mais avant d'avoir connecté le courant (figure 22). Notez que la position bloquée peut être différente de celle d'unités similaires. Ceci constitue la preuve que l'alimentation ne peut pas être déconnectée par accident, et ainsi causer de possible dommages.
	Vorsicht	Vergewissern Sie sich, dass sich die Sicherheitsschraube in der verriegelten Position befindet (gegen den Uhrzeigersinn), nachdem das Netzteil eingebaut wurde, aber bevor das Gerät an die Stromversorgung angeschlossen wird (Abbildung 22). Beachten Sie, dass die verriegelte Position anders als bei ähnlichen Einheiten sein kann. So wird sichergestellt, dass das Netzteil nicht versehentlich getrennt wird, was zu Beschädigungen führen kann.



Page number	Statement type	Statement
Page 27	Caution	These are +48V DC power supplies, not -48V. Please connect accordingly.
	Attention	Il s'agit d'une alimentation +48V, et non -48V. Connectez en fonction.
	Vorsicht	Die Netzteile weisen Anschlusswerte von +48 V DC (Gleichstrom) auf, nicht -48 V. Bitte schließen Sie diese entsprechend an.



Page number	Statement type	Statement
Page 30	Caution	Your license is attached to the compact flash (CF); do not discard it. Even if a CF card fails, keep the device and contact RGB technical support for instructions on repair or obtaining a working replacement.
	Attention	Votre licence se trouve sur la carte mémoire Compact Flash. Ne l'égariez pas. Au cas où la carte mémoire Compact Flash serait déficiente, conservez-la et contactez le support technique RGB pour obtenir des instructions concernant la réparation ou le remplacement.
	Vorsicht	Ihre Lizenz ist auf der Compact Flash-Karte enthalten. Entsorgen Sie diese nicht. Selbst wenn eine CF-Karte ausfällt, bewahren Sie diese auf, und wenden Sie sich an den technischen Kundendienst von RGB, um Anweisungen für die Reparatur oder den Austausch durch eine funktionsfähige Karte zu erhalten.



Page number	Statement type	Statement
Page 50	Caution	Care is needed when selecting this action: forcing a redundancy change will temporarily (and briefly) interrupt services during the failover process.
	Attention	Sélectionnez cette action avec précaution : forcer un changement de redondance interrompt temporairement (et brièvement) les services pendant le processus de basculement.
	Vorsicht	Gehen Sie bei diesem Vorgang mit Bedacht vor. Das Erzwingen einer Redundanzänderung führt zu einer vorübergehenden (kurzen) Dienstunterbrechung während des Failover-Vorgangs.



Page number	Statement type	Statement
Page 163	Caution	If you replace one transport stream with another, the original will be completely deleted.
	Attention	Si vous remplacez un flux de transport par un autre, le flux original sera complètement détruit.
	Vorsicht	Beim Ersetzen eines Transportstroms durch einen anderen wird der ursprüngliche Strom vollständig gelöscht.



Page number	Statement type	Statement
Page 284	Warning	Never replace any FRU while the chassis is still connected to the power source.
	Avertissement	Ne remplacez jamais une unité remplaçable sur site si le châssis est toujours connecté à l'alimentation.
	Warnung	Tauschen Sie kein vor Ort austauschbares Teil aus, während das Chassis mit der Stromversorgung verbunden ist.



Page number	Statement type	Statement
Page 284	Warning	Do not replace any component (such as fuses) not specifically described here. For replacement beyond the FRU level, contact your technical support representative for instructions on returning the component. (See “Contacting RGB Customer Support” on page 280.)
	Avertissement	Ne remplacez aucun composant (tel que les fusibles) qui ne soit pas spécifiquement décrit ici. Pour des remplacements au-delà des unités remplaçables sur site, contactez le représentant du support technique pour connaître les instructions à suivre si vous souhaitez renvoyer le composant. (Voir “Contacting RGB Customer Support” on page 280).
	Warnung	Tauschen Sie keine Komponenten (wie Sicherungen) aus, die hier nicht ausdrücklich genannt sind. Beim Austausch von Komponenten, die keine vor Ort austauschbaren Teile sind, wenden Sie sich an den für Sie zuständigen Mitarbeiter des technischen Kundendiensts, um Anweisungen zum Zurücksenden der Komponente zu erhalten. (Siehe “Contacting RGB Customer Support” on page 280.)



Page number	Statement type	Statement
Page 291	Caution	ASI modules should always be replaced; no filler should be used.
	Attention	Les modules ASI doivent toujours être remplacés. N'utilisez jamais de bouche-trou.
	Vorsicht	ASI-Module müssen immer ersetzt werden. Verwenden Sie keine Blindblenden.

Information to Users

United States



DECLARATION OF CONFORMITY

Responsible Party Name:	RGB Networks, Inc.
Address:	390 West Java Drive Sunnyvale, CA 94089, U.S.A.
Telephone:	(877) 742-6389
Declares that product:	Broadcast Network Processor—BNP3xr Complies with Part 15 of the FCC Rules.

This device complies with Part 15 of the FCC Rules. Operations are subject to the following two conditions: (1) This device must not be allowed to cause harmful interference; (2) This device must accept any interference received, including interference that may cause undesired operation.

Modifying the equipment without RGB Networks' authorization may result in the equipment no longer complying with FCC requirements for Class A or Class B digital devices. In that event, your right to use the equipment may be limited by FCC regulations, and you may be required to correct any interference to radio or television communications at your own expense.

For Class A Equipment



Note: *This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.*

Canada

This Class A digital apparatus complies with Canadian ICES-003.

Avis de conformité à la réglementation d'Industrie Canada.

Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

European Declaration of Conformity

RGB Networks, Inc., declares that the product Broadcast Network Processor, BNP3xr to which this declaration relates is in conformity with the following standards:

- CISPR 22:2005
- EN55022:2006
- EN55024:1998 + A1:2001 + A2:2003
- EN61000-4-2: ESD immunity
- EN61000-4-3: Radiated RF field immunity
- EN61000-4-4: Immunity to electrical fast transients
- EN61000-4-5: Surge immunity
- EN61000-4-6: RF conducted immunity
- CB/UL 60950-1:2007; CAN/CSA-C22.2 No. 60950-1-07

This product follows the provisions of the EMC Directive 2004 / 108 / EC and carries the CE marking accordingly.

Support Tel: 877-RGB-NETW
FAX: (408) 701-2710

Glossary

This glossary defines the acronyms common in the video industry, and used in this guide. It is not all-inclusive but serves as a reference.

Numeric

3DES Triple Data Encryption Standard. A mode of DES that encrypts data three times. Three 64-bit keys are used, for an overall key length of 192 bits.

A

AES Advanced Encryption Standard. AES is a privacy transform for IPsec and Internet Key Exchange, and is replacing the Data Encryption Standard (DES). AES offers a larger key size and a variable key length.

Alpha Channel In reference to editing image files, an alpha channel stores selections as grayscale images. Adding alpha channels to an image allows the creation and storing of masks in order to manipulate or protect parts of an image.

ARP Address Resolution Protocol. ARP broadcasts a packet containing the IP address that the sender specifies to all hosts attached to an Ethernet connection. When the target recognizes that the IP address is its own, it returns a response.

ASI Asynchronous Serial Interface. ASI extends the functionality from strictly a video/audio-bounded device to a transport stream-based system that can store data in either a single program stream or a set of multiple program streams.

ATSC Advanced Television Systems Committee. ATSC is working to coordinate television standards among different communications media. ATSC is also developing digital television implementation strategies.

C

CA Conditional Access. Conditional access is an encryption/decryption management method by which a broadcaster controls a subscriber's access to services.

CAS Conditional Access Systems. These are systems that ensure broadcast service is accessible only to those entitled to access, usually by scrambling or encrypting the service.

CBR Constant Bit Rate. Constant bit rate encoding ensures that the rate at which a codec's output is consumed is constant. Because it is the maximum bitrate that matters, CBR is useful for streaming multimedia content on limited capacity channels. See also VBR.

CSA Common Scrambling Algorithm.

D

DCCT	Direct Channel Change Table, part of 9 tables in the ATCS PSIP. The DCCT instructs the receiver to change channels based on viewer preferences, demographics or geographical location. This table works with a DCCSDT in the set top box.
DCCSDT	DCC Selected Code Change Table, part of 9 tables in the ATCS PSIP.
DES	Data Encryption Standard. DES specifies a FIPS approved cryptographic algorithm as required by FIPS 140-1. Encrypting data converts it to an unintelligible form called cipher. The cryptographic security of the data depends on the security provided for the key used to encipher and decipher the data. Data can be recovered from cipher only by using exactly the same key used to encipher it.
DET	Data Event Table, part of 9 tables in the ATCS PSIP. The DET announces the data portion of a video/audio/data event when the data event does not match the exact duration of an video/audio event.
DHCP	Dynamic Host Configuration Protocol. DHCP servers let individual computers on an IP network extract their configurations. DHCP servers have no specific information about the individual computers until they request the information.
DOCSIS	Data Over Cable Service Interface Specifications. Now known as CableLabs Certified Cable Modems. DOCSIS specifies modulation schemes and the protocol for exchanging bidirectional signals over cable.
DPI	Digital Program Insertion. The digital splicing of one MPEG program (typically a commercial) into another based on digital cues within the MPEG transport stream.
DVB	Digital Video Broadcast. A European set of defined transmission standards for digital broadcasting systems.
DWDM	Dense Wavelength Division Multiplexing. A fiber-optic transmission technique using light wavelengths to transmit data parallel-by-bit or serial-by-character.

E

EAS	Emergency Alert System. An operational structure for national and local emergency alerts used by broadcast, cable, and wireless cable.
EBIF	Enhanced Binary Interchange Format. EBIF standard provides a solution for the delivery of interactive data to existing set-top boxes (STBs), including older models of STBs. EBIF condenses interactive applications in order to use the minimal STB resources available for interactive data delivery
ECM	Entitlement Control Messages.
ECMG	ECM Generator.
EISS	ETV Integrated Signaling Stream data ES — carries timing signals that trigger events associated with the user-agent application loaded onto the STB.

EIT	Event Information Table, part of 9 tables in the ATCS PSIP. EITs are associated with a specific virtual channel in the VCT, contain event information, and point to the location of extended text in the ETT. Each EIT PID contains 3 hours worth of events per program.
EM	Element Manager. The graphical user interface for the BNP.
EMM	Entitlement Management Message. A packet containing the information necessary to decrypt the picture.
EMMG	Entitlement Management Message Generator. The component of the conditional access headend that delivers entitlements to the multiplexers.
EOD	Everything-On-Demand.
ES	Elementary Stream, an individual audio, video, or data output stream that is transmitted in a program
ETT	Extended Text Table, part of 9 tables in the ATCS PSIP. ETTs carry longer text messages than EITs for describing events and virtual channels.
ETV	Enhanced Television.

F

FCC	Federal Communications Commission. The agency that regulates communications services, including cable television, at the Federal level.
FPGA	Field Programmable Gate Array. An array of logic gates that can be hardware-programmed to fulfill user-specified task.
FVOD	Free-Video-On-Demand.

G

GigE	Gigabit Ethernet. Ethernet which supports data transfer rates of 1 Gigabit (1,000 megabits) per second.
GBP /GBP2	Gigabit Ethernet Processor module.
GUI	Graphical User Interface.

H

HD	High Definition. High-resolution digital television combined with Dolby Digital surround sound (AC-3).
HFC	Hybrid Fiber/Coax. A distribution system combining fiber and coax cable. An HFC system is used to distribute CATV signals into a neighborhood.

I

IGMP	Internet Group Management Protocol. IP hosts use IGMP to register dynamic multicast group membership. Connected routers discover the group members using the same protocol.
IP	Internet Protocol. The network layer for the TCP/IP Protocol Suite. It is a connectionless, best-effort packet switching protocol.
ITU	International Telecommunication Union. An international organization through which governments and the private sector coordinate global telecommunications networks and devices.

J

JRE	Java Runtime Environment. JRE is made up of the Java virtual machine, the Java platform core classes, and supporting files.
-----	---

L

LED	Light Emitting Diode. A semiconductor diode that emits light when current passes through it. LEDs are used as indicators.
-----	---

M

MGT	Master Guide Table, part of 9 tables in the ATCS PSIP. MGT provides program-identification (PID) locations so a receiver can find the other tables, and informs the receiver of changes or table updates.
MIB	Management Information Base. MIB defines the variables needed by the SNMP protocol to monitor and control elements in a network.
MID	Mid-plane.
MPEG	Moving Pictures Experts Group. The standards group and the standard for compression and storage of motion video.
MPTS	Multi-Program Transport Stream. A combined multiplex of video streams.
MUX	Multiplexer. A device that both combines multiple data sources into a single data stream for transmission, and demultiplexes the single data stream into its composite forms.

N

NTP	Network Time Protocol. A TCP protocol that assures accurate local time-keeping with reference to radio and atomic clocks, and can synchronize distributed clocks within milliseconds.
NTSC	National Television System Committee. Committee that defined the current standard for analog color television in North America, as well as the name for the standard. The format is 525 lines in 4MHz of video bandwidth.

O

OOB Out-Of-Band.

P

PAT Program Association Table. A table ID that indicates the MPEG-2 SI packet type.

PCR Program Clock Reference.

PMT Program Map Table. A table ID that indicates the MPEG-2 SI packet type.

PNG Portable Network Graphics. PNG format is used for lossless compression and for display of images on the web. Unlike GIF, PNG supports 24-bit images and produces background transparency without jagged edges. PNG format supports RGB, Indexed Color, Grayscale, and Bitmap mode images without alpha channels. PNG preserves transparency in grayscale and RGB images.

PSI Program Specific Information, as part of MPEG-2.

PSIP Program and System Information Protocol. PSIP is a collection of nine tables that allow the DTV transport stream to provide information about a station's services and programming. These nine tables include:

- Master Guide Table (MGT)
- System Time Table (STT)
- Virtual Channel Table (VCT)
- Rating Region Table (RRT)
- Event Information Table (EIT)
- Extended Text Table (ETT)
- Data Event Table (DET)
- Directed Channel Change Table (DCCT)
- DCC Selected Code Change Table (DCCSDT)

Q

QAM Quadrature Amplitude Modulation. This is the modulation technique used in systems carrying digital video.

QoS Quality of Service. Guarantees network bandwidth and availability for applications.

R

RF Radio Frequency. Television signals are modulated onto RF signals and are then demodulated by the television tuner.

RTP	Real Time Protocol. RTP provides services such as payload type identification, sequence numbering, time-stamping, and delivery monitoring to real-time applications.
RU	Rack Unit. A common increment of equipment space height. The height of 1 RU is 1.75 inches.

S

SAP	Secondary Audio Program. A way to provide a second audio channel within a TV broadcast channel. Commonly used for stereophonic sound or bilingual audio tracks.
SCTE	Society of Cable Telecommunications Engineers. An organization that develops training for cable television installers and engineers and standards for the cable industry.
SD	Standard definition.
SFP	Small Form Factor Pluggable. An optical interface that is used in network switches for Fibre Channel, Gigabit Ethernet and InfiniBand.
SNMP	Simple Network Management Protocol. A protocol used to monitor and control network devices, and to manage configurations, statistics collection, performance, and security.
SPTS	Single Program Transport Stream.
SSM	Source Specific Multicast. A way to deliver multicast packets whereby only packets delivered to a receiver are those that have originated from a specific source IP address that has been requested by the receiver.
STP	Strip Processor. The STP modules (NP and ASI) is one of the units that comprise the BNP.
STT	System Table Time. Allows a broadcaster to present time indicators to the consumer, ensuring that the time is synchronized.
SVOD	Subscription-Video-on-Demand. This is a Video-on-Demand service offered by subscription, providing viewers with access to select programs from the libraries of featured cable networks.

T

TFTP	Trivial File Transfer Protocol. TFTP uses UDP and is often used by servers to boot diskless workstations, X-terminals, and routers.
TS	Transport Stream, the result of multiplexed--or combined--audio, video, or other data content that is packaged and transmitted through the broadcast network.
TVCT	A Terrestrial Virtual Channel Table is a mandatory PSIP table that lists all the virtual channels available in an ATSC transport stream, and optionally, virtual channels available in other ATSC transport streams.

U

UDP	User Datagram Protocol. A connectionless protocol that runs on top of IP networks. UDP provides a direct way to send information over an IP network. It is used primarily for broadcasting messages over a network.
-----	---

V

VBI	Vertical Blanking Interval. A portion of a television signal that carries non-audio/video data, such as closed-caption text.
VBR	Variable Bit Rate. VBR streams vary in bandwidth over time.
VCT	Virtual Channel Table, part of 9 tables in the ATCS PSIP. The VCT contains a list of all the channels that are or will be online, along with their channel name and number. This table contains the set of data that enables a receiver to tune and locate the service being broadcast.
VOD	Video-on-Demand. Video-on-demand systems allow users to watch video content over a network as part of an interactive television system, either by streaming or by download.

X

XFP	10 Gigabit Small Form Factor Pluggable (SFP). The XFP is a pluggable, hot-swappable optical interface for 10 Gigabit SONET/SDH, Fibre Channel, Gigabit Ethernet, and other applications. XFP modules are optical transceivers, typically 1310nm or 1550nm. Optical XFPs include digital diagnostics.
-----	--

Numerics

19-inch rack 22

A

AAA 57

AAA default IP 65

AAA default port 65

AAA default protocol 65

AAA Server Order menu 67

AAA servers 63

access criteria 266, 272

Account level

 administrator 62

 operator 62

 user 62

Ad Server 214

ad splicing 221

Adding AAA servers 63

advanced messaging 7

air flow 22

Alarms 275

 Viewing 275

alpha channel 90

alpha channels 8, 90

antistatic mat 16

applying power 26, 27, 28

ASI 9, 21

assumptions 2

Asynchronous Serial Interface 20

authentication, authorization and accounting
 (AAA) 57

B

bit rate 168

Bitrates

 Monitoring 208

BNP3xr 1

bracket

 rack mount 15

C

CA 35

CAS 237, 238, 255, 256, 258, 259, 266, 274

Caution

 mounting location and environmental
 conditions 22

Change Password 62

Changing Server Order 66

chassis

 ground 24

 view 36

Chassis Redundancy 43

common scrambling algorithm 8, 237

 CSA 237

compact flash 17, 18, 30, 279, 280

components 16

conditional access system 237

configure Global AAA parameters 59

configure passwords 61

crawl 8

creating

 transport stream 127, 131, 137, 141, 142

creating multiple TS 128

CSA 8, 237

Customer Support

 Contacting 280

CVCT 140

CWG 8, 237

D

deleting 163

 streams 163

Deleting Servers 68

descriptor rules 223

Digital Program Insertion (DPI) 213

document audience 2

document organization 2

DPI Based

 Ad Splicing 7

DTV transport stream 140

DVB Transport Stream 142

DVB-CA 8, 35, 237, 238, 239, 240, 241, 246, 251,
 252, 254, 264, 265, 266, 267, 269, 270, 272,
 274

 access criteria 266

 CAS mode 253

 create ECM

 access criteria 272

 CAS ID 271

 PID 272

 sub CAS ID 271

 create ECMG

 CAS ID 257

 CAS name 257

 channel count 257

 channel start offset 257

 ECMG IP address 257

 port 257

 second CAS ID 257

 Sub CAS ID 257

 create EMM

 client ID 260

 data ID 260

- max bandwidth 260
 - second CAS ID 260
 - create SCG
 - CP duration 268
 - disable 269
 - scramble level 269
 - transport stream 268
 - createECM
 - private data 272
 - createECMG, CAS name 254
 - creating input TS 243
 - creating output TS 244
 - crypto period duration 252
 - CW mode 253
 - ECM ID 271
 - ECM test timeout 253
 - EIS test interval 253
 - EIS test timeout 253
 - EIT source 245
 - EMM multicast IP 254
 - EMM test interval 253
 - EMMG data port number 254
 - EMMG TCP control port number 253
 - external EIS port number 253
 - global parameters 250
 - license 239
 - modulation mode 245
 - network ID 244
 - private data 260
 - required components 238
 - SCG ID 268
 - scramble level 252
 - SDT source 245
 - TS type 244
 - unique TS ID 244
 - update timer 254
- E**
- EAS 7
 - audio override 8
 - audio stream insertion 8
 - configuration 69
 - EBIF 219, 220, 222, 225, 226, 228, 229, 230, 322
 - late-bind 231
 - pre-bind 224, 227, 231
 - pre-bind, network 231
 - pre-bind, passthrough 224
 - pre-bind, passthrough, keep 228
 - pre-bind. passthrough, keep 228
 - ECM 8, 237, 253, 270, 271, 272, 274
 - ECMG 9, 237, 238, 253, 256, 257, 274
 - Edit AAA Server 64, 65
 - Editing AAA Servers 63
 - Editing an AAA Server 64
 - EIS 9, 237, 238, 245, 252, 253, 254, 274
 - EISS 220, 222, 226, 228, 230
 - electrostatic precautions 16
 - Element Manager 2, 31, 32, 33, 34, 35, 36, 107, 110, 119, 221, 225, 227, 229, 231, 234, 238, 239, 240, 241, 251, 254, 264, 280
 - menu descriptions 35
 - Element Monitor
 - reboot with 116
 - Element Stream 179
 - elementary stream 206
 - emergency alert system 7
 - EMM 8, 237, 253, 254, 259, 261, 263, 274
 - EMMG 9, 237, 238, 253, 254, 258, 260, 274
 - Enabling AAA Settings 60
 - enhanced television (ETV) 219
 - enhanced television binary interchange format (EBIF) 219
 - entitlement control message generator 9, 237
 - entitlement management message generator 9, 237
 - ES 205
 - ESD 16, 284
 - wrist strap 16
 - Ethernet Control Port 38
 - Ethernet control port 50
 - ETV 219, 220, 231
 - configuration 226, 227, 229, 232
 - placeholder ES 223
 - pre-bind 231
 - ETV integrated signaling stream (EISS) 220
 - event information scheduler 9, 237
 - Events 275
 - Viewing 275
- F**
- fan tray 21
 - fast Ethernet 29, 30, 50
 - Field-replaceable Unit *see* FRU
 - force redundancy 50
 - Force Sync 45, 46
 - front bezel 16, 17, 289, 290
 - front panel 16, 17
 - FRU 284
 - FTP 108
- G**
- GBP
 - installation 289
 - GBP module 20
 - GigE 9, 11, 12, 18, 25, 30, 38, 53, 54
 - IP address 54
 - GigE ports 120
 - Global 59
 - global AAA options 59
 - Grooming 7, 163, 173
 - grooming 119
 - PSI/SI table 247
 - ground
 - chassis 24

grounding 15, 16, 24, 25

H

HRC 30

I

Input Source 122, 123

installation 26, 27

 rack mount 22

 requirements 15

installing 15

 XFPs 25

intended audience 2

IP Address 43

IP address 34

IPaddress

 determining (with DHCP running) 53

J

Java 2, 32, 110

JRE 32

L

late-bind 231

 source 233, 234, 236

LED indicator 279, 280

LEDs 279

LEDs, defined 17

Light Emitting Diodes, *see* LEDs

Local Configuration 61

Local screen 62

local user account 61

Local, 59

login 33, 34

logo overlay 69

 positioning 92

 zone configuration 91

M

mapping 164

mapping scheme, SFP port 19

master guide table 140

mat, antistatic 16

menus

 chassis view 36

 software upgrade 280

message system

 operator alert messages 76

messaging system

 configuration 69

MGT 140

mirroring

 removing 55

modifying

 programs 156

 streams 156

module

 GBP module 20

MSO 219

Multiple IP Creation 128

multiple TS creation 128

Multiple UDP Creation 128

multiplex 139

Multiplexing 7

N

Network Information Tables (NIT) 145

Network Information Tables, *see* NIT

network processing modules 20

NIT

noise emissions 296

nut, M4 25

O

overlay 8

P

PAL content 43

Panel 16

passthrough 224, 228

 keep 228

passwords 62

PID 139

PNG 8, 90

port

 mapping scheme 19

port connection

 connecting ports 29

port mirroring 54

Portable Network Graphics 8, 90

Postblack 217

Postblack Configuration 44, 218

power cord 15

power cycle 116

power supply

 redundant 21

 removing and replacing 284

power, applying 26, 28

pre-bind 220, 221, 224, 227, 228, 229, 231

PROC3 21

program descriptors

 managing 203

programs 163

 deleting 163

 modifying 156

Protocol 61

PSIP 121, 140

Q

Quality of Service (QoS) 7

R

rack mount 15, 22, 289
 bracket 15
RADIUS 57
Radius 61, 67
reboot 35, 108, 116, 117, 292
Redundancy 50
redundancy 13, 29, 30
 Chassis-level 13
 configure 47
 force change 50
Redundant Chassis Configuration 43
redundant fan tray 21
regroom 35
 program redundancy 114
regrooming 114
regulatory 285
Remote Only 61
Remote user authentication 57
remove chassis redundancy, 35
Reordering Server List 65
requirements for installation 15
RGB 90
RRT 140

S

SCG 35, 254, 264, 265, 267, 268, 269, 270, 272
scheduler 164
scrambling
 verifying 274
scrambling, verifying 264
SCS 8, 237
SCTE 30 7, 213, 215
SCTE 35 7, 213, 215
SCTE Transport Stream 141
serial port 16, 17
Server Configuration 62
Server Order Behavior 67
Servers 59, 63
Servers tab 62, 65
service-level redundancy 12
services
 stopping 115
set-top boxes (STBs) 219
SFP
 mapping schemes 19
Shared Secret 65
SimulCrypt Engine 8, 237
Single Program Transport Stream (SPTS) 132
software upgrade 280
Standby Chassis 46
Status Bar 277
STB 219, 220

stop service 115
STP module 20, 291
Streams
 Deleting 163
 Modifying 156
streams
 deleting 163
 modifying 156
STT 140
Switched Digital Video (SDV) 10
synchronize
 input to output 166

T

tables 140
TACACS 61
TACACS+ 57, 67
temperature
 operating 22
 storage 22
Terrestrial Virtual Channel Table 140
time zone 42
tools required 15
transparency 90
transport stream
 creating 127, 131, 137, 141, 142
 join/disjoin 261, 262
transport streams 120
Transrating 7
TVCT 140

U

Unreferenced PID 190
User Accounts 62
user agent 219

V

view
 front 16
Virtual IP Address Configuration 44

W

Warning
 do not replace fuses 284
 replacing FRU while power up 284
 use ESD 16
wire strippers 25

X

X Y coordinates 92
XFP
 installation 25